



1128950164

VRF Concealed Duct High Static Pressure air conditioner

Model name:

40VD____H-8S-TST

For commercial use
สำหรับใช้งานเชิงพาณิชย์

Installation Manual

Notice: *Carrier* is committed to continuously improving its products to ensure the highest quality and reliability standards, and to meet local regulations and market requirements. All features and specifications are subject to change without prior notice.

Installation Manual 1 English

คู่มือการติดตั้ง 30 ภาษาไทย



Original instruction

- Please read this Installation Manual carefully before installing the Air Conditioner.
- This Manual describes the installation method of the indoor unit.
 - For installation of the outdoor unit, follow the Installation Manual attached to the outdoor unit.

ADOPTION OF NEW REFRIGERANT

This Air Conditioner uses R410A an environmentally friendly refrigerant.

Information

If U series models (TU2C-Link) are combined with models other than U series (TCC-Link), the wiring specifications and maximum number of connectable indoor units will be changed. Pay attentions to their communication specifications when carrying out the installation, maintenance, or repair. For its details, refer to the **“Electrical connection”** in this Manual.

Contents

1	Precautions for safety	3
2	Accessory parts	7
3	Selection of installation place	7
4	Installation	9
5	Drain piping	10
6	Duct design	13
7	Refrigerant piping	14
8	Electrical connection	15
9	Applicable controls	19
10	Test run	21
11	Maintenance	22
12	Troubleshooting	23

Thank you for purchasing this air conditioner.

Please read carefully through these instructions that contain important information and ensure that you understand them.

After completing the installation work, hand over this Installation Manual as well as the Owner’s Manual provided to the user, and ask the user to keep them in a safe place for future reference.

Generic Denomination: Air Conditioner

Definition of Qualified Installer or Qualified Service Person

The air conditioner must be installed, maintained, repaired and removed by a qualified installer or qualified service person. When any of these jobs is to be done, ask a qualified installer or qualified service person to do them for you. A qualified installer or qualified service person is an agent who has the qualifications and knowledge described in the following table.

Agent	Qualifications and knowledge which the agent must have
Qualified installer	<ul style="list-style-type: none"> • The qualified installer is a person who installs, maintains, relocates and removes the air conditioners. He or she has been trained to install, maintain, relocate and remove the air conditioners or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. • The qualified installer who is allowed to do the electrical work involved in installation, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. • The qualified installer who is allowed to do the refrigerant handling and piping work involved in installation, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. • The qualified installer who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.
Qualified service person	<ul style="list-style-type: none"> • The qualified service person is a person who installs, repairs, maintains, relocates and removes the air conditioners. He or she has been trained to install, repair, maintain, relocate and remove the air conditioners or, alternatively, he or she has been instructed in such operations by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to these operations. • The qualified service person who is allowed to do the electrical work involved in installation, repair, relocation and removal has the qualifications pertaining to this electrical work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to electrical work on the air conditioners or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. • The qualified service person who is allowed to do the refrigerant handling and piping work involved in installation, repair, relocation and removal has the qualifications pertaining to this refrigerant handling and piping work as stipulated by the local laws and regulations, and he or she is a person who has been trained in matters relating to refrigerant handling and piping work on the air conditioners or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work. • The qualified service person who is allowed to work at heights has been trained in matters relating to working at heights with the air conditioners or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.



Definition of Protective Gear

When the air conditioner is to be transported, installed, maintained, repaired or removed, wear protective gloves and 'Safety' work clothing.
 In addition to such normal protective gear, wear the protective gear described below when undertaking the special work detailed in the following table.
 Failure to wear the proper protective gear is dangerous because you will be more susceptible to injury, burns, electric shocks and other injuries.

Work undertaken	Protective gear to wear
All types of work	Protective gloves 'Safety' working clothing
Electrical-related work	Gloves to provide protection for electricians and from heat Insulating shoes Clothing to provide protection from electric shock
Work at heights (50 cm or more)	Helmets for use in industry
Transportation of heavy objects	Shoes with additional protective toe cap
Repair of outdoor unit	Gloves to provide protection for electricians and from heat

These safety cautions describe important matters concerning safety to prevent injury to users or other people and damages to property. Please read through this manual after understanding the contents below (meanings of indications), and be sure to follow the description.


Indication	Meaning of Indication
WARNING	Text set off in this manner indicates that failure to adhere to the directions in the warning could result in serious bodily harm (*1) or loss of life if the product is handled improperly.
CAUTION	Text set off in this manner indicates that failure to adhere to the directions in the caution could result in slight injury (*2) or damage to property (*3) if the product is handled improperly.

- *1: Serious bodily harm indicates loss of eyesight, injury, burns, electric shock, bone fracture, poisoning, and other injuries which leave aftereffect and require hospitalization or long-term treatment as an outpatient.
- *2: Slight injury indicates injury, burns, electric shock, and other injuries which do not require hospitalization or long-term treatment as an outpatient.
- *3: Damage to property indicates damage extending to buildings, household effects, domestic livestock, and pets.

Center of gravity

(Unit: mm)

Use forklift to carry in the air conditioner units and use winch or hoist at installation of them.



Warning indications on the air conditioner unit

Warning indication	Description		
<table border="1"> <tr> <td>WARNING</td> </tr> <tr> <td>ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.</td> </tr> </table>	WARNING	ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.	WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.
WARNING			
ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.			
<table border="1"> <tr> <td>WARNING</td> </tr> <tr> <td>Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.</td> </tr> </table>	WARNING	Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.	WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.
WARNING			
Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.			
<table border="1"> <tr> <td>CAUTION</td> </tr> <tr> <td>High temperature parts. You might get burned when removing this panel.</td> </tr> </table>	CAUTION	High temperature parts. You might get burned when removing this panel.	CAUTION High temperature parts. You might get burned when removing this panel.
CAUTION			
High temperature parts. You might get burned when removing this panel.			
<table border="1"> <tr> <td>CAUTION</td> </tr> <tr> <td>Do not touch the aluminum fins of the unit. Doing so may result in injury.</td> </tr> </table>	CAUTION	Do not touch the aluminum fins of the unit. Doing so may result in injury.	CAUTION Do not touch the aluminium fins of the unit. Doing so may result in injury.
CAUTION			
Do not touch the aluminum fins of the unit. Doing so may result in injury.			
<table border="1"> <tr> <td>CAUTION</td> </tr> <tr> <td>BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.</td> </tr> </table>	CAUTION	BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.	CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.
CAUTION			
BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.			

1 Precautions for safety

The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual.

WARNING

General

- Before starting to install the air conditioner, read through the Installation Manual carefully, and follow its instructions to install the air conditioner.
 - Only a qualified installer or qualified service person is allowed to do installation work. Inappropriate installation may result in water leakage, electric shock or fire.
 - Do not use any refrigerant different from the one specified for complement or replacement. Otherwise, abnormally high pressure may be generated in the refrigeration cycle, which may result in a failure or explosion of the product or an injury to your body.
 - Before opening the electrical control box cover of the indoor unit or service panel of the outdoor unit, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in electric shocks through contact with the interior parts. Only a qualified installer(*1) or qualified service person(*1) is allowed to remove the electrical control box cover of the indoor unit or service panel of the outdoor unit and do the work required.
 - Before carrying out the installation, maintenance, repair or removal work, set the circuit breaker to the OFF position. Otherwise, electric shocks may result.
 - Place a “Work in progress” sign near the circuit breaker while the installation, maintenance, repair or removal work is being carried out. There is a danger of electric shocks if the circuit breaker is set to ON by mistake.
- Only a qualified installer(*1) or qualified service person(*1) is allowed to undertake work at heights using a stand of 50 cm or more or to remove the intake grille of the indoor unit to undertake work.
 - Wear protective gloves and safety work clothing during installation, servicing and removal.
 - Do not touch the aluminium fin of the unit. You may injure yourself if you do so. If the fin must be touched for some reason, first put on protective gloves and safety work clothing, and then proceed.
 - Before opening the inspection opening, set the circuit breaker to the OFF position. Failure to set the circuit breaker to the OFF position may result in injury through contact with the rotation parts. Only a qualified installer (*1) or qualified service person(*1) is allowed to remove the inspection opening and do the work required.
 - When work is performed at heights, use a ladder which complies with the ISO 14122 standard, and follow the procedure in the ladder’s instructions. Also wear a helmet for use in industry as protective gear to undertake the work.
 - Before cleaning the filter (sold separately) or other parts of the outdoor unit, set the circuit breaker to OFF without fail, and place a “Work in progress” sign near the circuit breaker before proceeding with the work.
 - Before working at heights, put a sign in place so that no-one will approach the work location, before proceeding with the work. Parts and other objects may fall from above, possibly injuring a person below. While carrying out the work, wear a helmet for protection from falling objects.
 - The refrigerant used by this air conditioner is the R410A.
 - The air conditioner must be transported in stable condition. If any part of the product is broken, contact the dealer.



- When the air conditioner must be transported by hand, carry it by four or more people.
- Do not move or repair any unit by yourself. There is high voltage inside the unit. You may get electric shock when removing the cover and main unit.
- This appliance is intended to be used by expert or trained users in shops, in light industry, or for commercial use by lay persons.
- Do not add any other devices without factory advice.

Selection of installation location

- When the air conditioner is installed in a small room, provide appropriate measures to ensure that the concentration of refrigerant leakage occur in the room does not exceed the critical level.
- Do not install in a location where flammable gas leaks are possible. If the gas leak and accumulate around the unit, it may ignite and cause a fire.
- To transport the air conditioner, wear shoes with additional protective toe caps.
- To transport the air conditioner, do not take hold of the bands around the packing carton. You may injure yourself if the bands should break.
- Install the indoor unit at least 2.5 m above the floor level since otherwise the users may injure themselves or receive electric shocks if they poke their fingers or other objects into the indoor unit while the air conditioner is running.
- Do not place any combustion appliance in a place where it is directly exposed to the wind of air conditioner, otherwise it may cause imperfect combustion.

Installation

- Suction duct length must be longer than 850 mm.
- When the indoor unit is to be suspended, the designated hanging bolts (M10 or W3/8) and nuts (M10 or W3/8) must be used.
- Install the air conditioner securely in a location where the base can sustain the weight adequately. If the strength is not enough, the unit may fall down resulting in injury.
- Follow the instructions in the Installation Manual to install the air conditioner. Failure to follow these instructions may cause the product to fall down or topple over or give rise to noise, vibration, water leakage or other trouble.
- Carry out the specified installation work to guard against the possibility of high winds and earthquake. If the air conditioner is not installed appropriately, a unit may topple over or fall down, causing an accident.
- If refrigerant gas has leaked during the installation work, ventilate the room immediately. If the leaked refrigerant gas comes in contact with fire, noxious gas may generate.
- Use forklift to carry in the air conditioner units and use winch or hoist at installation of them.
- Helmet must be worn to protect your head from falling objects. Especially, when you work under an inspection opening, helmet must be worn to protect your head from falling objects from the opening.

Refrigerant piping

- Install the refrigerant pipe securely during the installation work before operating the air conditioner. If the compressor is operated with the valve open and without refrigerant pipe, the compressor sucks air and the refrigeration cycles is over pressurized, which may cause a injury.

- Tighten the flare nut with a torque wrench in the specified manner. Excessive tightening of the flare nut may cause a crack in the flare nut after a long period, which may result in refrigerant leakage.
- After the installation work, confirm that refrigerant gas does not leak. If refrigerant gas leaks into the room and flows near a fire source, such as a cooking range, noxious gas may be generated.
- When the air conditioner has been installed or relocated, follow the instructions in the Installation Manual and purge the air completely so that no gases other than the refrigerant will be mixed in the refrigerating cycle. Failure to purge the air completely may cause the air conditioner to malfunction.
- Nitrogen gas must be used for the airtight test.
- The charge hose must be connected in such a way that it is not slack.

Electrical wiring

- Only a qualified installer(*1) or qualified service person(*1) is allowed to carry out the electrical work of the air conditioner. Under no circumstances must this work be done by an unqualified individual since failure to carry out the work properly may result in electric shocks and/or electrical leaks.
- To connect the electrical wires, repair the electrical parts or undertake other electrical jobs, wear gloves to provide protection for electricians, insulating shoes and clothing to provide protection from electric shocks. Failure to wear this protective gear may result in electric shocks.
- Use wiring that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws. Use of wiring which does not meet the specifications may give rise to electric shocks, electrical leakage, smoking and/or a fire.
- Connect earth wire. (Grounding work)
Incomplete grounding causes an electric shock.

- Do not connect earth wires to gas pipes, water pipes, and lightning conductor or telephone earth wires.
- After completing the repair or relocation work, check that the earth wires are connected properly.
- Install a circuit breaker that meets the specifications in the Installation Manual and the stipulations in the local regulations and laws.
- Install the circuit breaker where it can be easily accessed by the agent.
- When installing the circuit breaker outdoors, install one which is designed to be used outdoors.
- Under no circumstances the power wire must not be extended. Connection trouble in the places where the wire is extended may give rise to smoking and/or a fire.
- Electrical wiring work shall be conducted according to law and regulation in the community and Installation Manual. Failure to do so may result in electrocution or short circuit.

Test run

- Before operating the air conditioner after having completed the work, check that the electrical control box cover of the indoor unit and service panel of the outdoor unit are closed, and set the circuit breaker to the ON position. You may receive an electric shock if the power is turned on without first conducting these checks.
- If there is any kind of trouble (such as an error display has appeared, smell of burning, abnormal sounds, the air conditioner fails to cool or heat or water is leaking) has occurred in the air conditioner, do not touch the air conditioner yourself but set the circuit breaker to the OFF position, and contact a qualified service person. Take steps to ensure that the power will not be turned on (by marking "out of service" near the circuit breaker, for instance) until qualified service person arrives. Continuing to use the air conditioner in the trouble status may cause mechanical problems to escalate or result in electric shocks or other trouble.



- After the work has finished, use an insulation tester set (500V Megger) to check the resistance is 1MΩ or more between the charge section and the non-charge metal section (Earth section). If the resistance value is low, a disaster such as a leak or electric shock is caused at user's side.
- Upon completion of the installation work, check for refrigerant leaks and check the insulation resistance and water drainage. Then conduct a test run to check that the air conditioner is operating properly.

Explanations given to user

- Upon completion of the installation work, tell the user where the circuit breaker is located. If the user does not know where the circuit breaker is, he or she will not be able to turn it off in the event that trouble has occurred in the air conditioner.
- After the installation work, follow the Owner's Manual to explain to the customer how to use and maintain the unit.

Relocation

- Only a qualified installer(*1) or qualified service person(*1) is allowed to relocate the air conditioner. It is dangerous for the air conditioner to be relocated by an unqualified individual since a fire, electric shocks, injury, water leakage, noise and/or vibration may result.
- When carrying out the pump-down work shut down the compressor before disconnecting the refrigerant pipe. Disconnecting the refrigerant pipe with the service valve left open and the compressor still operating will cause air or other gas to be sucked in, raising the pressure inside the refrigeration cycle to an abnormally high level, and possibly resulting in rupture, injury or other trouble.

⚠ CAUTION

New refrigerant air conditioner installation

- **This air conditioner adopts the new HFC refrigerant (R410A) which does not destroy ozone layer.**
- The characteristics of R410A refrigerant are; easy to absorb water, oxidizing membrane or oil, and its pressure is approx. 1.6 times higher than that of refrigerant R22. Accompanied with the new refrigerant, refrigerating oil has also been changed. Therefore, do not let water, dust, former refrigerant, or refrigerating oil enter the refrigerating cycle during installation work.
- To prevent charging an incorrect refrigerant and refrigerating oil, the sizes of connecting sections of charging port of the main unit and installation tools are changed from those for the conventional refrigerant.
- Accordingly the exclusive tools are required for the new refrigerant (R410A).
- For connecting pipes, use new and clean piping designed for R410A, and please care so that water or dust does not enter.

To disconnect the appliance from main power supply.







- This appliance must be connected to the main power supply by means of a switch with a contact separation of at least 3 mm.

The installation fuse (all types can be used) must be used for the power supply line of this conditioner.

(*1) Refer to the "Definition of Qualified Installer or Qualified Service Person."

2 Accessory parts

■ Accessory parts

Part name	Q'ty	Shape	Usage
Installation Manual	1	This manual	(Hand over to customers)
Heat insulating pipe	2	 (200×200×6t)	For heat insulation of gas pipe and liquid pipe connecting section
Washer	8		For hanging-down unit
Hose band	1		For connecting drain pipe
Flexible hose	1		For adjusting center of drain pipe
Heat insulator	1	 (220×300×10t)	For heat insulation of drain connecting section
Seal material	3	 (45×45×3t)	For sealing of wire connecting port

3 Selection of installation place

Avoid installing in the following places

Select a location for the indoor unit where the cool or warm air will circulate evenly.

Avoid installation in the following kinds of locations.

- Saline area (coastal area)
- Locations with acidic or alkaline atmospheres (such as areas with hot springs, factories where chemicals or pharmaceuticals are made and places where the exhaust air from combustion appliances will be sucked into the unit).
Doing so may cause the heat exchanger (its aluminum fins and copper pipes) and other parts to become corroded.
- Locations with atmospheres with mist of cutting oil or other types of machine oil.
Doing so may cause the heat exchanger to become corroded, mists caused by the blockage of the heat exchanger to be generated, the plastic parts to be damaged, the heat insulators to peel off, and other such problems to result.
- Places where iron or other metal dust is present. If iron or other metal dust adheres to or collects on the interior of the air conditioner, it may spontaneously combust and start a fire.
- Locations where vapors from food oils are formed (such as kitchens where food oils are used).
Blocked filters may cause the air conditioner's performance to deteriorate, condensation to form, the plastic parts to be damaged, and other such problems to result.
- Locations near obstructions such as ventilation openings or lighting fixtures where the flow of the blown air will be disrupted (a disruption of the air flow may cause the air conditioner's performance to deteriorate or the unit to shut down).
- Locations where an in-house power generator is used for the power supply.
The power line frequency and voltage may fluctuate, and the air conditioner may not work properly as a result.
- On truck cranes, ships or other moving conveyances.
- The air conditioner must not be used for special applications (such as for storing food, plants, precision instruments or art works).
(The quality of the items stored may be degraded.)
- Locations where high frequencies are generated (by inverter equipment, in-house power generators, medical equipment or communication equipment).
(Malfunctioning or control trouble in the air conditioner or noise may adversely affect the equipment's operation.)
- Locations where there is anything under the unit installed that would be compromised by wetness.
(If the drain has become blocked or when the humidity is over 80%, condensation from the indoor unit will drip, possibly causing damage to anything underneath.)
- In the case of the wireless type of system, rooms with the inverter type of fluorescent lighting or locations exposed to direct sunlight.
(The signals from the wireless remote controller may not be sensed.)
- Locations where organic solvents are being used.
- The air conditioner cannot be used for liquefied carbonic acid cooling or in chemical plants.
- Location near doors or windows where the air conditioner may come into contact with high-temperature, high-humidity outdoor air.
(Condensation may occur as a result.)
- Locations where special sprays are used frequently.
- Places with poor ventilation.

■ Installation under high-humidity atmosphere

In some cases including the rainy season, especially inside of the ceiling may become high-humidity atmosphere (dew-point temperature: 23 °C or higher).

1. Installation to inside of the ceiling with tiles on the roof
 2. Installation to inside of the ceiling with slated roof
 3. Installation to a place where inside of the ceiling is used for pathway to intake the fresh air
 4. Installation to a kitchen
- In the above cases, additionally attach the heat insulator to all positions of the air conditioner, which come to contact with the high-humidity atmosphere. In this case, arrange the side plate (Check port) so that it is easily removed.
 - Apply also a sufficient heat insulation to the duct and connecting part of the duct.





[Reference]	Condensation test conditions
Indoor side:	27 °C dry bulb temperature 24 °C wet bulb temperature
Air volume:	Low air volume, operation time 4 hours

■ Installation space

(Unit: mm)

Reserve sufficient space required for installation or service work.

Space required for installation and servicing



※1 If there are enough space under the unit (more than 1000 mm) the service door (Ceiling opening) is not necessary.

■ Filter cleaning sign term setting

The lighting term setup of the filter sign (Notification of filter cleaning) of the remote controller can be changed according to the condition of installation.

For setup method, refer to "Filter sign setting" in the Applicable controls of this Manual.


4 Installation

CAUTION

- Strictly comply with the following rules to prevent damage of the indoor units and human injury.
- Do not put a heavy article on the indoor unit or let a person get on it. (Even units are packaged)
 - Carry in the indoor unit as it is packaged if possible. If carrying in the indoor unit unpacked by necessity, use buffering cloth or other material to not damage the unit.
 - To move the indoor unit, hold the hooking brackets (4 positions) only.
Do not apply force to the other parts (such as refrigerant pipe, drain pan, foamed parts, or resin parts).
 - Carry the package by four or more persons, and do not bundle it with plastic band at positions other than specified.
 - To install vibration isolation material to hanging bolts, confirm that it does not increase the unit vibration.

External dimensions

(Unit: mm)



Installation of hanging bolt

- Consider the piping / wiring after the unit is hung to determine the location of the indoor unit installation and orientation.
- After the location of the indoor unit installation has been determined, install hanging bolts.
- For the dimensions of the hanging bolt pitches, refer to the external view.
- When a ceiling already exists, lay the drain pipe, refrigerant pipe, control wires, and remote controller wires to their connection locations before hanging the indoor unit.

Procure hanging bolts washer and nuts for installing the indoor unit (these are not supplied).

Hanging bolt	M10 or W3/8	4 pieces
Nut	M10 or W3/8	12 pieces
Washer	M10	8 pieces

Installation of hanging bolt

Use M10 hanging bolts (4 pcs, locally procured). Matching to the existing structure, set pitch according to size in the unit external view as shown below.


New concrete slab	
Install the bolts with insert brackets or anchor bolts.	
 (Blade type bracket)	 (Slide type bracket)
 Rubber Anchor bolt (Pipe hanging anchor bolt)	
Steel frame structure	
Use existing angles or install new support angles.	
 Hanging bolt, Hanging bolt, Support angle	
Existing concrete slab	
Use a hole-in anchors, hole-in plugs, or a hole-in bolts.	

Installation of indoor unit

Treatment of ceiling



The ceiling differs according to structure of building. For details, consult your constructor or interior finish contractor.
In the process after the ceiling board has been removed, it is important to reinforce ceiling foundation (frame) and to keep horizontal level of installed ceiling correctly in order to prevent vibration of ceiling board.

- Attach the nuts and the M10 flat washers to the hanging bolt.
- Put washers at up and down of the hanging bracket of the indoor unit to hang down the indoor unit.
- Check that four sides are horizontal with a level gauge. (Horizontal degree: Within 5 mm)



REQUIREMENT


- Hang the unit in a horizontal position. When unit is hunged to slant, it may cause overflow of drainage.
- Install the unit within the dimension according to the figure below.
- Use level gauge to confirm whether the unit is hang horizontally.



■ REQUIREMENT

Removing the cardboard for transportation

- Make sure to remove the protection cardboard for transportation that is inserted in the gap between the top cabinet and the heat exchanger before installing the indoor unit.




5 Drain piping

⚠ CAUTION

Following the Installation Manual, perform the drain piping work so that water is properly drained. Apply a heat insulator so as not to cause a dew condensation. Inappropriate piping work may result in water leakage in the room and wet furniture.

- Provide the indoor drain piping with proper heat insulation.
- Provide the area where the pipe connects to the indoor unit with proper heat insulation. Improper heat insulation will cause condensation to form.
- The drain pipe must be sloping downward (at an angle of 1/100 or more), and do not run the pipe up and down (arched shape) or allow it to form traps. Doing so may cause abnormal sounds.
- Restrict the length of the traversing drain pipe to 20 meters or less. For a long pipe, provide support brackets at intervals of 1.5 to 2 meters to prevent flapping.
- Install the collective piping as shown in the following figure.
- Do not provide any air vents. Otherwise, the drain water will spout, causing water to leak.
- Do not allow any force to be applied to the connection area with the drain pipe.



■ Pipe material, size and insulator

The following materials for piping work and insulating process are locally procured.


Pipe material	Hard vinyl chloride pipe VP25 (Nominal outer diameter 32 mm)
Insulator	Foamed polyethylene foam, thickness: 10 mm or more

■ Connecting drain pipe

Insert flexible drain hose into the drain pipe of main unit as far as it will go. Fix it with hose band.

REQUIREMENT

Mount the flexible drain hose using the hose band without using adhesive.



■ Drain up


When install the drain pump kit (TCB-DP40DPE) of optional accessory, read the Installation Manual supplied to a drain pump kit.

■ Check the draining

Check if the water can flow out properly during the test run. Also, check if no water leakage from the piping connection port.


REQUIREMENT

- Conduct the drain test even in the heating season.
- If it is before the duct work, pour water into the drain pan through the air outlet.
- If it is after the duct work, remove the access panel and pour water, then conduct the drain check.




■ Heat insulating process

- As shown in the figure, cover the flexible hose and hose band with the attached heat insulator up to the bottom of the indoor unit tightly.
- Cover the drain pipe tightly with a heat insulator procured locally so that it overlaps with the attached heat insulator of the drain connecting section.



■ Connecting method of the duct




⚠ CAUTION

Incomplete heat insulation of the supply air flange and sealing may occur dewing resulted in falling of water drop.






Fan characteristics

072H type



096H type



6 Duct design


■ Duct design

- 1** In order to prevent short circuits, design the duct work so that the intake and discharge openings are not adjacent to each other.
- 2** The indoor unit does not have a built-in air filter.
Always install the air filter (Local procure) in a location that permits easy maintenance, such as behind the intake grille. (If no air filter is installed, dust will collect in the heat exchanger, which may cause the air conditioner to fail or to leak.)

<Overview of duct connection>

NOTE

Parts except air conditioner unit are to be locally procured.




■ Arrangement

Referring to the following dimensions, manufacture duct at the local site.


(Unit: mm)

(Thickness of plate : 0.8 mm)

<Air outlet>



<Air inlet>



7 Refrigerant piping

Refrigerant piping

- Use general copper pipes with a wall thickness of 0.8 mm for Ø12.7 mm, and with a wall thickness of 1.0 mm for Ø22.2 mm (half hard). Do not use any copper pipes with a wall thickness less than these thicknesses.
- Flare nut and flare works are also different from those of the conventional refrigerant. Take out the flare nut attached to the main unit of the air conditioner, and use it.

REQUIREMENT

When the refrigerant pipe is long, provide support brackets at intervals of 2.5 to 3 m to clamp the refrigerant pipe. Otherwise, abnormal sound may be generated.

CAUTION

Important 4 points for piping work

- Remove dust and moisture from the inside of the connecting pipes.
- Tight connection (between pipes and unit)
- Evacuate the air in the connecting pipes using VACUUM PUMP.
- Check the gas leakage. (Connected points)

Pipe size

(Unit: mm)

Outside diameter size	Gas side	22.2 mm
	Liquid side	12.7 mm

Liquid side refrigerant pipe connection


Permissible piping length and height difference

They vary according to the outdoor unit. For details, refer to the Installation Manual attached to the outdoor unit.

Flaring

- Cut the pipe with a pipe cutter. Remove burrs completely. Remaining burrs may cause gas leakage.
- Insert a flare nut into the pipe, and flare the pipe. As the flaring sizes of R410A differ from those of refrigerant R22, the flare tools newly manufactured for R410A are recommended.

However, the conventional tools can be used by adjusting projection margin of the copper pipe.




Projection margin in flaring: B (Unit: mm) RIDGID (Clutch type)

Outer dia. of copper pipe	R410A tool used	Conventional tool used
	R410A	R410A
12.7	0 to 0.5	1.5 to 2.0

Flaring dia meter size: A (Unit: mm)

Outer dia. of copper pipe	A ⁺⁰ / _{-0.02} (-0.4)
	R410A
12.7	16.6

- * In case of flaring for R410A with the conventional flare tool, pull it out approx. 0.5 mm more than that for R22 to adjust to the specified flare size. The copper pipe gauge is useful for adjusting projection margin size.



Tightening connection

CAUTION


Do not apply excessive torque. Otherwise, the nut may crack depending on the conditions.

(Unit: N·m)

Outer dia. of copper pipe	Tightening torque
12.7 mm (dia.)	50 to 62 (5.0 to 6.2 kgf·m)

Tightening torque of flare pipe connections

Pressure of R410A is higher than that of R22. (Approx. 1.6 times) Therefore, using a torque wrench, tighten the flare pipe connecting sections which connect the indoor and outdoor units of the specified tightening torque. Incorrect connections may cause not only a gas leak, but also a trouble of the refrigeration cycle. Align the centres of the connecting pipes and tighten the flare nut as far as possible with your fingers. Then tighten the nut with a spanner and torque wrench as shown in the figure.




Use a wrench to secure. Use a torque wrench to tighten.

REQUIREMENT

Tightening with an excessive torque may crack the nut depending on installation conditions. Tighten the nut within the specified tightening torque.

Gas side refrigerant pipe connection


- Turn up the pipe heat insulator to the unit side.
- Wrap the pipe with wet cloth.



- Remove the cup on the gas side piping by using a brazing machine.

CAUTION


- Do not burn the pipe heat insulator.
- Be careful for the flame, due to the brazing process on the ceiling.



- Braze the connection piping to the joint part.



- Turn back the pipe heat insulator and tie up with a banding band.



Piping with outdoor unit

For details of installation, refer to the Installation Manual of the outdoor unit.

Evacuation

Using a vacuum pump, perform vacuuming from the charge port of valve of the outdoor unit. For details, follow to the Installation Manual attached to the outdoor unit. Never use the refrigerant sealed in the outdoor unit for evacuation.

REQUIREMENT

For the tools such as charge hose, etc., use those manufactured exclusively for R410A.

Refrigerant amount to be added

For addition of the refrigerant, add refrigerant "R410A" referring to the attached Installation Manual of outdoor unit.

Use a scale to charge the refrigerant of specified amount.

REQUIREMENT

- Charging an excessive or too little amount of refrigerant causes a trouble of the compressor. Charge the refrigerant of specified amount.
- A personnel who charged the refrigerant should write down the pipe length and the added refrigerant amount in the F-GAS label of the outdoor unit. It is necessary to fix the compressor and refrigeration cycle malfunction.

Open the valve fully

Open the valve of the outdoor unit fully.

A 4 mm-hexagonal wrench is required for opening the valve of liquid side.

For details, refer to the Installation Manual attached to the outdoor unit.

Gas leak check

Check with a leak detector or soap water whether gas leaks or not, from the pipe connecting section or cap of the valve.

REQUIREMENT

Use a leak detector manufactured exclusively for HFC refrigerant (R410A, R134a).


Heat insulation process

Apply heat insulation for the pipes separately at liquid side and gas side.

- For the heat insulation to the pipes at gas side, be sure to use the material with heat-resisting temperature 120 °C or higher.
- To use the attached heat insulation pipe, apply the heat insulation to the pipe connecting section of the indoor unit securely without gap.

REQUIREMENT

- Apply the heat insulation to the pipe connecting section of the indoor unit securely up to the root without exposure of the pipe. (The pipe exposed to the outside causes water leak.)
- Wrap heat insulator with its slits facing up (ceiling side).



8 Electrical connection

⚠ WARNING

- **Use the specified wires for wiring connect the terminals. Securely fix them to prevent external forces applied to the terminals from affecting the terminals.**
Incomplete connection or fixation may cause a fire or other trouble.
- **Connect earth wire. (grounding work)**
Incomplete grounding cause an electric shock. Do not connect earth wires to gas pipes, water pipes, lightning conductor or telephone earth wires.
- **Appliance shall be installed in accordance with national wiring regulations.**
Capacity shortage of power circuit or incomplete installation may cause an electric shock or a fire.

⚠ CAUTION

- **For communication line, use wires with the same type and size. If each wire has a different type and size from another one, it will cause a communication trouble.**
- If incorrect/incomplete wiring is carried out, it will cause an electrical fire or smoke.
- Install an earth leakage breaker that is not tripped by shock waves. If an earth leakage breaker is not installed, an electric shock may be caused.
- Use the cord clamps attached to the product.
- Do not damage or scratch the conductive core and inner insulator of power and system interconnection wires when peeling them.
- Use the power supply wire and control wires of specified thickness, type, and protective devices required.
- Do not connect 220V power to the terminal blocks (Uv (U1)), (Uv (U2)), (A), (B) for control wiring. (Otherwise, the system will fail.)
- Perform the electric wiring so that it does not come to contact with the high-temperature part of the pipe. The coating may melt resulting in an accident.

REQUIREMENT

- For power supply wiring, strictly conform to the Local Regulation in each country.
- For wiring of power supply of the outdoor units, follow the Installation Manual of each outdoor unit.
- After connecting wires to the terminal blocks, provide a trap and fix wires with the cord clamp.
- Run the refrigerant piping line and control wiring line in the same line.
- Do not turn on the power of the indoor unit until the refrigerant pipes are vacuumed.

■ Power supply wire and communication wires specifications

Power supply wire and communication wires are procured locally.

For the power supply specifications, follow to the following table. If capacity is little, it is dangerous because overheat or burnout may be caused. For specifications of the power capacity of the outdoor unit and the power supply wires, refer to the Installation Manual attached to the outdoor unit.

Indoor unit power supply

- For the power supply of the indoor unit, prepare the exclusive power supply separated from that of the outdoor unit.
- Arrange the power supply, circuit breaker, and main switch of the indoor unit connected to the same outdoor unit so that they are commonly used.
- Power supply wire specification: Cable 3-core 2.5 mm², in conformity with Design 60245 IEC 57.

▼ Power supply

Power supply	220V ~, 50 Hz	
Power supply switch/circuit breaker or power supply wiring/fuse rating for indoor units should be selected by the accumulated total current values of the indoor units.		
Power supply wiring	Below 20 m	2.5 mm ²
	Below 50 m	4.0 mm ²

Control wiring, Central controller wiring

- 2-core with polarity wires are used for the Control wiring between indoor unit and outdoor unit and Central controller wiring.
- To prevent noise trouble, use 2-core shield wire.
- The length of the communication line means the total length of the inter-unit wire length between indoor and outdoor units added with the central control system wire length.

▼ Communication line

Uv line and Uc line (L2, L3, L4) (2-core shield wire, non-polarity)	Wire size :	0.5 mm ² 0.75 to 1.25 mm ²	(Up to 500 m) (Up to 1000 m)
Uh line (L1) (2-core shield wire, non-polarity)	Wire size :	0.75 to 1.25 mm ² 2.0 mm ²	(Up to 1000 m) (Up to 2000 m)

- **U (v, h, c)** line means of control wiring.
 - Uv line** : Between indoor and outdoor units.
 - Uh line** : Central control line.
 - Uc line** : Between outdoor and outdoor units.
- **Uv line and Uc line** are independent from another refrigerant line. Total length of **Uv** and **Uc** lines (**L3+L4**) in each refrigerant line is up to 1000 m.


[Uh line]

L1 = Up to 2000 m

[Uv and Uc line]

L2 = Up to 1000 m

(L3+L4) = Up to 1000 m




Remote controller wiring

- 2-core with non-polarity wire is used for wiring of the remote controller wiring and group remote controllers wiring.

Remote controller wiring, remote controller inter-unit wiring	Wire size: 0.5 mm ² to 2.0 mm ²	
Total wire length of remote controller wiring and remote controller inter-unit wiring = L + L1 + L2 + ... Ln	In case of wired type only	Up to 500 m
	In case of wireless type included	Up to 400 m
Total wire length of remote controller inter-unit wiring = L1 + L2 + ... Ln	Up to 200 m	

CAUTION

- The remote controller wire (Communication line) and AC 220V wires cannot be parallel to contact each other and cannot be stored in the same conduits. If doing so, it may cause troubles on the control system due to noise or other factor.




Wiring between indoor unit and outdoor unit

NOTE

- An outdoor unit that is interconnected to the indoor units automatically becomes the header unit.

Wiring example




■ Wire connection

REQUIREMENT

- Connect the wires matching the terminal numbers. Incorrect connection causes a trouble.
- Pass the wires through the bushing of wire connection holes of the indoor unit.
- Keep a margin (Approx. 100 mm) on a wire to hang down the electrical control box at servicing or other purpose.
- The low-voltage circuit is provided for the remote controller. (Do not connect the high-voltage circuit)


- Before performing wiring work in the electrical control box, remove the cover of the box (fixed with 6 screws).
- Remove screw A, and loosen screw B.
- Pull up the electrical control box cover and then open it forward.
- Tighten the screws of the terminal block firmly, and fix the wires with the cord clamps attached to the electrical control box. (Do not apply tension to the connecting section of the terminal block.)
- Mount the cover of the electrical control box without pinching wires (fixed with 6 screws).
- Using the attached seal material, seal the wire connecting port.



■ Remote controller wiring

Strip off approx. 9 mm the wire to be connected.

Wiring diagram





Side D (Space: 8.5 mm) Side C (Space: 4 mm)

Select side C or D for the power cable clamping position referring to the following table according to the cable type and diameter.
* Cable clamp can be attached on either right or left side.
When twin system are connected, clamp two cables with one cable clamp.

Wire type	Specification	Cable clamping position
Cabtyre cable	3-core stranded wire 2.5 mm ²	Side D
Cabtyre cable	4-core stranded wire 1.5 mm ²	Side C

※ 3 and 4 terminals is Flow Selector Unit wiring.



9 Applicable controls

REQUIREMENT

When the air conditioner is used for the first time, it will take some moments after the power has been turned on before the remote controller becomes available for operations: This is normal and is not indicative of trouble.

- Concerning the automatic addresses (The automatic addresses are set up by performing operations on the outdoor interface circuit board.)

While the automatic addresses are being set up, no remote controller operations can be performed. Setup takes up to 10 minutes (usually about 5 minutes).

- When the power is turned on after automatic address setup

It takes up to 10 minutes (usually about 3 minutes) for the outdoor unit to start operating after the power has been turned on.

Before the air conditioner was shipped from the factory, all units are set to [STANDARD] (factory default). If necessary, change the indoor unit settings.

The settings are changed by operating the wired remote controller.

* The settings cannot be changed using only a wireless remote controller, simple remote controller or group control remote controller by itself so install a wired remote controller separately as well.

■ Applicable controls setup (settings at the site)


Basic procedure

Be sure to stop the air conditioner before making settings.

(Change the setup while the air conditioner is not working.)


⚠ CAUTION

Set only the Code No. shown in the following table: DO NOT set any other Code No. If a Code No. not listed is set, it may not be possible to operate the air conditioner or other trouble with the product may result.



1 Push and hold menu button and [▽] setting button simultaneously for 10 seconds or more.


- After a while, the display flashes as shown in the figure. "ALL" is displayed as indoor unit numbers during initial communication immediately after the power has been turned on.



2 Each time [▽][△] setting button is pushed, indoor unit numbers in the group control change cyclically. Select the indoor unit to change settings for.

- The fan of the selected indoor unit runs. The indoor unit can be confirmed for which to change settings.

3 Push OFF timer button to confirm the selected indoor unit.



4 Push the menu button to make Code No. [] flash. Change Code No. [**] with [▽][△] setting button.**

5 Push the menu button to make Set data [**] flash. Change Set data [****] with [▽][△] setting button.**

6 Push OFF timer button. By doing so, the setup is completed.

- To change other settings of the selected indoor unit, repeat from Procedure 4.

7 When all the settings have been completed, push ON/OFF button to determine the settings.

"SETTING" flashes and then the display content disappears and the air conditioner enters the normal stop mode. (The remote controller is unavailable while "SETTING" is flashing.)

- To change settings of another indoor unit, repeat from Procedure 1.

■ External static pressure settings

To set the external static pressure, refer to the "Fan characteristics" in 6 Duct design. Set up a tap change based upon the external static pressure of the duct to be connected.

To set up a tap change, follow to the basic operation procedure (1 → 2 → 3 → 4 → 5 → 6).


- Specify [5d] to the CODE No. in procedure 4.
- For the SET DATA of procedure 5, select a SET DATA of the external static pressure to be set up from the following table.

SET DATA	External static pressure	
0000	150 Pa	Factory default
0001	50 Pa	—
0002	83 Pa	—
0003	217 Pa	—
0004	117 Pa	—
0005	183 Pa	—
0006	250 Pa	—

The list above is when SW501-1 and SW501-2 is OFF. If the setting is wrong, "P12" may appear indicating a fan motor error.

<Setting up on the circuit board of the indoor unit>

To set up the external static pressure, use the DIP switch on the circuit board of the wireless reception part. For details, refer to the instruction manual of the wireless remote controller kit. Alternatively, use the switch on the indoor micro computer circuit board as shown in the following figure and table.



SW501-1	OFF	ON	OFF	ON
SW501-2	OFF	OFF	ON	ON
SET DATA	Factory default	0001	0003	0006

To reset to the factory default

Switch off SW501-1 and SW501-2, connect a separately-sold wired remote controller, and then perform the procedure for external static pressure settings on this page to set the [5d] data to "0000".

■ Filter sign setting

According to the installation condition, the filter sign term (Notification of filter cleaning) can be changed. Follow to the basic operation procedure (1 → 2 → 3 → 4 → 5 → 6 → 7).

- Specify [01] for the Code No. in Procedure 4.
- For the set data in Procedure 5, select the set data of filter sign term from the following table.

SET DATA	Filter sign term
0000	None
0001	150 H
0002	2500 H (Factory default)
0003	5000 H
0004	10000 H

- The filter sign may be unavailable depending on the remote controllers.

■ Remote controller sensor

The temperature sensor of the indoor unit senses room temperature usually. Set the remote controller sensor to sense the temperature around the remote controller.

Select items following the basic operation procedure (1 → 2 → 3 → 4 → 5 → 6).

- Specify [32] for the CODE No. in Procedure 4.
- Select the following data for the SET DATA in Procedure 5.

SET DATA	0000	0001
Remote controller sensor	Not used (Factory default)	Used

When flashes, the remote controller sensor is defective.

Select the SET DATA [0000] (not used) or replace the remote controller.

■ Group control

In a group control, a remote controller can control up to maximum 16 units.

- The wired remote controller only can control a group control. The wireless remote controller is unavailable for this control.
- For wiring procedure and wires of the individual line (Identical refrigerant line) system, refer to "Electrical Connection" in this Manual.
- Wiring between indoor units in a group is performed in the following procedure.
- Connect the indoor units by connecting the remote controller wires from the remote controller terminal blocks (A, B) of the indoor unit connected with a remote controller to the remote controller terminal blocks (A, B) of the other indoor unit. (Non-polarity)
- For address setup, refer to the Installation Manual attached to the outdoor unit.

10 Test run

■ Before test run

- Before turning on the power supply, carry out the following procedure.
 - 1) By using insulation tester (500VMΩ) check that resistance of 1MΩ or more exists between the terminal block L to N and the earth (grounding). If resistance of less than 1MΩ is detected, do not run the unit.
 - 2) Check the valve of the outdoor unit being opened fully.
- To protect the compressor at activation time, leave power-ON for 12 hours or more before operating.
- Before starting a test run, set addresses by following the Installation Manual supplied with the outdoor unit.

◆ Requirements for turning thermostat OFF

Cooling operation

- When the outdoor/suction air temperature is lower than or equal to 19 °C.
- When the outdoor/suction air temperature is lower than or equal to 3 °C above the set temperature.

■ Execute a test run

- When a fan operation is to be performed for an individual indoor unit, turn off the power, short circuit CN72 on the circuit board, and then turn the power back on. (Set the operation mode to “fan” to operate the unit.) When the test run has been performed using this method, be sure to release the short circuit of CN72 after the test run is completed.

Operate the unit with the remote controller as usual. For the procedure of the operation, refer to the attached Owner’s Manual to the outdoor unit. A forced test run can be executed in the following procedure even if the operation stops by thermostat-OFF.

In order to prevent a serial operation, the forced test run is released after 60 minutes have passed and returns to the usual operation.


⚠ CAUTION

Do not use the forced test run for cases other than the test run because it applies an excessive load to the devices.


Wired remote controller

Be sure to stop the air conditioner before making settings.


(Change the setup while the air conditioner is not working.)



- 1 Push and hold OFF timer button and [Δ] setting button simultaneously for 10 seconds or more. [TEST] is displayed on the display part and the test run is permitted.



- 2 Push ON/OFF button.
- 3 Push menu button to select the operation mode. Select [Cool] with [▽] [Δ] setting button, and then push menu button (three times) again to determine the operation mode.
 - Do not run the air conditioner in a mode other than [Cool].
 - The temperature setting function does not work during test run.
 - The check code is displayed as usual.
- 4 After the test run, push OFF timer button to stop a test run. ([TEST] disappears on the display and the air conditioner enters the normal stop mode.)



11 Maintenance


⚠ CAUTION

When connecting a return air duct to the unit, the cleaning method of the air filter differs according to the construction of duct end. Ask a qualified installer or qualified service person.

<Daily maintenance> (Once every 3 months)

▼ Cleaning of the air filter (sold separately : TCB-LK2801DP-E)

1 Push the button to stop the operation, then turn off the circuit breaker.



1. Take out the air filter (sold separately).
2. Cleaning with water or vacuum cleaner.
 - If dirt is heavy, clean the air filter by tepid water with neutral detergent or water.
 - After cleaning with water, dry the air filter sufficiently in a shade place.
3. Mount the air filter (sold separately).

2 Turn on the circuit breaker, then push the button on the remote controller to start the operation.

⚠ CAUTION

- Do not start the air conditioner while leaving air filter (sold separately) removed.

▼ Periodic Maintenance

For environmental conservation, it is strongly recommended that the indoor and outdoor units of the air conditioner in use be cleaned and maintained regularly to ensure efficient operation of the air conditioner.

When the air conditioner is operated for a long time, periodic maintenance (once a year) is recommended. Furthermore, regularly check the outdoor unit for rust and scratches, and remove them or apply rustproof treatment, if necessary.

As a general rule, when an indoor unit is operated for 8 hours or more daily, clean the indoor unit and outdoor unit at least once every 3 months. Ask a professional for this cleaning / maintenance work.

Such maintenance can extend the life of the product though it involves the owner's expense.


Failure to clean the indoor and outdoor units regularly will result in poor performance, freezing, water leakage, and even compressor failure.

▼ Inspection before maintenance (Once a year)

Following inspection must be carried out by a qualified installer or qualified service person.

Parts	Inspection method
Fan motor	Access from the access panel and check if any abnormal noise can be heard.
Fan	Access from the access panel and remove the access panel. Examine the fan if there are any waggles, damages or adhesive dust.
Filter (sold separately)	Access from check port and check if there are any stains or breaks on the filter.
Drain pan	Access from the access panel and remove the access panel. Check if there is any clogging or drain water is polluted.

- The unit can be accessed from the access panel shown in the figure.




▼ Maintenance List

Part	Unit	Check (visual / auditory)	Maintenance
Heat exchanger	Indoor / outdoor	Dust / dirt clogging, scratches	Wash the heat exchanger when it is clogged.
Fan motor	Indoor / outdoor	Sound	Take appropriate measures when abnormal sound is generated.
Filter (sold separately)	Indoor	Dust / dirt, breakage	<ul style="list-style-type: none"> • Wash the filter with water when it is contaminated. • Replace it when it is damaged.
Fan	Indoor	<ul style="list-style-type: none"> • Vibration, balance • Dust / dirt, appearance 	<ul style="list-style-type: none"> • Replace the fan when vibration or balance is terrible. • Brush or wash the fan when it is contaminated.
Air intake / discharge grilles	Indoor / outdoor	Dust / dirt, scratches	Fix or replace them when they are deformed or damaged.
Drain pan	Indoor	Dust / dirt clogging, drain contamination	Clean the drain pan and check the downward slope for smooth drainage.
Ornamental panel, louvers	Indoor	Dust / dirt, scratches	Wash them when they are contaminated or apply repair coating.
Exterior	Outdoor	<ul style="list-style-type: none"> • Rust, peeling of insulator • Peeling / lift of coat 	Apply repair coating.

12 Troubleshooting

Confirmation and check

If a problem occurs with the air conditioner, the OFF timer indicator alternately shows the check code and the indoor Unit No. in which the problem occurred.



Troubleshooting history and confirmation

You can check the troubleshooting history with the following procedure if a problem occurs with the air conditioner. (The troubleshooting history records up to 4 incidents.)

You can check it during operation or when operation is stopped.

- If you check the troubleshooting history during OFF timer operation, the OFF timer will be canceled.

Procedure	Description of operation
1	<p>Push the OFF timer button for over 10 seconds and the indicators appear as an image indicating the troubleshooting history mode has been entered. If [Service check] is displayed, the mode enters in the troubleshooting history mode.</p> <ul style="list-style-type: none"> • [01: Order of troubleshooting history] appears in the temperature indicator. • The OFF timer indicator alternately shows the [check code] and the [indoor Unit No.] in which the problem occurred.
2	<p>Each time the setting button is pushed, the recorded troubleshooting history is displayed in sequence. The troubleshooting history appears in order from [01] (newest) to [04] (oldest).</p> <p>CAUTION</p> <p>In the troubleshooting history mode, DO NOT push the Menu button for over 10 seconds, doing so deletes the entire troubleshooting history of the indoor unit.</p>
3	<p>After you have finished checking, push the ON/OFF button to return to the regular mode.</p> <ul style="list-style-type: none"> • If the air conditioner is operating, it remains operated even after the ON/OFF button has been pushed. To stop its operation, push the ON/OFF button again.



Check method

On the wired remote controller, central control remote controller and the interface P.C. Board of the outdoor unit (I/F), a check display LCD (Remote controller) or 7-segment display (on the outdoor interface P.C. Board) to display the operation is provided. Therefore the operation status can be known. Using this self-diagnosis function, a trouble or position with error of the air conditioner can be found as shown in the table below.

Check code list

The following list shows each check code. Find the check contents from the list according to part to be checked.

- In case of check from indoor remote controller: See "Wired remote controller display" in the list.
- In case of check from outdoor unit: See "Outdoor unit 7-segment display" in the list.
- In case of check from indoor unit with a wireless remote controller: See "Sensor block display of receiving unit" in the list.

○ : Lighting, ◻ : Flashing, ● : Goes off
 ALT: Flashing is alternately when there are two flashing LED.
 SIM: Simultaneous flashing when there are two flashing LED.
 Inverter: Compressor / Fan Inverter P.C. Board

Wired remote controller display	Check code		Wireless remote controller				Check code name	Judging device
		Outdoor unit 7-segment display	Sensor block display of receiving unit					
		Auxiliary code	Operation	Timer	Ready	Flash		
E01	—	—	◻	●	●		Communication trouble between indoor unit and remote controller (Detected at remote controller side)	Remote controller
E02	—	—	◻	●	●		Remote controller transmission trouble	Remote controller
E03	—	—	◻	●	●		Communication trouble between indoor unit and remote controller (Detected at indoor unit side)	Indoor unit
E04	—	—	●	●	◻		Communication circuit trouble between indoor / outdoor unit (Detected at indoor unit side)	Indoor unit
E06	E06	No. of indoor units in which sensor has been normally received	●	●	◻		Decrease of No. of indoor units	I/F
—	E07	—	●	●	◻		Communication circuit trouble between indoor / outdoor unit (Detected at outdoor unit side)	I/F
E08	E08	Duplicated indoor unit addresses	◻	●	●		Duplicated indoor unit addresses	Indoor unit • I/F
E09	—	—	◻	●	●		Duplicated master remote controllers	Remote controller
E10	—	—	◻	●	●		Communication trouble between indoor unit MCU	Indoor unit
E11	—	—	◻	●	●		Communication trouble between Application control kit and indoor unit	Indoor unit Application control kit
E12	E12	01: Indoor / Outdoor units communication 02: Outdoor / Outdoor units communication	◻	●	●		Automatic address start trouble	I/F
E15	E15	—	●	●	◻		No indoor unit during automatic addressing	I/F
E16	E16	00: Capacity over 01: No. of connected units	●	●	◻		Capacity over / No. of connected indoor units	I/F
E18	—	—	◻	●	●		Communication trouble between header and follower units Indoor unit	Indoor unit
E19	E19	00: Header is not detected 02: Two or more header units	●	●	◻		Outdoor header units quantity trouble	I/F
E20	E20	01: Outdoor unit of other line connected 02: Indoor unit of other line connected	●	●	◻		Other line connected during automatic address	I/F
E23	E23	—	●	●	◻		Sending trouble in communication between outdoor units Trouble in number of heat storage units (trouble with reception)	I/F
E25	E25	—	●	●	◻		Duplicated follower outdoor addresses	I/F
E26	E26	No. of outdoor units which received signal normally	●	●	◻		Decrease of No. of connected outdoor units	I/F
E28	E28	Detected outdoor unit number	●	●	◻		Follower outdoor unit trouble	I/F
E31	E31	*1 Inverter quantity information	●	●	◻		Inverter communication trouble	I/F
F01	—	—	◻	◻	●	ALT	Indoor unit TCJ sensor trouble	Indoor unit
F02	—	—	◻	◻	●	ALT	Indoor unit TC2 sensor trouble	Indoor unit
F03	—	—	◻	◻	●	ALT	Indoor unit TC1 sensor trouble	Indoor unit
F04	F04	—	◻	◻	○	ALT	TD1 sensor trouble	I/F
F05	F05	—	◻	◻	○	ALT	TD2 sensor trouble	I/F



Check code		Wireless remote controller				Check code name	Judging device	
Wired remote controller display	Outdoor unit 7-segment display		Sensor block display of receiving unit					
		Auxiliary code	Operation	Timer	Ready			Flash
F06	F06	01: TE1 sensor 02: TE2 sensor 03: TE3 sensor	☐	☐	○	ALT	TE1,TE2 or TE3 sensor trouble	I/F
F07	F07	01: TL1 sensor 02: TL2 sensor 03: TL3 sensor	☐	☐	○	ALT	TL1,TL2 or TL3 sensor trouble	I/F
F08	F08	—	☐	☐	○	ALT	TO sensor trouble	I/F
F09	F09	01: TG1 sensor 02: TG2 sensor 03: TG3 sensor	☐	☐	○	ALT	TG1,TG2 or TG3 sensor trouble	I/F
F10	—	—	☐	☐	●	ALT	Indoor unit TA sensor trouble	Indoor unit
F11	—	—	☐	☐	●	ALT	TF sensor trouble	Indoor unit
F12	F12	01: TS1 sensor 03: TS3 sensor	☐	☐	○	ALT	TS1 or TS3 sensor trouble	I/F
F13	F13	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	☐	☐	○	ALT	TH sensor trouble	Inverter
F15	F15	—	☐	☐	○	ALT	Outdoor unit temp. sensor miswiring (TE, TL)	I/F
F16	F16	—	☐	☐	○	ALT	Outdoor unit pressure sensor miswiring (Pd, Ps)	I/F
F22	F22	—	☐	☐	○	ALT	TD3 sensor trouble	I/F
F23	F23	—	☐	☐	○	ALT	Ps sensor trouble	I/F
F24	F24	—	☐	☐	○	ALT	Pd sensor trouble	I/F
F29	—	—	☐	☐	●	SIM	Indoor unit other trouble	Indoor unit
F30	F30	—	☐	☐	○	SIM	Occupancy sensor trouble	Indoor unit
F31	F31	—	☐	☐	○	SIM	Indoor unit EEPROM trouble	I/F
H01	H01	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	●	☐	●		Compressor break down	Inverter
H02	H02	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	●	☐	●		Compressor trouble (lock)	Inverter
H03	H03	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	●	☐	●		Current detect circuit system trouble	Inverter
H04	H04	—	●	☐	●		Comp. 1 case thermostat operation	I/F
H05	H05	—	●	☐	●		TD1 sensor miswiring	I/F
H06	H06	—	●	☐	●		Low pressure protective operation	I/F
H07	H07	—	●	☐	●		Oil level down detective protection	I/F
H08	H08	01: TK1 sensor trouble 02: TK2 sensor trouble 03: TK3 sensor trouble 04: TK4 sensor trouble 05: TK5 sensor trouble	●	☐	●		Oil level detective temp. sensor trouble	I/F
H14	H14	—	●	☐	●		Comp. 2 case thermostat operation	I/F
H15	H15	—	●	☐	●		TD2 sensor miswiring	I/F
H16	H16	01: TK1 oil circuit system trouble 02: TK2 oil circuit system trouble 03: TK3 oil circuit system trouble 04: TK4 oil circuit system trouble 05: TK5 oil circuit system trouble	●	☐	●		Oil level detective circuit trouble	I/F
H25	H25	—	●	☐	●		TD3 sensor miswiring	I/F



Check code		Wireless remote controller				Check code name	Judging device	
Wired remote controller display	Outdoor unit 7-segment display		Sensor block display of receiving unit					
		Auxiliary code	Operation	Timer	Ready			Flash
L02	L02	—	☐	●	☐	SIM	Model mismatch of indoor and outdoor unit	I/F
L03	—	—	☐	●	☐	SIM	Indoor unit centre unit duplicated	Indoor unit
L04	L04	—	☐	○	☐	SIM	Outdoor unit line address duplicated	I/F
L05	—	—	☐	●	☐	SIM	Duplicated indoor units with priority (Displayed in indoor unit with priority)	I/F
L06	L06	No. of indoor units with priority	☐	●	☐	SIM	Duplicated indoor units with priority (Displayed in unit other than indoor unit with priority)	I/F
L07	—	—	☐	●	☐	SIM	Group line in individual indoor unit	Indoor unit
L08	L08	—	☐	●	☐	SIM	Indoor unit group / Address unset	Indoor unit, I/F
L09	—	—	☐	●	☐	SIM	Indoor unit capacity unset	Indoor unit
L10	L10	—	☐	○	☐	SIM	Outdoor unit capacity unset	I/F
L17	L17	—	☐	○	☐	SIM	Outdoor unit type mismatch trouble	I/F
L18	L18	—	☐	○	☐	SIM	Flow selector unit trouble	I/F
L20	—	—	☐	○	☐	SIM	Duplicated central control addresses	Indoor unit
L28	L28	—	☐	○	☐	SIM	Too many outdoor units connected	I/F
L29	L29	*1 Inverter quantity information	☐	○	☐	SIM	No. of inverter trouble	I/F
L30	L30	Detected indoor unit address	☐	○	☐	SIM	Indoor unit outside interlock	Indoor unit
—	L31	—	—	—	—	—	Extended I/C trouble	I/F
P01	—	—	●	☐	☐	ALT	Indoor fan motor trouble	Indoor unit
P03	P03	—	☐	●	☐	ALT	Discharge temp. TD1 trouble	I/F
P04	P04	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	☐	●	☐	ALT	High-pressure SW system operation	Inverter
P05	P05	00: 01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	☐	●	☐	ALT	Phase missing detection / Power failure detection Inverter DC voltage trouble (comp.) Inverter DC voltage trouble (comp.) Inverter DC voltage trouble (comp.)	I/F
P07	P07	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side ----- 04: Heat sink	☐	●	☐	ALT	Heat sink overheat trouble ----- Heat sink dew condensation trouble	Inverter, I/F
P10	P10	Detected indoor unit address	●	☐	☐	ALT	Indoor unit overflow trouble	Indoor unit
P11	P11	—	●	☐	☐	ALT	Outdoor heat exchanger freezing trouble	I/F
P12	—	—	●	☐	☐	ALT	Indoor unit fan motor trouble	Indoor unit
P13	P13	—	●	☐	☐	ALT	Outdoor liquid back detection trouble	I/F
P15	P15	01: TS condition 02: TD condition	☐	●	☐	ALT	Gas leak detection	I/F
P17	P17	—	☐	●	☐	ALT	Discharge temp. TD2 trouble	I/F
P19	P19	Detected outdoor unit number	☐	●	☐	ALT	4-way valve inverse trouble	I/F
P20	P20	—	—	●	—	ALT	High-pressure protective operation	I/F
P22	P22	#0: Element short circuit #E: Vdc voltage trouble #1: Position detection circuit trouble #2: Input current sensor trouble #3: Motor lock trouble #C: Sensor temperature trouble (No TH sensor) #4: Motor current trouble #D: Sensor short circuit/release trouble (No TH sensor) #5: Synchronization/step-out trouble *Put in Fan Inverter No. in [#] mark.	☐	●	☐	ALT	Outdoor unit fan inverter trouble	Inverter



Check code			Wireless remote controller				Check code name	Judging device
Wired remote controller display	Outdoor unit 7-segment display		Sensor block display of receiving unit					
		Auxiliary code	Operation	Timer	Ready	Flash		
P26	P26	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	☐	●	☐	ALT	IPM short protection trouble	Inverter
P29	P29	01: Comp. 1 side 02: Comp. 2 side 03: Comp. 3 side	☐	●	☐	ALT	Comp. position detective circuit system trouble	Inverter
P31	—	—	☐	●	☐	ALT	Other indoor unit trouble (Group follower indoor unit trouble)	Indoor unit

***1 Inverter quantity information**

• For details about check codes determined with an Interface P.C. Board or an Inverter P.C. Board, refer to the Installation Manual of the outdoor unit.

No.	Comp. Inverter		Fan Inverter		Trouble
	1	2	1	2	
01	○				Comp. 1
02		○			Comp. 2
03	○	○			Comp. 1 + Comp. 2
08			○		Fan1
09	○		○		Comp. 1 + Fan1
0A		○	○		Comp. 2 + Fan1
0B	○	○	○		Comp. 1 + Comp. 2 + Fan1
10				○	Fan2
11	○			○	Comp. 1 + Fan2
12		○		○	Comp. 2 + Fan2
13	○	○		○	Comp. 1 + Comp. 2 + Fan2
18			○	○	Fan1 + Fan2
19	○		○	○	Comp. 1 + Fan1 + Fan2
1A		○	○	○	Comp. 2 + Fan1 + Fan2
1B	○	○	○	○	All
○ : Inverter trouble					

Trouble detected by central control device

Check code			Wireless remote controller				Check code name	Judging device
Central control device indication	Outdoor unit 7-segment display		Sensor block display of receiving unit					
		Auxiliary code	Operation	Timer	Ready	Flash		
C05	—	—			—		Sending trouble in central control device	Communication Link
C06	—	—			—		Receiving trouble in central control device	Communication Link
C12	—	—			—		Batch alarm of general-purpose equipment control interface	General-purpose equipment I/F
P30 (L20)	Differs according to trouble contents of unit with occurrence of alarm						Group control follower unit trouble	Communication Link
	—	—	(L20 is displayed.)				<ul style="list-style-type: none"> • Duplication addresses of indoor units in central control device • With the combination of air conditioning system, the indoor unit may detect the check code of L20 	

Warnings on Refrigerant Leakage

Check of concentration limit

The room in which the air conditioner is to be installed requires a design that in the event of refrigerant gas leaking out, its concentration will not exceed a set limit.

The refrigerant R410A which is used in the air conditioner is safe, without the toxicity or combustibility of ammonia, and is not restricted by laws to be imposed which protect the ozone layer. However, since it contains more than air, it poses the risk of suffocation if its concentration should rise excessively. Suffocation from leakage of R410A is almost non-existent. With the recent increase in the number of high concentration buildings, however, the installation of multi air conditioner systems is on the increase because of the need for effective use of floor space, individual control, energy conservation by curtailing heat and carrying power etc.

Most importantly, the multi air conditioner system is able to replenish a large amount of refrigerant compared with conventional individual air conditioners. If a single unit of the multi conditioner system is to be installed in a small room, select a suitable model and installation procedure so that if the refrigerant accidentally leaks out, its concentration does not reach the limit (and in the event of an emergency, measures can be made before injury can occur).


In a room where the concentration may exceed the limit, create an opening with adjacent rooms, or install mechanical ventilation combined with a gas leak detection device. The concentration is as given below.

$$\frac{\text{Total amount of refrigerant (kg)}}{\text{Min. volume of the indoor unit installed room (m}^3\text{)}} \leq \text{Concentration limit (kg/m}^3\text{)}$$

The concentration limit of R410A which is used in multi air conditioners is 0.3 kg/m³.

▼ NOTE 1

If there are 2 or more refrigerating systems in a single refrigerating device, the amounts of refrigerant should be as charged in each independent device.



For the amount of charge in this example:


The possible amount of leaked refrigerant gas in rooms A, B and C is 10 kg.

The possible amount of leaked refrigerant gas in rooms D, E and F is 15 kg.

▼ NOTE 2


The standards for minimum room volume are as follows.

- 1) No partition (shaded portion)




Important

- 2) When there is an effective opening with the adjacent room for ventilation of leaking refrigerant gas (opening without a door, or an opening 0.15% or larger than the respective floor spaces at the top or bottom of the door).




- 3) If an indoor unit is installed in each partitioned room and the refrigerant piping is interconnected, the smallest room of course becomes the object. But when a mechanical ventilation is installed interlocked with a gas leakage detector in the smallest room where the density limit is exceeded, the volume of the next smallest room becomes the object.



▼ NOTE 3

The minimum indoor floor area compared with the amount of refrigerant is roughly as follows: (When the ceiling is 2.7 m high)



■ Confirmation of indoor unit setup

Prior to delivery to the customer, check the address and setup of the indoor unit, which has been installed in this time and fill the check sheet. (Following table). Data of four units can be entered in this check sheet. Copy this sheet according to the No. of the indoor units. If the installed system is a group control system, use this sheet by entering each line system into each Installation Manual attached to the other indoor units.

REQUIREMENT

This check sheet is required for maintenance after installation. Fill this sheet and then pass this Installation Manual to the customers.

Indoor unit setup check sheet

Indoor unit		Indoor unit		Indoor unit		Indoor unit		
Room name	Room name	Room name	Room name	Room name	Room name	Room name	Room name	
Model	Model	Model	Model	Model	Model	Model	Model	
Check indoor unit address. (For check method, refer to APPLICABLE CONTROLS in this manual.) *In case of a single system, it is unnecessary to enter the indoor address. (CODE NO.: Line [12], Indoor [13], Group [14], Central control [03])								
Line	Indoor	Group	Line	Indoor	Group	Line	Indoor	Group
Central control address		Central control address		Central control address		Central control address		
Various setup		Various setup		Various setup		Various setup		
Have you changed high ceiling setup? If not, fill check mark [x] in [NO CHANGE], and fill check mark [x] in [ITEM] if changed, respectively. (For check method, refer to APPLICABLE CONTROLS in this manual.) * In case of replacement of jumper blocks on indoor microcomputer P.C. Board, setup is automatically changed.								
External static pressure (CODE NO. [5d]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> STANDARD <input type="checkbox"/> STATIC 1 <input type="checkbox"/> STATIC 2 <input type="checkbox"/> STATIC 3 <input type="checkbox"/> STATIC 4 <input type="checkbox"/> STATIC 5 <input type="checkbox"/> STATIC 6		External static pressure (CODE NO. [5d]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> STANDARD <input type="checkbox"/> STATIC 1 <input type="checkbox"/> STATIC 2 <input type="checkbox"/> STATIC 3 <input type="checkbox"/> STATIC 4 <input type="checkbox"/> STATIC 5 <input type="checkbox"/> STATIC 6		External static pressure (CODE NO. [5d]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> STANDARD <input type="checkbox"/> STATIC 1 <input type="checkbox"/> STATIC 2 <input type="checkbox"/> STATIC 3 <input type="checkbox"/> STATIC 4 <input type="checkbox"/> STATIC 5 <input type="checkbox"/> STATIC 6		External static pressure (CODE NO. [5d]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> STANDARD <input type="checkbox"/> STATIC 1 <input type="checkbox"/> STATIC 2 <input type="checkbox"/> STATIC 3 <input type="checkbox"/> STATIC 4 <input type="checkbox"/> STATIC 5 <input type="checkbox"/> STATIC 6		
Have you changed lighting time of filter sign? If not, fill check mark [x] in [NO CHANGE], and fill check mark [x] in [ITEM] if changed, respectively. (For check method, refer to APPLICABLE CONTROLS in this manual.)								
Filter sign lighting time (CODE NO. [011]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> NONE <input type="checkbox"/> 150H <input type="checkbox"/> 2500H <input type="checkbox"/> 5000H <input type="checkbox"/> 10000H		Filter sign lighting time (CODE NO. [011]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> NONE <input type="checkbox"/> 150H <input type="checkbox"/> 2500H <input type="checkbox"/> 5000H <input type="checkbox"/> 10000H		Filter sign lighting time (CODE NO. [011]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> NONE <input type="checkbox"/> 150H <input type="checkbox"/> 2500H <input type="checkbox"/> 5000H <input type="checkbox"/> 10000H		Filter sign lighting time (CODE NO. [011]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> NONE <input type="checkbox"/> 150H <input type="checkbox"/> 2500H <input type="checkbox"/> 5000H <input type="checkbox"/> 10000H		
Have you changed detected temp. shift value? If not, fill check mark [x] in [NO CHANGE], and fill check mark [x] in [ITEM] if changed, respectively. (For check method, refer to APPLICABLE CONTROLS in this manual.)								
Detected temp. shift value setup (CODE NO. [06]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> NO SHIFT <input type="checkbox"/> +1°C <input type="checkbox"/> +2°C <input type="checkbox"/> +3°C <input type="checkbox"/> +4°C <input type="checkbox"/> +5°C <input type="checkbox"/> +6°C		Detected temp. shift value setup (CODE NO. [06]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> NO SHIFT <input type="checkbox"/> +1°C <input type="checkbox"/> +2°C <input type="checkbox"/> +3°C <input type="checkbox"/> +4°C <input type="checkbox"/> +5°C <input type="checkbox"/> +6°C		Detected temp. shift value setup (CODE NO. [06]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> NO SHIFT <input type="checkbox"/> +1°C <input type="checkbox"/> +2°C <input type="checkbox"/> +3°C <input type="checkbox"/> +4°C <input type="checkbox"/> +5°C <input type="checkbox"/> +6°C		Detected temp. shift value setup (CODE NO. [06]) <input type="checkbox"/> NO CHANGE <input type="checkbox"/> NO SHIFT <input type="checkbox"/> +1°C <input type="checkbox"/> +2°C <input type="checkbox"/> +3°C <input type="checkbox"/> +4°C <input type="checkbox"/> +5°C <input type="checkbox"/> +6°C		
Incorporation of parts sold separately		Incorporation of parts sold separately		Incorporation of parts sold separately		Incorporation of parts sold separately		
Have you incorporated the following parts sold separately? If incorporated, fill check mark [x] in each [ITEM]. (When incorporating, the setup change is necessary in some cases. For setup change method, refer to Installation Manual attached to each part sold separately.)								
<input type="checkbox"/> Others () <input type="checkbox"/> Others ()		<input type="checkbox"/> Others () <input type="checkbox"/> Others ()		<input type="checkbox"/> Others () <input type="checkbox"/> Others ()		<input type="checkbox"/> Others () <input type="checkbox"/> Others ()		



คำแนะนำเบื้องต้น

โปรดอ่านคู่มือการติดตั้งอย่างละเอียดก่อนการติดตั้งเครื่องปรับอากาศ

- คู่มือนี้อธิบายวิธีการติดตั้งตัวเครื่องภายใน
- ในการติดตั้งตัวเครื่องภายนอก โปรดปฏิบัติตามคู่มือการติดตั้งที่ให้มาพร้อมกับตัวเครื่องภายนอก

การเลือกใช้สารทำความเย็นชนิดใหม่

เครื่องปรับอากาศนี้ใช้สารทำความเย็น R410A ซึ่งเป็นสารทำความเย็นซึ่งเป็นมิตรต่อสิ่งแวดล้อม

ข้อมูล

หากรุ่น U series (TU2C-Link) ใช้ร่วมกับรุ่นอื่นนอกเหนือจากรุ่น U series (TCC-Link) คุณสมบัติของสายไฟและจำนวนสูงสุดของตัวเครื่องภายในที่สามารถเชื่อมต่อได้ก็จะเปลี่ยนไป โปรดคำนึงถึงคุณสมบัติในการสื่อสารเมื่อทำการติดตั้ง บำรุงรักษาหรือซ่อมแซม สำหรับรายละเอียดให้อ้างอิงจาก “การต่อสายไฟ” ในคู่มือเล่มนี้

สารบัญ

1 ข้อควรระวังเพื่อความปลอดภัย	32
2 ชั้นส่วนอุปกรณ์เสริม	36
3 การเลือกสถานที่ติดตั้ง	36
4 การติดตั้ง	38
5 การต่อท่อน้ำทิ้ง	39
6 การออกแบบท่อลม	42
7 การต่อท่อส่งสารทำความเย็น	43
8 การต่อสายไฟ	44
9 การควบคุมการใช้งาน	48
10 การทดสอบการทำงาน	50
11 การบำรุงรักษา	51
12 การแก้ไขปัญหา	52

ขอบคุณที่เลือกซื้อเครื่องปรับอากาศ

โปรดอ่านคำแนะนำต่างๆ ที่มีข้อมูลสำคัญและโปรดปฏิบัติตามข้อมูลดังกล่าว

หลังจากทำการติดตั้งแล้ว โปรดส่งคู่มือการติดตั้งนี้พร้อมกับคู่มือการใช้งานเครื่องปรับอากาศให้กับผู้ใช้ และบอกให้ผู้ใช้เก็บรักษาคู่มือทั้งสองฉบับไว้เพื่อใช้อ้างอิงในภายหลัง

ข้อสามัญ: เครื่องปรับอากาศ

คำจำกัดความของผู้ติดตั้งที่มีความชำนาญหรือช่างบริการที่มีความชำนาญ

เครื่องปรับอากาศนี้ต้องได้รับการติดตั้ง บำรุงรักษา ซ่อมแซม และเคลื่อนย้ายโดยผู้ติดตั้งที่มีความชำนาญ หรือช่างบริการที่มีความชำนาญ เมื่อมีงานใดๆ ที่เกี่ยวข้องกับเครื่องปรับอากาศนี้ ให้ถามผู้ติดตั้งที่มีความชำนาญ หรือช่างบริการที่มีความชำนาญ ให้ดำเนินการต่อไป

ผู้ติดตั้งที่มีความชำนาญหรือช่างบริการที่มีความชำนาญ หมายถึง ผู้ปฏิบัติงานที่มีคุณสมบัติและความรู้ตามที่อธิบายไว้ในตารางต่อไปนี้

ตัวแทน	ความชำนาญและความรู้ที่ตัวแทนจะต้องมี
ผู้ติดตั้งที่มีความชำนาญ	<ul style="list-style-type: none"> • ผู้ติดตั้งที่มีความชำนาญ คือ บุคคลที่ทำการติดตั้ง ดูแลรักษา ย้ายตำแหน่ง และถอดเครื่องปรับอากาศ ผู้ติดตั้งต้องได้รับการฝึกอบรมเพื่อติดตั้ง ดูแลรักษา ย้ายตำแหน่ง และถอดเครื่องปรับอากาศ หรืออีกประการหนึ่ง ผู้ติดตั้งนั้นได้รับคำแนะนำในการปฏิบัติงานดังกล่าวจากบุคคลที่ได้รับการอบรมและมีความรู้ความเข้าใจเป็นอย่างดีเกี่ยวกับการปฏิบัติงานเหล่านี้ • ผู้ติดตั้งที่มีความชำนาญซึ่งได้รับอนุญาตให้ปฏิบัติงานทางด้านไฟฟ้าที่เกี่ยวกับการติดตั้ง การย้ายตำแหน่ง และการถอด จะมีความเชี่ยวชาญเกี่ยวกับงานด้านไฟฟ้าตามที่กำหนดไว้โดยข้อกำหนดและกฎหมายท้องถิ่น และเป็นบุคคลที่ได้รับการฝึกอบรมงานทางด้านไฟฟ้าเกี่ยวกับเครื่องปรับอากาศ หรืออีกประการหนึ่ง ผู้ติดตั้งนั้นได้รับคำแนะนำในการปฏิบัติงานดังกล่าวจากบุคคลที่ได้รับการอบรมและมีความรู้ความเข้าใจเป็นอย่างดีเกี่ยวกับการปฏิบัติงานนี้ • ผู้ติดตั้งที่มีความชำนาญซึ่งได้รับอนุญาตให้ปฏิบัติงานกับสารทำความเย็นและท่อทางในการติดตั้ง การย้ายตำแหน่ง และการถอดจะมีความเชี่ยวชาญเกี่ยวกับงานด้านสารทำความเย็นและการต่อท่อทางตามที่กำหนดไว้โดยข้อกำหนดและกฎหมายท้องถิ่น และเป็นบุคคลที่ได้รับการฝึกอบรมทางด้านงานปฏิบัติงานกับสารทำความเย็นและท่อทางของเครื่องปรับอากาศ หรืออีกประการหนึ่ง ผู้ติดตั้งนั้นได้รับคำแนะนำในการปฏิบัติงานดังกล่าวจากบุคคลที่ได้รับการอบรมและมีความรู้ความเข้าใจเป็นอย่างดีเกี่ยวกับการปฏิบัติงานนี้ • ผู้ติดตั้งที่มีความชำนาญซึ่งได้รับอนุญาตให้ปฏิบัติงานที่ความสูงได้รับการฝึกอบรมในการปฏิบัติงานที่ความสูงกับเครื่องปรับอากาศ หรืออีกประการหนึ่ง ผู้ติดตั้งนั้นได้รับคำแนะนำในการปฏิบัติงานดังกล่าวจากบุคคลที่ได้รับการอบรมและมีความรู้ความเข้าใจเป็นอย่างดีเกี่ยวกับการปฏิบัติงานนี้
ช่างบริการที่มีความชำนาญ	<ul style="list-style-type: none"> • ช่างบริการที่มีความชำนาญ คือ บุคคลที่ทำการติดตั้ง ซ่อมแซม บำรุงรักษา ย้ายตำแหน่ง และถอดเครื่องปรับอากาศ ช่างบริการจะต้องได้รับการฝึกอบรมเพื่อติดตั้ง ซ่อมแซม บำรุงรักษา ย้ายตำแหน่ง และถอดเครื่องปรับอากาศ หรืออีกประการหนึ่ง ช่างบริการนั้นได้รับคำแนะนำในการปฏิบัติงานดังกล่าวจากบุคคลที่ได้รับการอบรมและมีความรู้ความเข้าใจเป็นอย่างดีเกี่ยวกับการปฏิบัติงานเหล่านี้ • ช่างบริการที่มีความชำนาญซึ่งได้รับอนุญาตให้ปฏิบัติงานทางด้านไฟฟ้าที่เกี่ยวกับการติดตั้ง การซ่อมแซม การย้ายตำแหน่ง และการถอดจะมีความเชี่ยวชาญเกี่ยวกับงานด้านไฟฟ้าตามที่กำหนดไว้โดยข้อกำหนดและกฎหมายท้องถิ่นและเป็นบุคคลที่ได้รับการฝึกอบรมงานทางด้านไฟฟ้าเกี่ยวกับเครื่องปรับอากาศ หรืออีกประการหนึ่ง ช่างบริการนั้นได้รับคำแนะนำในการปฏิบัติงานดังกล่าวจากบุคคลที่ได้รับการอบรมและมีความรู้ความเข้าใจเป็นอย่างดีเกี่ยวกับการปฏิบัติงานนี้ • ช่างบริการที่มีความชำนาญซึ่งได้รับอนุญาตให้ปฏิบัติงานกับสารทำความเย็นและท่อทางที่เกี่ยวกับการติดตั้ง การซ่อมแซม การย้ายตำแหน่ง และการถอดจะมีความเชี่ยวชาญเกี่ยวกับงานด้านสารทำความเย็นและท่อทางตามที่กำหนดไว้โดยข้อกำหนดและกฎหมายท้องถิ่น และเป็นบุคคลที่ได้รับการฝึกอบรมทางด้านงานปฏิบัติงานกับสารทำความเย็นและท่อทางของเครื่องปรับอากาศ หรืออีกประการหนึ่ง ช่างบริการนั้นได้รับคำแนะนำในการปฏิบัติงานดังกล่าวจากบุคคลที่ได้รับการอบรมและมีความรู้ความเข้าใจเป็นอย่างดีเกี่ยวกับการปฏิบัติงานนี้ • ช่างบริการที่มีความชำนาญซึ่งได้รับอนุญาตให้ปฏิบัติงานบนที่สูงได้รับการฝึกอบรมในการปฏิบัติงานบนที่สูงกับเครื่องปรับอากาศ หรืออีกประการหนึ่ง ช่างบริการที่มีความชำนาญนั้นได้รับคำแนะนำในการปฏิบัติงานดังกล่าวจากบุคคลที่ได้รับการอบรมและมีความรู้ความเข้าใจเป็นอย่างดีเกี่ยวกับการปฏิบัติงานนี้

คำอธิบายอุปกรณ์ป้องกัน

สวมถุงมือป้องกันและชุดที่ปลอดภัยสำหรับการทำงาน เมื่อเคลื่อนย้าย ติดตั้ง บำรุงรักษาซ่อมแซม หรือถอดชิ้นส่วน เครื่องปรับอากาศ

นอกเหนือจากอุปกรณ์ป้องกันพื้นฐานดังกล่าว ควรสวมใส่อุปกรณ์ป้องกันตามที่อธิบายไว้ด้านล่างเมื่อต้องปฏิบัติงานพิเศษ ตามที่กล่าวไว้ในตารางต่อไปนี้

การไม่สวมใส่อุปกรณ์ป้องกันที่เหมาะสมอาจก่อให้เกิดอันตรายได้ เนื่องจากคุณอาจได้รับบาดเจ็บ เกิดแผลไหม้ ไฟฟ้าช็อต และอาการบาดเจ็บอื่นๆ

งานที่ทำ	อุปกรณ์ป้องกันที่สวมใส่
ทุกประเภทงาน	ถุงมือป้องกัน ชุดที่ปลอดภัยสำหรับการทำงาน
งานที่เกี่ยวข้องกับไฟฟ้า	ถุงมือป้องกันความร้อนสำหรับช่างไฟฟ้า รองเท้าที่เป็นฉนวน เสื้อผ้าที่ป้องกันไฟฟ้าช็อต
งานที่ต้องทำในที่สูง (50 cm หรือสูงกว่า)	หมวกนิรภัย
งานเคลื่อนย้ายของหนัก	รองเท้าที่เสริมการป้องกันบริเวณนิ้วเท้า
งานซ่อมแซมตัวเครื่องภายนอก	ถุงมือป้องกันความร้อนสำหรับช่างไฟฟ้า

ข้อควรระวังเพื่อความปลอดภัยต่อไปนี้ อธิบายหัวข้อสำคัญด้านความปลอดภัยเพื่อป้องกันการบาดเจ็บต่อผู้ใช้ หรือต่อบุคคลอื่น และความเสียหายต่อทรัพย์สิน โปรดอ่านคู่มือนี้โดยละเอียดเมื่อเข้าใจเนื้อหาตามด้านล่างแล้ว (ความหมายของสัญลักษณ์) และต้องปฏิบัติตามคำอธิบายที่ให้ไว้

สัญลักษณ์	ความหมายของสัญลักษณ์
คำเตือน	ข้อความที่อธิบายไว้ในหัวข้อนี้จะอธิบายว่า การไม่ปฏิบัติตามคำเตือน อาจส่งผลให้เกิดอันตราย อย่างรุนแรงต่อร่างกาย (*1) หรือสูญเสียชีวิต หากใช้งานเครื่องปรับอากาศไม่ถูกต้อง
ข้อควรระวัง	ข้อความที่อธิบายไว้ในหัวข้อนี้จะอธิบายว่า การไม่ปฏิบัติตามข้อควรระวัง อาจส่งผลให้เกิดการบาดเจ็บเล็กน้อย (*2) หรือเกิดความเสียหายต่อทรัพย์สิน (*3) หากใช้งานเครื่องปรับอากาศไม่ถูกต้อง

*1: อันตรายอย่างรุนแรงต่อร่างกาย หมายถึง สูญเสียการมองเห็น เกิดแผลไหม้ ไฟฟ้าช็อต กระดุกหัก ได้รับสารพิษและการบาดเจ็บอื่นๆ ที่ส่งผลกระทบต่อร่างกาย และต้องเข้ารับการรักษาในโรงพยาบาล หรือรับการบำบัดรักษาในระยะยาวในฐานะผู้ป่วยนอก


*2: อาการบาดเจ็บเล็กน้อยหมายถึง อาการบาดเจ็บ เกิดแผลไหม้ ไฟฟ้าช็อต และอาการบาดเจ็บอื่นที่ไม่จำเป็นต้องเข้ารับการรักษาในโรงพยาบาล หรือรับการรักษาระยะยาวในฐานะผู้ป่วยนอก

*3: ความเสียหายต่อทรัพย์สิน หมายถึง ความเสียหายที่เกิดขึ้นกับอาคาร ที่พักอาศัย วัสดุตัวที่เสียดในพื้น และสัตว์เลี้ยง

จุดศูนย์ถ่วง

(หน่วย : mm)

ใช้รถยกในการขนย้ายตัวเครื่องปรับอากาศและใช้เครื่องกว้านหรือรอกในการติดตั้ง



สัญลักษณ์คำเตือนของตัวเครื่องปรับอากาศ

สัญลักษณ์คำเตือน	คำอธิบาย
<p>WARNING ELECTRICAL SHOCK HAZARD Disconnect all remote electric power supplies before servicing.</p>	<p>คำเตือน</p> <p>อันตรายจากไฟฟ้าช็อต ปลดการเชื่อมต่อจากแหล่งจ่ายกำลังไฟทั้งหมดก่อนการบำรุงรักษา</p>
<p>WARNING Moving parts. Do not operate unit with grille removed. Stop the unit before the servicing.</p>	<p>คำเตือน</p> <p>ชิ้นส่วนที่เคลื่อนไหวได้ อย่าใช้งานเครื่องปรับอากาศขณะที่ถอดตะแกรงออกให้ปิดเครื่องปรับอากาศ ก่อนทำการบำรุงรักษา</p>
<p>CAUTION High temperature parts. You might get burned when removing this panel.</p>	<p>ข้อควรระวัง</p> <p>ส่วนที่มีอุณหภูมิสูง ท่านอาจรู้สึกร้อนมากเมื่อเคลื่อนย้ายชิ้นส่วนดังกล่าว</p>
<p>CAUTION Do not touch the aluminum fins of the unit. Doing so may result in injury.</p>	<p>ข้อควรระวัง</p> <p>อย่าสัมผัสครีบอลูมิเนียมของเครื่องปรับอากาศ อาจได้รับบาดเจ็บ</p>
<p>CAUTION BURST HAZARD Open the service valves before the operation, otherwise there might be the burst.</p>	<p>ข้อควรระวัง</p> <p>อันตรายจากการระเบิด เปิดวาล์วบริการก่อนเปิดเครื่องปรับอากาศ มิฉะนั้น อาจเกิดระเบิดได้</p>

1 ข้อควรระวังเพื่อความปลอดภัย

ผู้ผลิตจะไม่รับผิดชอบใดๆ หากเกิดความเสียหายที่เกิดจากการไม่อ่านข้อมูลโดยละเอียดจากคู่มือนี้

⚠ คำเตือน

ทั่วไป

- อ่านคู่มือการติดตั้งอย่างละเอียดก่อนทำการติดตั้งเครื่องปรับอากาศ และปฏิบัติตามคำแนะนำในการติดตั้งเครื่องปรับอากาศ
- การติดตั้งเครื่องปรับอากาศ ควรติดตั้งโดยผู้ติดตั้งที่มีความชำนาญ หรือช่างบริการที่มีความชำนาญเท่านั้น การติดตั้งที่ไม่ถูกต้องอาจส่งผลให้เกิดน้ำรั่ว ไฟฟ้าดูดหรืออัคคีภัยได้
- ห้ามใช้สารทำความเย็นใดๆ ที่แตกต่างไปจากที่ระบุไว้สำหรับการเติม หรือการเปลี่ยน มิฉะนั้นอาจมีแรงดันสูงผิดปกติเกิดขึ้นในวงจรการทำงาน ซึ่งอาจทำให้ผลิตภัณฑ์นี้ทำงานผิดปกติหรือเกิดการระเบิด หรืออาจทำให้ท่านได้รับบาดเจ็บได้
- ก่อนเปิดฝาครอบกล่องควบคุมไฟของตัวเครื่องภายในหรือแผงควบคุมไฟของตัวเครื่องภายนอก ต้องโยกสวิตช์ของเครื่องตัดกระแสไฟฟ้าไปที่ตำแหน่ง OFF มิฉะนั้นอาจเกิดไฟฟ้าลัดวงจรกับชิ้นส่วนภายในผ่านหน้าสัมผัสได้ ผู้ติดตั้งที่มีความชำนาญ(*1) หรือช่างบริการที่มีความชำนาญ(*1) เท่านั้น ที่จะเปิดฝาครอบกล่องควบคุมไฟของตัวเครื่องภายในหรือแผงควบคุมไฟของตัวเครื่องภายนอก และปฏิบัติงานที่ต้องการได้
- ก่อนทำการติดตั้ง บำรุงรักษา ซ่อมแซม หรือถอดชิ้นส่วน ให้ปิดเครื่องตัดกระแสไฟฟ้าก่อน มิฉะนั้นอาจถูกไฟฟ้าช็อตได้
- แขนงป้าย “กำลังทำงาน” ใกล้เคียงเครื่องตัดกระแสไฟฟ้าขณะทำการติดตั้ง บำรุงรักษา ซ่อมแซม หรือถอดชิ้นส่วน มีอันตรายจากไฟฟ้าช็อต หากเครื่องตัดกระแสไฟฟ้าเปิดอยู่
- ควรให้ผู้ติดตั้งที่มีความชำนาญ(*1) หรือช่างบริการที่มีความชำนาญ(*1) เท่านั้น เป็นผู้ดำเนินการบนที่มีความสูงตั้งแต่ 50 cm ขึ้นไปโดยใช้บันได หรือดำเนินการถอดตะแกรงลมเข้าของตัวเครื่องภายใน

- สวมถุงมือป้องกันและเสื้อผ้าที่ปลอดภัยสำหรับการทำงานขณะทำการติดตั้ง ซ่อมแซม หรือถอดชิ้นส่วน
- ห้ามแตะต้องครีบอลูมิเนียม คุณอาจได้รับอันตรายหากแตะต้องชิ้นส่วนดังกล่าว หากจำเป็นจะต้องสัมผัสครีบอลูมิเนียม ควรสวมถุงมือป้องกันและเสื้อผ้าที่ปลอดภัยสำหรับการทำงานก่อนแล้วจึงลงมือปฏิบัติงาน
- ก่อนเปิดช่องการตรวจสอบ ต้องโยกสวิตช์ของเครื่องตัดกระแสไฟฟ้าไปที่ตำแหน่ง OFF การไม่โยกสวิตช์ของเครื่องตัดกระแสไฟฟ้าไปที่ตำแหน่ง OFF อาจส่งผลให้เกิดการบาดเจ็บจากการสัมผัสกับชิ้นส่วนที่กำลังหมุนได้ การเปิดช่องการตรวจสอบและปฏิบัติงานที่ต้องการต้องกระทำโดยผู้ติดตั้งที่มีความชำนาญ(*1) หรือช่างบริการที่มีความชำนาญ(*1) เท่านั้น
- เมื่อปฏิบัติงานบนที่สูง ให้ใช้บันไดที่สอดคล้องกับมาตรฐาน ISO 14122 และปฏิบัติตามคำแนะนำในการใช้บันได รวมทั้งสวมหมวกนิรภัยเมื่อปฏิบัติงาน
- ก่อนการทำความสะอาดแผ่นกรองอากาศ (จำหน่ายแยก) หรือชิ้นส่วนอื่นๆ ของตัวเครื่องภายนอก ควรปิดเครื่องตัดกระแสไฟฟ้า และแขวนป้าย “กำลังทำงาน” ใกล้เคียงเครื่องตัดกระแสไฟฟ้าก่อนลงมือปฏิบัติงาน
- ก่อนการปฏิบัติงานบนที่สูง ควรตั้งป้ายเตือนเพื่อไม่ให้มีผู้ใดเดินเข้ามาใกล้บริเวณนั้น อุปกรณ์หรือวัตถุอื่นๆ อาจหล่นใส่และทำให้คนที่เดินอยู่ด้านล่างได้รับบาดเจ็บ ในขณะที่ปฏิบัติงาน ควรสวมหมวกนิรภัยเพื่อป้องกันวัตถุหล่นใส่
- สารทำความเย็นที่ใช้ในเครื่องปรับอากาศ คือ R410A
- เครื่องปรับอากาศต้องเคลื่อนย้ายในสภาพสมบูรณ์ หากส่วนใดส่วนหนึ่งของผลิตภัณฑ์เสียหาย โปรดติดต่อผู้แทนจำหน่าย
- เมื่อต้องเคลื่อนย้ายเครื่องปรับอากาศด้วยมือ ต้องใช้คนอย่างน้อยสี่คน
- อย่าเคลื่อนย้ายหรือซ่อมเครื่องใดๆ ด้วยตนเอง เนื่องจากมีไฟฟ้าแรงสูงภายในเครื่อง ท่านอาจถูกไฟฟ้าดูดขณะถอดฝาครอบและตัวเครื่องหลัก
- อุปกรณ์นี้จะต้องใช้โดยผู้เชี่ยวชาญหรือผู้ได้รับการอบรมกับทางร้านค้า ในอุตสาหกรรมเบา หรือเพื่อการพาณิชย์โดยผู้ใช้ทั่วไป
- ห้ามเพิ่มอุปกรณ์ใดๆ ที่โรงงานไม่ได้แนะนำไว้

การเลือกสถานที่เพื่อทำการติดตั้ง

- หากติดตั้งเครื่องปรับอากาศในห้องขนาดเล็ก ปฏิบัติตามมาตรการที่เหมาะสมเพื่อให้แน่ใจว่าความเข้มข้นของสารทำความเย็นที่รั่วไหลภายในห้องจะไม่เกินระดับที่เป็นอันตราย
- ห้ามติดตั้งในสถานที่ที่อาจเสี่ยงต่อการสัมผัสกับก๊าซไวไฟ หากก๊าซรั่วซึมออกมาเป็นจำนวนมากบริเวณตัวเครื่อง อาจก่อให้เกิดเพลิงไหม้ได้
- หากต้องการเคลื่อนย้ายเครื่องปรับอากาศ ควรสวมรองเท้าที่เสริมการป้องกันบริเวณนิ้วเท้า
- ในการเคลื่อนย้ายเครื่อง ห้ามจับถือที่สายรัดกล่องผลิตภัณฑ์ ท่านอาจบาดเจ็บได้หากสายขาด
- ติดตั้งตัวเครื่องภายในให้สูงจากพื้นอย่างน้อย 2.5 m มิเช่นนั้นผู้ใช้จะได้รับบาดเจ็บหรือถูกไฟฟ้าช็อต หากนำน้ำหรือวัตถุอื่นเข้าไปในตัวเครื่องภายในขณะที่เครื่องกำลังทำงานอยู่
- อย่าวางอุปกรณ์ที่มีการเผาไหม้ใดๆ ไว้ในทิศทางที่สัมผัสกับลมจากเครื่องปรับอากาศโดยตรงมิฉะนั้นอาจเกิดการเผาไหม้ที่ไม่สมบูร์ณ

การติดตั้ง

- ความยาวของท่อดูดต้องมากกว่า 850 mm
- หากต้องการติดตั้งตัวเครื่องภายในเป็นแบบแขวน ควรใช้โบลต์ (M10 หรือ W3/8) และน็อต (M10 หรือ W3/8) ในการติดตั้ง
- ติดตั้งเครื่องปรับอากาศให้แน่นหนาบนพื้นที่ที่สามารถรับน้ำหนักได้ ตัวเครื่องอาจร่วงหล่นลงมาทำให้ได้รับบาดเจ็บ หากพื้นผิวไม่มีความแข็งแรงพอ
- ปฏิบัติตามคำแนะนำในคู่มือการติดตั้งเครื่องปรับอากาศ หากไม่ปฏิบัติตามคำแนะนำเหล่านี้ตัวเครื่องอาจจะร่วงหล่นลงมา พลิกคว่ำ หรือเกิดเสียงรบกวน เกิดการสั่นสะเทือน น้ำรั่วซึม หรือปัญหาอื่นๆ ได้
- ดำเนินการติดตั้งตามที่ระบุไว้เพื่อป้องกันสภาวะลมแรงและแผ่นดินไหว หากเครื่องปรับอากาศไม่ได้รับการติดตั้งอย่างถูกต้อง ตัวเครื่องอาจพลิกคว่ำหรือร่วงหล่นลงมาและก่อให้เกิดอุบัติเหตุได้
- หากก๊าซสารทำความเย็นรั่วซึมออกมาขณะทำการติดตั้ง ให้ระบายอากาศในห้องทันทีหากก๊าซสารทำความเย็นรั่วซึมออกมาสัมผัสกับไฟ อาจก่อให้เกิดก๊าซที่เป็นพิษได้
- ใช้รถยกในการขนย้ายตัวเครื่องปรับอากาศและใช้เครื่องก้านหรือรถในการติดตั้ง
- ต้องสวมหมวกนิรภัยเพื่อป้องกันวัตถุหล่นใส่ศีรษะ โดยเฉพาะอย่างยิ่งเมื่อทำงานอยู่ใต้ช่องการตรวจสอบ ต้องสวมหมวกนิรภัยเพื่อป้องกันวัตถุหล่นใส่ศีรษะจากช่องดังกล่าว

การต่อท่อส่งสารทำความเย็น

- ติดตั้งท่อส่งสารทำความเย็นระหว่างทำการติดตั้งให้เรียบร้อยก่อนที่จะเปิดเครื่องปรับอากาศ หากคอมเพรสเซอร์ทำงานขณะที่วาล์วยังเปิดอยู่และไม่มีท่อส่งสารทำความเย็น คอมเพรสเซอร์จะดูดอากาศเข้าไปและทำให้วงจรการทำความเย็นมีแรงดันเกินซึ่งอาจจะส่งผลให้เกิดการบาดเจ็บต่อผู้ใช้ได้

- ชั้นเพรันทให้แน่นด้วยประแจวัดแรงบิดตามวิธีที่กำหนดไว้ หากชั้นเพรันทแน่นเกินไปอาจทำให้เกิดรอยร้าวที่เพรันท หลังการใช้งานเป็นระยะเวลาานาน ซึ่งอาจก่อให้เกิดการรั่วซึมของสารทำความเย็น
- หลังทำการติดตั้ง ควรตรวจสอบให้แน่ใจว่าก๊าซสารทำความเย็นไม่มีการรั่วซึม หากก๊าซสารทำความเย็นรั่วซึมออกมาในห้องและสัมผัสถูกต้นเพลิง เช่น เต้าทำอาหาร อาจก่อให้เกิดก๊าซที่เป็นพิษได้
- เมื่อทำการติดตั้งหรือเคลื่อนย้ายเครื่องปรับอากาศ ให้ปฏิบัติตามคำแนะนำในคู่มือการติดตั้งและไล่อากาศทั้งหมด เพื่อจะได้ไม่มีก๊าซอื่นผสมอยู่ในวงจรการทำงานทำความเย็นนอกเหนือจากสารทำความเย็น เครื่องปรับอากาศอาจทำงานผิดปกติหากไม่มีการไล่อากาศทั้งหมดเสียก่อน
- ควรใช้ก๊าซไนโตรเจนเพื่อทดสอบการผนึกแน่นไม่ให้อากาศเข้า
- ควรเชื่อมต่อท่อเติมสารทำความเย็นตามวิธีการดังกล่าวเพื่อไม่ให้ท่อหลุดออกจากกัน

การเดินสายไฟ

- การดำเนินการเกี่ยวกับไฟฟ้ากับเครื่องปรับอากาศต้องกระทำโดยผู้ติดตั้งที่มีความชำนาญ(*1) หรือช่างบริการที่มีความชำนาญ(*1) เท่านั้น ผู้ที่ไม่มีความชำนาญไม่สามารถดำเนินการเองได้เพราะการดำเนินการที่ไม่เหมาะสมอาจก่อให้เกิดไฟฟ้าดูดและ/หรือไฟฟ้ารั่วได้
- เมื่อเชื่อมต่อสายไฟ ซ่อมแซมชิ้นส่วนที่เป็นไฟฟ้า หรือดำเนินงานด้านอื่นๆ เกี่ยวกับไฟฟ้า ช่างไฟควรสวมถุงมือ รองเท้าและเสื้อผ้าที่เป็นฉนวน เพื่อป้องกันไฟฟ้าช็อต การไม่สวมใส่อุปกรณ์ป้องกันอาจก่อให้เกิดไฟฟ้าช็อตได้
- ใช้สายไฟที่มีคุณสมบัติตรงตามที่กำหนดไว้ในคู่มือการติดตั้ง ข้อบังคับในท้องถิ่น และข้อกำหนดทางกฎหมาย การใช้สายไฟที่ไม่ตรงตามคุณสมบัติอาจเพิ่มความเสี่ยงในการเกิดไฟฟ้าช็อตไฟฟ้ารั่ว ควันไฟและ/หรือเพลิงไหม้
- ต่อสายดิน (งานสายกราวด์)
การต่อสายดินที่ไม่ถูกต้องอาจก่อให้เกิดไฟฟ้าลัดวงจรได้

- ห้ามต่อสายดินกับท่อก๊าซ ท่อน้ำ และสายล่อฟ้า หรือสายดินของโทรศัพท์
- หลังซ่อมแซมหรือย้ายที่ติดตั้ง ควรตรวจสอบให้แน่ใจว่าได้เชื่อมต่อสายดินอย่างถูกต้องแล้ว
- ติดตั้งเครื่องตัดกระแสไฟฟ้าที่มีคุณสมบัติตรงตามที่กำหนดไว้ในคู่มือการติดตั้ง ข้อบังคับในท้องถิ่น และข้อกำหนดทางกฎหมาย
- ติดตั้งเครื่องตัดกระแสไฟฟ้าในที่ที่ผู้ตรวจสอบสามารถเข้าถึงได้โดยสะดวก
- เมื่อติดตั้งเครื่องตัดกระแสไฟฟ้านอกอาคาร ควรเลือกใช้เครื่องตัดกระแสไฟฟ้าที่ออกแบบมาเพื่อการใช้งานนอกอาคาร
- ไม่ควรพ่วงต่อสายไฟให้ยาวขึ้นในทุกกรณี ปัญหาด้านการเชื่อมต่อในที่ที่มีการพ่วงต่อสายไฟอาจเพิ่มความเสี่ยงในการเกิดควันไฟหรือเพลิงไหม้
- ควรเดินสายไฟตามข้อกำหนดทางกฎหมายและข้อบังคับในชุมชนรวมถึงคู่มือการติดตั้ง
การไม่กระทำตามอาจส่งผลให้เสียชีวิตจากการถูกไฟดูดหรือเกิดไฟฟ้าลัดวงจร

การทดสอบการทำงาน

- ก่อนเปิดใช้งานเครื่องปรับอากาศหลังการติดตั้ง ควรตรวจสอบให้แน่ใจว่าฝาครอบกล่องควบคุมไฟของตัวเครื่องภายในและแผงบริการของตัวเครื่องภายนอกปิดสนิท และเปิดเครื่องตัดกระแสไฟฟ้าแล้ว คุณอาจโดนไฟฟ้าช็อตได้หากเปิดเครื่องปรับอากาศโดยไม่ได้ตรวจสอบสิ่งเหล่านี้เสียก่อน
- หากเกิดปัญหาใดๆ กับเครื่องปรับอากาศ (เช่น ข้อความผิดพลาดปรากฏบนหน้าจอ กลิ่นไหม้เสียงผิดปกติเครื่องปรับอากาศ ไม่สามารถทำความเย็นหรือทำให้อากาศอุ่นขึ้น หรือมีน้ำรั่วซึมออกมา) อย่าแตะต้องเครื่องปรับอากาศ แต่ให้ปิดเครื่องตัดกระแสไฟฟ้า แล้วติดต่อช่างบริการที่มีความชำนาญ ตรวจสอบให้แน่ใจว่าจะไม่มีใครเปิดเครื่องปรับอากาศจนกระทั่งช่างบริการที่มีความชำนาญมาถึง (โดยการติดป้าย “ชำรุด” ใกล้เคียง กับเครื่องตัดกระแสไฟฟ้า เป็นต้น) หากยังใช้เครื่องปรับอากาศในขณะที่มีความผิดปกติอาจทำให้กลไกการทำงานเกิดปัญหา และเพิ่มความเสี่ยงหรือส่งผลให้เกิดไฟฟ้าช็อตหรือปัญหาอื่นๆ ได้

- หลังจากเสร็จงานแล้ว ให้ใช้ชุดอุปกรณ์ทดสอบฉนวน (แรงดันไฟฟ้า 500V) ตรวจสอบว่าความต้านทานระหว่างส่วนที่มีประจุกับส่วนโลหะที่ไม่มีประจุ (ส่วนดิน) อยู่ที่ 1MΩ หรือมากกว่าหรือไม่ หากค่าความต้านทานต่ำ อาจทำให้เกิดการรั่วไหลหรือเกิดไฟฟ้าช็อตได้
- เมื่อติดตั้งเสร็จสมบูรณ์แล้ว ควรตรวจหาการรั่วไหลของสารทำความเย็นและตรวจสอบความต้านทานของฉนวนและการระบายน้ำ จากนั้นทำการทดสอบการทำงาน เพื่อตรวจสอบว่าเครื่องปรับอากาศทำงานได้อย่างถูกต้อง

คำอธิบายสำหรับผู้ใช้งาน

- เมื่อติดตั้งเสร็จสมบูรณ์แล้ว ให้แจ้งผู้ใช้งานว่าเครื่องตัดกระแสไฟฟ้าติดตั้งอยู่ที่ใด หากผู้ใช้ไม่ทราบว่าเครื่องตัดกระแสไฟฟ้าอยู่ที่ใด ผู้ใช้จะไม่สามารถปิดเครื่องตัดกระแสไฟฟ้าได้เมื่อมีปัญหาใดๆ เกิดขึ้นกับเครื่องปรับอากาศ
- ภายหลังจากติดตั้ง ควรอธิบายให้ลูกค้าทราบถึงวิธีการใช้งาน รวมทั้งการบำรุงรักษาเครื่องตามคู่มือผู้ใช้งาน

การย้ายที่ติดตั้ง

- ควรให้ผู้ติดตั้งที่มีความชำนาญ(*1) หรือช่างบริการที่มีความชำนาญ(*1) เท่านั้น เป็นผู้ดำเนินการย้ายที่ติดตั้งเครื่องปรับอากาศเท่านั้น หากให้ผู้ที่ไม่มีความชำนาญเป็นผู้ดำเนินการอาจเกิดเพลิงไหม้ไฟฟ้าช็อต ได้รับความเจ็บ เกิดการรั่วไหลของน้ำเสียงรบกวน และ/หรือการสั้นสะพานได้
- เมื่อกระทำการบีบดาวน์ให้ปิดคอมเพรสเซอร์ก่อนที่จะถอดท่อสารทำความเย็น การถอดท่อสารทำความเย็นขณะที่เปิดวาล์วทิ้งไว้และคอมเพรสเซอร์ยังทำงานอยู่ จะทำให้อากาศและก๊าซอื่นถูกดูดเข้าไป เป็นการเพิ่มแรงดันภายในวงจรการทำงานทำความเย็นให้สูงขึ้น และอาจก่อให้เกิดการแตกออก ทำให้ได้รับความเจ็บและเกิดปัญหาอื่นๆ ตามมาได้

⚠ ข้อควรระวัง

การติดตั้งเครื่องปรับอากาศที่ใช้สารทำความเย็นชนิดใหม่

- เครื่องปรับอากาศเครื่องนี้ใช้สารทำความเย็นแบบ HFC (R410A) ซึ่งไม่ทำลายชั้นโอโซน
- คุณลักษณะของสารทำความเย็นรุ่น R410A คือ จะดูดซึมน้ำได้ง่าย จับตัวกับเมมเบรนหรือน้ำมันได้ง่าย และแรงดันจะสูงกว่าสารทำความเย็นรุ่น R22 ถึง 1.6 เท่า สารทำความเย็นรุ่นใหม่นี้ยังมาพร้อมกับการเปลี่ยนแปลงของน้ำมันทำความเย็น ดังนั้นจึงไม่ควรให้น้ำ ฝุ่นผง สารทำความเย็นรุ่นเก่า หรือน้ำมันทำความเย็นเข้าไปในวงจรการทำงานทำความเย็นในระหว่างการติดตั้ง
- เพื่อป้องกันไม่ให้เกิดการรั่วสารทำความเย็นและน้ำมันทำความเย็นผิดชนิด ขนาดของส่วนเชื่อมต่อของช่องถ่ายเทประจุของตัวเครื่องกับอุปกรณ์การติดตั้งจึงเปลี่ยนไปจากเดิมที่เคยใช้กับสารทำความเย็นรุ่นเก่าด้วย
- ดังนั้นเครื่องมือที่ใช้สำหรับสารทำความเย็นรุ่นใหม่ (R410A) จึงนำมาให้ใช้โดยเฉพาะ
- สำหรับท่อเชื่อมให้ใช้ท่อใหม่ที่สะอาดซึ่งออกแบบมาสำหรับ R410A และโปรดตรวจสอบให้แน่ใจว่าไม่มีน้ำหรือฝุ่นผงเข้าไปได้

ถอดปลั๊กอุปกรณ์จากแหล่งจ่ายไฟหลัก


- อุปกรณ์นี้ต้องต่อกับแหล่งจ่ายไฟหลักด้วยสวิตช์ซึ่งมีระยะห่างหน้าสัมผัสขั้วต่ออย่างน้อย 3 mm

สายไฟของแหล่งจ่ายไฟของเครื่องปรับอากาศนี้ต้องใช้ฟิวส์ในการติดตั้ง (ใช้ได้ทุกชนิด)

- (*1) โปรดดู “คำจำกัดความของผู้ติดตั้งที่มีความชำนาญหรือช่างบริการที่มีความชำนาญ”

2 ชิ้นส่วนอุปกรณ์เสริม

■ ชิ้นส่วนอุปกรณ์เสริม

ชื่อชิ้นส่วน	จำนวน	รูปร่าง	การใช้งาน
คู่มือการติดตั้ง	1	คู่มือเล่มนี้	(ควรตรวจสอบให้แน่ใจว่าคุณลูกค้าได้รับคู่มือนี้)
ท่อฉนวนกันความร้อน	2	 (200×200×6t)	สำหรับการหุ้มฉนวนกันความร้อนของส่วนต่อเชื่อมของท่อก๊าซและท่อของเหลว
แหวนรอง	8		สำหรับการแขวนตัวเครื่อง
สายรัดท่อ	1		สำหรับการต่อท่อระบายน้ำ
ท่ออ่อน	1		สำหรับการปรับตั้งตำแหน่งกึ่งกลางของท่อระบาย
ฉนวนกันความร้อน	1	 (220×300×10t)	สำหรับการหุ้มฉนวนกันความร้อนของส่วนต่อเชื่อมของท่อระบายน้ำ
วัสดุกันรั่ว	3	 (45×45×3t)	สำหรับการกันรั่วของช่องเชื่อมต่อยุโรป

3 การเลือกสถานที่ติดตั้ง

หลีกเลี่ยงการติดตั้งในบริเวณต่อไปนี้

เลือกตำแหน่งสำหรับตัวเครื่องภายในโดยให้มีโอกาสเย็นหรืออุ่นถ่ายเทหมุนเวียนอย่างสม่ำเสมอ หลีกเลี่ยงการติดตั้งในสถานที่ที่มีลักษณะดังต่อไปนี้

- บริเวณที่มีน้ำเค็ม (พื้นที่ชายฝั่ง)
- บริเวณที่มีสภาวะความเป็นกรดหรือด่าง (เช่น บ่อน้ำพุร้อน โรงงานที่มีการผลิตสารเคมีหรือแก๊สพิษและสถานที่ที่มีโอโซนจากอุปกรณ์เผาไหม้ซึ่งจะถูกดูดเข้าไปในตัวเครื่อง) การติดตั้งในบริเวณดังกล่าวจะทำให้เครื่องแลกเปลี่ยนความร้อน (ครีบอลูมิเนียมและท่อทองแดง) และชิ้นส่วนอื่นๆ เกิดการสึกกร่อน
- บริเวณที่มีไอน้ำมันหล่อลื่นหรือไอน้ำมันประเภทอื่นจากเครื่องจักร การติดตั้งในบริเวณดังกล่าวจะทำให้เครื่องแลกเปลี่ยนความร้อนเกิดการสึกกร่อน โอโซนจะเกิดขึ้นจากการปิดกั้นของเครื่องแลกเปลี่ยนความร้อน ชิ้นส่วนพลาสติกเกิดความเสียหาย ฉนวนกันความร้อนจะลอกออกและปัญหาอื่นๆ เกิดขึ้นตามมา
- บริเวณที่มีเหล็กหรือผงโลหะต่างๆ หากมีเหล็กหรือผงโลหะติดอยู่หรือสะสมภายในเครื่องปรับอากาศ อาจก่อให้เกิดเพลิงไหม้ขึ้นเองได้
- บริเวณที่มีโอโซนจากน้ำมันอาหารก่อตัวขึ้น (เช่น ห้องครัวที่ใช้น้ำมันในการทำอาหาร) แผ่นกรองที่อุดตันจะทำให้การทำงานของเครื่องปรับอากาศเสื่อมถอย ไอน้ำก่อตัว ชิ้นส่วนพลาสติกเกิดความเสียหายและปัญหาอื่นๆ เกิดขึ้นตามมา
- บริเวณที่ใกล้กับสิ่งกีดขวาง เช่น ช่องเปิดถ่ายเทอากาศหรืออุปกรณ์ให้แสงสว่างซึ่งรบกวนการไหลเวียนของอากาศที่ปล่อยออกมา (การรบกวนการไหลเวียนของอากาศจะทำให้การทำงานของเครื่องปรับอากาศเสื่อมถอยหรือตัวเครื่องปิดการทำงาน)
- บริเวณที่ใช้งานเครื่องกำเนิดไฟฟ้าภายในบ้านเป็นแหล่งจ่ายไฟ คลื่นความถี่ของสายไฟและแรงดันไฟฟ้าอาจเกิดความผันผวนและส่งผลกระทบต่อการทำงานของเครื่องปรับอากาศอาจทำงานผิดปกติได้
- บนเครื่องบินหรือรถบรรทุก เรือหรือยานพาหนะเคลื่อนที่
- ห้ามใช้งานเครื่องปรับอากาศเพื่อจุดประสงค์อื่นๆ (เช่น การถนอมอาหาร พืช ใช้เป็นเครื่องมือวัดความแม่นยำ หรืองานศิลปะ) (คุณภาพของวัสดุที่เก็บรักษาอาจเสื่อมคุณภาพ)
- บริเวณที่มีคลื่นความถี่สูง (จากอุปกรณ์อินเวอร์เตอร์ เครื่องกำเนิดไฟฟ้าภายในบ้าน อุปกรณ์การแพทย์หรืออุปกรณ์สื่อสาร) (การทำงานไม่ถูกต้อง ปัญหาในการควบคุมเครื่องปรับอากาศหรือเสียงรบกวนอาจส่งผลกระทบต่อการทำงานของอุปกรณ์)
- บริเวณที่มีสิ่งใดก็ตามที่อยู่ใต้เครื่องที่ติดตั้งซึ่งอาจได้รับผลกระทบจากความเปียกชื้น (หากการระบายน้ำอุดตันหรือเมื่อความชื้นเกิน 80% หยดน้ำจากตัวเครื่องภายในจะหยดลง อาจก่อให้เกิดความเสียหายต่อสิ่งที่อยู่ใต้เครื่อง)
- ในกรณีของระบบประเภทไร้สาย ห้องที่ติดหลอดไฟเรืองแสงแบบอินเวอร์เตอร์หรือบริเวณที่ได้รับแสงแดดโดยตรง (สัญญาณจากรีโมทคอนโทรลแบบไร้สายอาจคลาดเคลื่อนได้)
- บริเวณที่มีการใช้สารทำลายอินทรีย์
- เครื่องปรับอากาศไม่สามารถใช้ในการทำความเย็นกรดคาร์บอนิกเหลวหรือโรงงานสารเคมีได้
- บริเวณที่ใกล้กับประตูหรือหน้าต่างที่เครื่องปรับอากาศอาจสัมผัสกับอากาศภายนอกที่มีอุณหภูมิสูงหรือความชื้นสูง (อาจเกิดการก่อตัวของหยดน้ำ)
- บริเวณที่ใช้สเปร์ยแบบเฉพาบ่อยๆ
- บริเวณที่มีการระบายอากาศไม่ดี

■ การติดตั้งในสถานะที่มีความชื้นสูง

ในบางกรณีรวมถึงช่วงฤดูฝนโดยเฉพาะอย่างยิ่งด้านในของเพดานอาจมีสถานะที่มีความชื้นสูง (อุณหภูมิของจุดน้ำค้าง: 23 °C ขึ้นไป)

1. การติดตั้งตัวเครื่องภายในที่มีกระเบื้องบนหลังคา
2. การติดตั้งตัวเครื่องภายในเพดานที่มีหลังคานวน
3. การติดตั้งตัวเครื่องภายในเพดานที่ใช้สำหรับเป็นทางนำเข้าอากาศบริสุทธิ์
4. การติดตั้งตัวเครื่องที่ห้องครัว

- ในกรณีข้างต้นให้ติดฉนวนกันความร้อนเพิ่มทุกตำแหน่งที่ต้องสัมผัสกับสถานะความชื้นสูงของเครื่องปรับอากาศในกรณีนี้ ให้จัดเตรียมแผ่นด้านข้าง (ช่องตรวจสอบ) เพื่อให้สามารถถอดออกได้ง่าย
- ใช้ฉนวนกันความร้อนให้พอดีกับท่อลมและชิ้นส่วนเชื่อมต่อของท่อลม





[ข้อมูลอ้างอิง]	สภาพการทดสอบการเกิดหยดน้ำ
ด้านเครื่องภายใน:	อุณหภูมิกระเปาะแห้ง 27 °C อุณหภูมิกระเปาะเปียก 24 °C
ปริมาณอากาศ:	ปริมาณอากาศต่ำ เวลาทำงาน 4 ชั่วโมง

■ พื้นที่ติดตั้ง

(หน่วย: mm)

สำรวจพื้นที่ว่างให้เพียงพอสำหรับการติดตั้งหรืองานซ่อมบำรุง

พื้นที่ว่างที่ต้องใช้สำหรับการติดตั้งและซ่อมบำรุง



※1 หากมีพื้นที่ว่างเพียงพอได้ตัวเครื่อง (มากกว่า 1000 mm) ประตูลงซ่อมบำรุง (ช่องเพดาน) จะไม่มีความจำเป็น

■ การตั้งค่าระยะเวลาสัญญาณเตือนการทำความสะอาดแผ่นกรอง

สามารถเปลี่ยนการตั้งค่าระยะเวลาแสดงสัญญาณเตือนทำความสะอาดของแผ่นกรอง (การแจ้งเตือนทำความสะอาดแผ่นกรอง) ของรีโมทคอนโทรลได้ ตามเงื่อนไขการติดตั้ง สำหรับวิธีการตั้งค่า โปรดดู “การตั้งค่าสัญญาณแจ้งเตือนแผ่นกรอง” ในการควบคุมการใช้งานจากคู่มือเล่มนี้

4 การติดตั้ง


⚠️ ข้อควรระวัง

โปรดปฏิบัติตามกฎต่อไปนี้เป็นอย่างเคร่งครัดเพื่อป้องกันความเสียหายที่จะเกิดกับตัวเครื่องภายในและเพื่อป้องกันผู้ใช้งานการได้รับบาดเจ็บ

- ห้ามวางของแข็งบนตัวเครื่องภายในหรือให้ผู้ใดเป็นขึ้นไป (แม้ตัวเครื่องจะยังอยู่ในกล่องก็ตาม)
- หากเป็นไปได้ ให้ยกตัวเครื่องภายในที่ยังบรรจุอยู่ในกล่อง หากต้องยกตัวเครื่องภายในที่ไม่ได้บรรจุในกล่อง ให้ห่อหุ้มด้วยผ้ากันกระแทกหรือวัสดุอื่นๆ เพื่อไม่ให้ตัวเครื่องเสียหาย
- หากต้องการเคลื่อนย้ายตัวเครื่องภายใน ให้จับที่เป็นยึด (4 ตำแหน่ง) เท่านั้น ห้ามใช้แรงกดบนชิ้นส่วนต่างๆ (เช่น ท่อสารทำความเย็น ถาดรับน้ำทิ้ง ชิ้นส่วนที่เป็นโฟม หรือชิ้นส่วนที่เป็นยาง)
- ใช้คน 4 คนหรือมากกว่าเพื่อยกกล่อง และห้ามใช้สายรัดพลาสติกรัดตำแหน่งอื่นนอกเหนือจากที่ระบุไว้
- เพื่อที่จะทำการติดตั้งวัสดุลดแรงสั่นสะเทือนเข้ากับสลักสำหรับแขวน ควรตรวจสอบให้แน่ใจว่าจะไม่เพิ่มความสั่นให้กับตัวเครื่อง

■ ขนาดภายนอก

(หน่วย: mm)



■ การติดตั้งสลักสำหรับแขวน

- ขณะที่ทำการกำหนดตำแหน่งและทิศทางที่จะแขวนตัวเครื่องภายใน ควรพิจารณาเรื่องการวางท่อ/ การเดินสายไฟ หลังแขวนตัวเครื่องด้วย
- หลังกำหนดตำแหน่งที่จะทำการติดตั้งตัวเครื่องภายในได้แล้ว ให้ติดตั้งสลักสำหรับแขวน
- สำหรับขนาดของช่องสำหรับสลักแขวน โปรดอ้างอิงกับมุมมองภายนอก
- หากใช้ฝ้าเพดานที่มีอยู่เดิม ให้วางท่อระบายน้ำ ท่อสารทำความเย็น สายควบคุมและสายไฟของรีโมทคอนโทรลไว้ใกล้ตำแหน่งการเชื่อมต่อ ก่อนที่จะทำการแขวนตัวเครื่องภายใน

หาซื้อแหวนรองของสลักสำหรับแขวนและน็อตสำหรับการติดตั้งตัวเครื่องภายใน (ชิ้นส่วนเหล่านี้ไม่ได้ให้มาด้วย)

สลักสำหรับแขวน	M10 หรือ W3/8	4 ชิ้น
น็อต	M10 หรือ W3/8	12 ชิ้น
แหวนรอง	M10	8 ชิ้น

การติดตั้งสลักสำหรับแขวน

ใช้สลักสำหรับแขวน M10 (4 ชิ้น ให้มาเฉพาะส่วน) จัดให้เข้ากับโครงสร้างที่มี แล้วจัดตำแหน่งตามขนาดในมุมมองภายนอกของตัวเครื่องดังที่แสดงด้านล่างนี้


แผ่นคอนกรีตใหม่	
ติดตั้งสลักด้วยแป้นยึดแบบสอดหรือสลักเกลียวสวม	
(แป้นยึดแบบยาว)	(แป้นยึดชนิดเลื่อนได้)
สลักเกลียวสวมที่ใช้แขวนท่อ	
โครงสร้างเหล็ก	
ใช้มุมที่มีอยู่หรือติดตั้งมุมเสริมใหม่	
สลักสำหรับแขวน	มุมเสริม
แผ่นคอนกรีตที่มีอยู่เดิม	
ใช้สลักแบบสมอที่มีรู ปลั๊กเสียบที่มีรู หรือสลักที่มีรู	

■ การติดตั้งเครื่องภายใน

การดูแลรักษาฝ้าเพดาน


ฝ้าเพดานจะแตกต่างกันไปตามโครงสร้างตึก ปรีक्षाผู้รับเหมาหรือผู้รับเหมาตกแต่งภายในสำหรับรายละเอียด หลังจากนำฝ้าเพดานออกแล้ว ควรหนุนฐานเพดาน (กรอบ) และรักษาระดับแนวนอนของเพดานที่ติดตั้งไว้ให้ถูกต้อง เพื่อป้องกันการสะเทือนของฝ้าเพดาน

- ชั้นน็อตและแหวนรองแบบ M10 เข้ากับสลักสำหรับแขวน
- วางแหวนรองที่จุดขึ้นและลงของแป้นยึดสำหรับแขวนของตัวเครื่องภายในเพื่อแขวนตัวเครื่องภายใน
- ตรวจสอบว่าทั้งสี่ด้านอยู่ในแนวนอนโดยใช้เกจวัดระดับ (องศาแนวนอน: ภายใน 5 mm)




ข้อกำหนด

- แขวนตัวเครื่องในตำแหน่งแนวนอน เมื่อแขวนตัวเครื่องเอียง อาจทำให้ช่องระบายน้ำล้น
- ติดตั้งตัวเครื่องภายในขอบเขตตามภาพด้านล่าง
- ใช้เกจวัดระดับเพื่อตรวจสอบยืนยันว่าตัวเครื่องถูกแขวนอยู่ในแนวนอนหรือไม่



ติดตั้งด้านของการเชื่อมต่อท่อระบายน้ำให้ต่ำกว่าด้านตรงข้ามไม่เกิน 5 mm




ติดตั้งด้านของคูดอากาศหรือด้านช่องปล่อยอากาศให้ชิดกันไม่เกิน 5 mm

■ ข้อกำหนด

การนำแผ่นกันกระแทกออกเพื่อการเคลื่อนย้าย

- ให้แน่ใจว่าได้ถอดแผ่นกันกระแทกออกป้องกันสำหรับการเคลื่อนย้ายที่สอดคล้องในช่องว่างระหว่างโครงด้านบนและตัวแลกเปลี่ยนความร้อน




5 การต่อท่อน้ำทิ้ง

⚠ ข้อควรระวัง

ต่อท่อระบายน้ำโดยปฏิบัติตามคู่มือการติดตั้งเพื่อให้น้ำไหลออกไปได้อย่างเหมาะสม ใช้ฉนวนกันความร้อนเพื่อไม่ให้เกิดหยดน้ำ การวางท่อที่ไม่เหมาะสมอาจมีผลทำให้น้ำรั่วภายในห้องและเพอร์นิเจอร์เปียกได้

- ห้ามฉนวนกันความร้อนให้กับท่อน้ำทิ้งภายในอย่างเหมาะสม
- ห้ามฉนวนกันความร้อนให้กับจุดที่ท่อเชื่อมต่อกับตัวเครื่องภายใน การห้ามฉนวนกันความร้อนอย่างไม่เหมาะสมจะทำให้เกิดการก่อตัวของหยดน้ำ
- ท่อน้ำทิ้งต้องลาดเอียงลง (ที่มุม 1/100 ขึ้นไป) และห้ามเดินท่อขึ้นและลง (รูปทรงแบบโค้ง) หรือทำให้เกิดการดักน้ำ การกระทำดังกล่าวอาจทำให้เกิดเสียงดังผิดปกติ
- จำกัดความยาวของท่อน้ำทิ้งที่พาดขวางอยู่ที่ 20 m หรือน้อยกว่า สำหรับท่อยาว ให้ติดตั้งโครงยึดที่ระยะห่าง 1.5 ถึง 2 m เพื่อป้องกันการส่าย
- ติดตั้งชุดท่อระบายน้ำตามที่แสดงในรูปภาพด้านล่าง
- ห้ามไม่ให้มีช่องลม มีฉนวนที่ระบายจะทะลักและเป็นสาเหตุของน้ำรั่วไหล
- ห้ามใช้แรงกดไปที่บริเวณเชื่อมต่อกับท่อน้ำทิ้ง



■ วัสดุของท่อ ขนาด และฉนวนกันความร้อน

วัสดุดังต่อไปนี้มีจำหน่ายทั่วไปสำหรับงานวางท่อและขั้นตอนการหุ้มฉนวน


วัสดุของท่อ	ท่อโวนิลคลอไรด์แบบแข็ง VP25 (เส้นผ่านศูนย์กลางรอบนอกที่ตั้งไว้ 32 mm)
ฉนวนกันความร้อน	โพลีโพลีเอธิลีน ความหนา: 10 mm หรือมากกว่า

■ การต่อท่อระบายน้ำ

สอดท่ออ่อนระบายน้ำเข้าไปในท่อน้ำทิ้งของตัวเครื่องหลักให้ลึกที่สุดเท่าที่ทำได้ ยึดให้แน่นด้วยสายรัดท่อ

ข้อกำหนด

ติดตั้งท่ออ่อนระบายน้ำด้วยการใช้สายรัดท่อโดยไม่ต้องใช้กาว



■ การต่อท่อระบายขึ้น


เมื่อติดตั้งชุดปั๊มระบายน้ำ (TCB-DP40DPE) ของอุปกรณ์เสริม โปรดอ่านคู่มือการติดตั้งที่นำมาพร้อมกับชุดปั๊มระบายน้ำ

■ การตรวจสอบการระบายน้ำ

ตรวจสอบว่าน้ำสามารถไหลออกได้ดีในระหว่างการทดสอบการทำงาน นอกจากนี้ให้ตรวจสอบว่าไม่มีน้ำรั่วไหลจากช่องเชื่อมต่อของท่อ


ข้อกำหนด

- ดำเนินการทดสอบการระบายน้ำ ถึงแม้ว่าอยู่ในช่วงหน้าร้อน
- หากทำการทดสอบก่อนงานต่อท่อลม ให้เทน้ำลงในถาดน้ำทิ้งผ่านช่องลมออก
- หากทำการทดสอบหลังจากงานต่อท่อลม ให้ถอดแผงปิดช่องทางเข้าออกและเทน้ำ จากนั้นให้ดำเนินการตรวจสอบการระบายน้ำ




■ ขั้นตอนการใช้ฉนวนกันความร้อน

- ควรคลุมท่ออ่อนและสายรัดท่อด้วยฉนวนกันความร้อน ตั้งแต่ด้านบนจนถึงด้านล่างของตัวเครื่องภายในให้สนิท ดังที่แสดงในภาพ
- คลุมท่อระบายให้สนิทด้วยฉนวนกันความร้อนที่หนา เพื่อให้ทับกันกับฉนวนกันความร้อนที่ติดอยู่บริเวณที่เชื่อมต่อ



■ วิธีการเชื่อมต่อท่อ




⚠️ ข้อควรระวัง



การหุ้มฉนวนกันความร้อนของหน้าแปลนท่อลมเย็นและการกันรั่วที่ไม่สมบูรณ์อาจทำให้เกิดหยดน้ำและทำให้น้ำหยดลง

■ คุณลักษณะการทำงานของพัดลม

ประเภท 072H



ประเภท 096H



6 การออกแบบท่อลม


■ การออกแบบท่อลม

- 1 เพื่อป้องกันไม่ให้เกิดการลัดวงจร ให้ทำการออกแบบท่อลมเพื่อให้ช่องเปิดรับลมเข้าหรือลมออกไม่ประกบชิดกัน
- 2 ตัวเครื่องภายในไม่มีแผ่นกรองอากาศชนิดติดตั้งมาให้ ให้ติดตั้งแผ่นกรองอากาศ (หาได้ทั่วไป) ในตำแหน่งที่สามารถทำการดูแลรักษาได้ง่าย เช่น ด้านหลังตะแกรงลมเข้า (หากไม่มีแผ่นกรองอากาศติดตั้ง ฝุ่นละอองจะสะสมอยู่ในเครื่องแลกเปลี่ยนความร้อน ซึ่งจะเป็นสาเหตุให้เครื่องปรับอากาศทำงานล้มเหลวหรือรั่วไหล)

<โครงสร้างของการเชื่อมต่อท่อลม>

หมายเหตุ

ชิ้นส่วนต่างๆ ยกเว้นหน่วยเครื่องปรับอากาศที่ต้องหาซื้อ






■ การจัดเตรียม

โปรดอ้างอิงขนาดต่อไปนี้ จัดทำท่อลมในสถานที่ติดตั้ง


(หน่วย: mm)

(ความหนาของแผ่น : 0.8 mm)

<ช่องลมออก>



<ช่องลมเข้า>



7 การต่อท่อส่งสารทำความเย็น

■ การต่อท่อส่งสารทำความเย็น

- ใช้ท่อทองแดงทั่วไปที่มีความหนาของผนัง 0.8 mm สำหรับ Ø12.7 mm และความหนาของผนัง 1.0 mm สำหรับ Ø22.2 mm (แข็งครึ่ง)
ห้ามใช้ท่อทองแดงที่มีความหนาน้อยกว่าความหนาตามที่ระบุไว้
- แฟรันทและงานขยายท่อมีความแตกต่างจากงานท่อสำหรับสารทำความเย็นปกติ
ถอดแฟรนต์ที่ติดตั้งอยู่กับตัวเครื่องหลักของเครื่องปรับอากาศและใช้แฟรนต์ดังกล่าว

ข้อกำหนด

หากท่อส่งสารทำความเย็นยาว ให้ใช้สกรูยึดที่ระยะทุก 2.5 ถึง 3 m เพื่อยึดให้ท่อส่งสารทำความเย็นแน่นขึ้น มิฉะนั้นอาจทำให้เกิดเสียงผิดปกติได้

⚠ ข้อควรระวัง

จุดวางท่อที่สำคัญ 4 แห่ง

- ขจัดฝุ่นและความชื้นออกจากด้านในของท่อเชื่อมต่อ
- จุดเชื่อมต่อที่ขึ้นแน่น (ระหว่างท่อและตัวเครื่อง)
- โล่อากาศที่อยู่เหนือท่อโดยใช้มีมส์สุญญากาศ
- ตรวจสอบการรั่วไหลของก๊าซ (จุดเชื่อมต่อ)

■ ขนาดท่อ

(หน่วย : mm)

ขนาดเส้นผ่านศูนย์กลางภายนอก	ด้านก๊าซ	22.2 mm
	ด้านของเหลว	12.7 mm

■ การต่อท่อส่งสารทำความเย็นด้านของเหลว


ความยาวของท่อที่ได้รับอนุญาตและความแตกต่างของความสูง

ทั้งสองอย่างผันแปรตามตัวเครื่องภายนอก โปรดอ้างอิงคู่มือการติดตั้งที่เามาพร้อมกับตัวเครื่องภายนอก

การขยายท่อ

- ตัดท่อด้วยเครื่องมือตัดท่อ
กำจัดขุยออกให้หมด
หากมีส่วนขุยติดอยู่อาจทำให้ก๊าซรั่วได้
- สอดแฟรนต์เข้าไปในท่อแล้วขยายท่อ
ขนาดการขยายท่อของ R410A มีความแตกต่างจากท่อของสารทำความเย็น R22 แนะนำให้ใช้ชุดขยายท่อที่ผลิตขึ้นมาใหม่สำหรับ R410A

อย่างไรก็ตามคุณสามารถใช้เครื่องมือแบบดั้งเดิมได้โดยปรับส่วนที่ยื่นออกมาของท่อทองแดง



▼ ขอบเขตการขยายท่อ : B (หน่วย : mm)


RIDGID (แบบก้ามปู)

เส้นผ่านศูนย์กลางภายนอกของท่อทองแดง	ใช้เครื่องมือ R410A	เครื่องมือเดิมที่ใช้
	12.7	0 ถึง 0.5

▼ ขนาดเส้นผ่านศูนย์กลางของการขยายท่อ: A (หน่วย : mm)

เส้นผ่านศูนย์กลางภายนอกของท่อทองแดง	A $^{+0.02}$ (-0.4)
	12.7

* ในกรณีการขยายท่อสำหรับ R410A ด้วยเครื่องมือแบบเดิม ให้ดึงท่อออกมาจาก R22 ประมาณ 0.5 mm เพื่อปรับให้มีขนาดตามที่ระบุ
ควรใช้เกจวัดท่อทองแดงในการปรับขอบเขต



การเชื่อมต่อแบบขันแน่น

⚠ ข้อควรระวัง

ห้ามใช้แรงบิดมากเกินไป มิฉะนั้นน็อตอาจแตกได้ โดยขึ้นอยู่กับสภาพต่างๆ

(หน่วย: N·m)

เส้นผ่านศูนย์กลางภายนอกของท่อทองแดง	แรงบิด
12.7 mm (เส้นผ่านศูนย์กลาง)	50 ถึง 62 (5.0 ถึง 6.2 kgf·m)

▼ แรงบิดในการขันแน่นการต่อท่อแบบปลายบาน

แรงดันของท่อ R410A สูงกว่า R22 (ประมาณ 1.6 เท่า) ดังนั้นใช้ประแจวัดแรงบิดขันแน่นการต่อท่อแบบปลายบานที่เชื่อมต่อตัวเครื่องภายในกับตัวเครื่องภายนอกตามค่าแรงบิดที่กำหนด
การเชื่อมต่อที่ไม่ถูกต้อง นอกจากจะก่อให้เกิดการรั่วไหลของก๊าซแล้วยังก่อให้เกิดข้อผิดพลาดของวงจรการทำความเย็น วงจรศูนย์กลางของท่อเชื่อมต่อให้ตรงกันแล้วใช้มีมส์ขันแฟรนต์ให้แน่นที่สุด จากนั้นใช้ประแจและประแจทอร์กขันน็อตให้แน่นตามที่แสดงในภาพ

ข้อต่อทองเหลืองแบบฮาฟยูเนียน




ใช้ประแจในการยึด ใช้ประแจวัดแรงบิดในการขันแน่น

ข้อกำหนด

การขันน็อตโดยใช้แรงมากเกินไปอาจทำให้น็อตแตกขึ้นอยู่กับลักษณะการติดตั้ง
ขันแน่นน็อตโดยใช้แรงบิดตามที่กำหนด

■ การต่อท่อส่งสารทำความเย็นด้านก๊าซ


- หมุนจนวนกันความร้อนของท่อขึ้นไปทีด้านตัวเครื่อง
- ท่อหุ้มท่อด้วยผ้าเปียก



- ถอดถ้วยที่ท่อด้านก๊าซด้วยการใช้เครื่องมือเชื่อม

⚠ ข้อควรระวัง

- ห้ามทำให้ฉนวนกันความร้อนของท่อไหม้
- โปรดระวังเปลวไฟจากขั้นตอนการเชื่อมบนเพดาน



- เชื่อมต่อเชื่อมต่อเข้ากับชิ้นส่วนข้อต่อ



- หมุนจนวนกันความร้อนของทอกลับและมัดด้วยสายรัด



การวางท่อกับตัวเครื่องภายนอก

สำหรับรายละเอียด ให้อ้างอิงคู่มือการติดตั้งที่แนบมากับตัวเครื่องภายนอก

■ การระบายอากาศออก

ใช้มีมส์สุญญากาศในการไล่อากาศออกจากช่องเติมของวาล์วของตัวเครื่องภายนอก
โปรดอ้างอิงคู่มือการติดตั้งที่เามาพร้อมกับตัวเครื่องภายนอก

ข้อกำหนด

สำหรับเครื่องมือต่างๆ เช่น ท่อเติมสารทำความเย็น ฯลฯ ให้ใช้เฉพาะที่ผลิตมาเพื่อ R410A เท่านั้น

ปริมาณสารทำความเย็นที่จะเติม

สำหรับการเติมสารทำความเย็น ให้เติมสารทำความเย็น “R410A” โดยอ้างอิงคู่มือการติดตั้งที่ให้มาพร้อมกับตัวเครื่องภายนอก

ใช้เครื่องชั่งในการอัดสารทำความเย็นในปริมาณที่กำหนด

ข้อกำหนด

- การอัดสารทำความเย็นในปริมาณที่มากเกินไปหรือน้อยเกินไปจะเป็นสาเหตุให้คอมเพรสเซอร์มีปัญหาให้อัดสารทำความเย็นในปริมาณที่กำหนด
- บุคคลที่ทำการอัดสารทำความเย็นควรจัดบันทึกความยาวของท่อและปริมาณของสารทำความเย็นที่เติมลงบนฉลาก F-GAS ของตัวเครื่องภายนอก จำเป็นต้องชั่งคอมเพรสเซอร์และความผิดปกติของวงจรทำความเย็น

เปิดวาล์วให้สุด

ควรเปิดวาล์วตัวเครื่องภายนอกให้สุด

ต้องใช้ประแจหกเหลี่ยม 4 mm ในการเปิดวาล์วด้านของเหลว

โปรดอ้างอิงคู่มือการติดตั้งที่ให้มาพร้อมกับตัวเครื่องภายนอก

การตรวจสอบก๊าซรั่ว

ตรวจสอบด้วยเครื่องตรวจจับการรั่วหรือน้ำสบู่ว่าก๊าซรั่วหรือไม่จากส่วนต่อเชื่อมของท่อหรือฝาครอบของวาล์ว

ข้อกำหนด

ใช้เครื่องตรวจจับการรั่วที่ผลิตเฉพาะเพื่อใช้กับสารทำความเย็น HFC เท่านั้น (R410A, R134a)


ขั้นตอนการใช้ฉนวนกันความร้อน

ใช้ท่อฉนวนกันความร้อนแยกกันระหว่างด้านของเหลวและด้านก๊าซ

- สำหรับการหุ้มฉนวนกันความร้อนให้ทับท่อที่ด้านก๊าซ ให้แน่ใจว่าได้ใช้วัสดุที่ทนต่อความร้อนอุณหภูมิ 120°C ขึ้นไป
- ควรใช้ท่อฉนวนกันความร้อนที่หุ้ม โดยหุ้มฉนวนกันความร้อนเข้ากับส่วนต่อเชื่อมของตัวเครื่องภายในให้แน่นโดยไม่ให้มีช่องว่าง

ข้อกำหนด

- หุ้มฉนวนกันความร้อนเข้ากับส่วนต่อเชื่อมของตัวเครื่องภายในให้แน่นจนถึงปลายโดยหุ้มให้สนิท (ท่อที่เปิดออกจะทำให้มีน้ำรั่วออกมา)
- ควรห่อหุ้มฉนวนกันความร้อนโดยให้รอยกรีดหงายขึ้น (ด้านเพดาน)



8 การต่อสายไฟ

⚠ คำเตือน

- ใช้สายไฟที่กำหนดในการเชื่อมต่อขั้วต่างๆ ยึดให้แน่น เพื่อป้องกันแรงที่กระทำต่อสายไฟจากภายนอก** การเดินสายไฟที่ไม่สมบูรณ์หรือการตัดแปลง อาจทำให้เกิดเพลิงไหม้หรือปัญหาอื่นๆ ได้
- ต่อสายดิน (งานสายกราวด์)** การต่อสายดินที่ไม่ถูกต้องอาจก่อให้เกิดไฟฟ้าลัดวงจรได้ ห้ามต่อสายดินกับท่อก๊าซ ท่อน้ำ สายล่อฟ้า หรือสายดินของโทรศัพท์
- ควรติดตั้งเครื่องใช้ไฟฟ้าตามกฎหมายการเดินสายไฟของประเทศนั้นๆ** วงจรไฟฟ้าที่ไม่มีกำลังเพียงพอหรือการติดตั้งที่ไม่สมบูรณ์ อาจก่อให้เกิดไฟฟ้าช็อตหรือเพลิงไหม้ได้

⚠ ข้อควรระวัง

- สำหรับสายสื่อสาร ให้ใช้สายไฟชนิดเดียวกันและขนาดเดียวกัน หากสายไฟแต่ละสายมีชนิดและขนาดที่แตกต่างกัน จะทำให้เกิดปัญหาการสื่อสารได้**
- หากเดินสายไฟอย่างไม่ถูกต้องหรือไม่สมบูรณ์ จะทำให้เกิดการติดไหม้หรือควันไฟได้
- ติดตั้งเบรกเกอร์ป้องกันสายดินรั่วชนิดที่ไม่ตัดการทำงานจากกระแสเกินอันเนื่องมาจากคลื่นกระแทก หากไม่ได้ติดตั้งเบรกเกอร์ป้องกันสายดินรั่ว อาจก่อให้เกิดไฟฟ้าช็อตได้
- ใช้ตัวยึดสายไฟให้เข้ากับผลิตภัณฑ์
- เมื่อปกอสายไฟหรือสายไฟเชื่อมระบบ ระวังอย่าขูดขีดหรือทำลายแกนตัวนำไฟฟ้าและฉนวนหุ้มด้านใน
- ใช้สายไฟของแหล่งจ่ายไฟและสายควบคุมที่มีความหนาประเภทและอุปกรณ์ป้องกันตามที่กำหนด
- ห้ามต่อไฟฟ้าที่มีกำลัง 220V เข้ากับบล็อกขั้วต่อ (Uv (U1)), (Uv (U2)), (A), (B) (มีฉนวน ระบบอาจเกิดความเสียหายได้)
- ทำการเดินสายไฟเพื่อไม่ให้สายไฟสัมผัสผิวฉนวนของท่อที่มีอุณหภูมิสูง ส่วนที่เคลือบสายไฟอาจจะละลายและทำให้เกิดอุบัติเหตุได้

ข้อกำหนด

- สำหรับการเดินสายไฟของแหล่งจ่ายไฟ โปรดปฏิบัติตามข้อบังคับในท้องถิ่นของแต่ละประเทศอย่างเคร่งครัด
- สำหรับการเดินสายไฟของแหล่งจ่ายไฟตัวเครื่องภายนอก โปรดปฏิบัติตามคู่มือการติดตั้งของตัวเครื่องภายนอกแต่ละเครื่อง
- หลังจากที่ได้เชื่อมต่อสายไฟเข้ากับบล็อกขั้วต่อแล้ว ให้ใช้ท่อพักน้ำและยึดสายไฟด้วยตัวยึดสายไฟ
- เดินสายท่อสารทำความเย็นและสายควบคุมในสายเดียวกัน
- อย่าเพิ่งเปิดตัวเครื่องภายในจนกว่าจะใส่อากาศในท่อส่งสารทำความเย็น

■ คุณสมบัติของสายไฟของแหล่งจ่ายไฟและสายสื่อสาร

สายไฟของแหล่งจ่ายไฟและสายสื่อสารสามารถหาซื้อได้ทั่วไป สำหรับคุณสมบัติของแหล่งจ่ายไฟ โปรดปฏิบัติตามตารางดังต่อไปนี้ หากความจุมีน้อยจะทำให้เกิดอันตราย เนื่องจากอาจก่อให้เกิดความร้อนมากเกินไปหรือหมดกำลังไฟ สำหรับคุณสมบัติของความจุกำลังไฟของตัวเครื่องภายนอกและสายของแหล่งจ่ายไฟ ให้อ้างอิงคู่มือการติดตั้งที่ให้มาพร้อมกับตัวเครื่องภายนอก

แหล่งจ่ายไฟของตัวเครื่องภายใน

- สำหรับแหล่งจ่ายไฟของตัวเครื่องภายใน ให้เตรียมแหล่งจ่ายไฟแยกออกมาโดยเฉพาะจากตัวเครื่องภายนอก
- จัดเตรียมแหล่งจ่ายไฟ เครื่องตัดกระแสไฟฟ้าและสวิตช์หลักของตัวเครื่องภายในที่เชื่อมต่อกับตัวเครื่องภายนอกตัวเดียวกันเพื่อให้สามารถใช้งานได้ทั่วไป
- คุณสมบัติของสายไฟของแหล่งจ่ายไฟ: สายไฟแบบ 3 แกน 2.5 mm², สอดคล้องกับแบบ 60245 IEC 57

▼ แหล่งจ่ายไฟ

แหล่งจ่ายไฟ	220V ~, 50 Hz	
ควรเลือกสวิตช์แหล่งจ่ายไฟ/เครื่องตัดกระแสไฟฟ้าหรือสายไฟของแหล่งจ่ายไฟ/พิกัดพิวส์สำหรับตัวเครื่องภายใน โดยใช้ค่ากระแสไฟโดยรวมที่สะสม		
สายไฟของแหล่งจ่ายไฟ	ต่ำกว่า 20 m	2.5 mm ²
	ต่ำกว่า 50 m	4.0 mm ²

สายควบคุม สายตัวควบคุมกลาง

- สายไฟไม่มีขั้วแบบ 2 แกน ใช้สำหรับการต่อสายควบคุมระหว่างตัวเครื่องภายในและตัวเครื่องภายนอก รวมถึงสายตัวควบคุมกลาง
- เพื่อป้องกันปัญหาเรื่องเสียงรบกวน ให้ใช้สายชีลด์แบบ 2 แกน
- ความยาวของสายสัญญาณ หมายถึง ความยาวรวมของความยาวสายไฟอุปกรณหลายตัวระหว่างตัวเครื่องภายในและภายนอก เสริมด้วยความยาวสายไฟของระบบควบคุมกลาง

▼ สายสัญญาณ

สายไฟ U _v และสายไฟ U _c (L2, L3, L4) (สายชีลด์แบบ 2 แกน ไม่มีขั้ว)	ขนาดสายไฟ:	0.5 mm ² (สูงสุด 500 m) 0.75 ถึง 1.25 mm ² (สูงสุด 1000 m)
สายไฟ U _h (L1) (สายชีลด์แบบ 2 แกน ไม่มีขั้ว)	ขนาดสายไฟ:	0.75 ถึง 1.25 mm ² (สูงสุด 1000 m) 2.0 mm ² (สูงสุด 2000 m)

- สายไฟ U (v, h, c) หมายถึง สายควบคุม
 - สายไฟ U_v : ระหว่างตัวเครื่องภายในและภายนอก
 - สายไฟ U_h : สายควบคุมกลาง
 - สายไฟ U_c : ระหว่างตัวเครื่องภายนอกและภายนอก
- สายไฟ U_v และสายไฟ U_c เป็นอิสระจากท่อส่งสารทำความเย็น ความยาวรวมของสายไฟ U_v และสายไฟ U_c (L3+L4) ในท่อส่งสารทำความเย็นแต่ละท่อ สูงสุด 1000 m


[สายไฟ U_h]

L1 = สูงสุด 2000 m

[สายไฟ U_v และ U_c]

L2 = สูงสุด 1000 m

(L3+L4) = สูงสุด 1000 m




การเดินสายไฟรีโมทคอนโทรล

- สายไฟไม่มีขั้วแบบ 2 แกน ใช้สำหรับการเดินสายไฟรีโมทคอนโทรลและเดินสายไฟรีโมทคอนโทรลแบบเป็นกลุ่ม

การเดินสายไฟรีโมทคอนโทรล, การเดินสายไฟรีโมทคอนโทรลที่ควบคุมอุปกรณ์หลายตัว	ขนาดสายไฟ: 0.5 mm ² ถึง 2.0 mm ²	
ความยาวสายไฟรวมของการเดินสายไฟรีโมทคอนโทรลและการเดินสายไฟรีโมทคอนโทรลที่ควบคุมอุปกรณ์หลายตัว = L + L1 + L2 + ... Ln	ในกรณีของชนิดสายไฟ	สูงสุด 500 m
	ในกรณีรวมชนิดไร้สาย	สูงสุด 400 m
ความยาวสายไฟรวมของการเดินสายไฟรีโมทคอนโทรลที่ควบคุมอุปกรณ์หลายตัว = L1 + L2 + ... Ln	สูงสุด 200 m	

⚠ ข้อควรระวัง

- ไม่ควรเดินสายไฟรีโมทคอนโทรล (สายสัญญาณ) และสายไฟ AC 220V เข้าด้วยกันให้อยู่ชิดและสัมผัสต่อกัน รวมทั้งไม่ควรเก็บสายไฟทั้งสองในท่อร้อยสายเดียวกัน หากทำเช่นนั้น อาจทำให้เกิดข้อผิดพลาดในการทำงานของระบบควบคุมอันเนื่องมาจากเสียงรบกวนหรือปัจจัยอื่น




■ การเดินสายไฟระหว่างตัวเครื่องภายในและตัวเครื่องภายนอก

หมายเหตุ

- ตัวเครื่องภายนอกที่เชื่อมต่อระหว่างกันกับตัวเครื่องภายในจะกลายเป็นตัวเครื่องหลักโดยอัตโนมัติ

▼ ตัวอย่างการเดินสายไฟ





■ การต่อสายไฟ

ข้อกำหนด

- เชื่อมต่อต่อสายไฟเข้ากับหมายเลขขั้วต่อที่ถูกต้อง หากต่อผิดอาจเกิดข้อผิดพลาดได้
- เดินสายไฟผ่านปลอกของช่องการเชื่อมต่อสายไฟของตัวเครื่องภายในแล้ว
- เว้นระยะ (ประมาณ 100 mm) บนสายไฟเพื่อห้อยกล่องควบคุมไฟฟ้าสำหรับการซ่อมบำรุง หรือวัดอุณหภูมิอื่น
- วงจรไฟฟ้ากำลังด้านนั้นมีไว้สำหรับรีโมทคอนโทรลแบบใช้สาย (อย่าต่อเข้ากับวงจรไฟฟ้ากำลังสูง)


- ก่อนทำการเดินสายไฟในกล่องควบคุมไฟฟ้า ให้ถอดฝาครอบของกล่องออก (ยึดไว้ด้วยสกรู 6 ตัว)
- ถอดสกรู A และคลายสกรู B
- ดึงฝาครอบของกล่องควบคุมไฟฟ้าขึ้น จากนั้นให้เปิดไปข้างหน้า
- ขันสกรูของบล็อกขั้วต่อให้แน่น และยึดสายไฟเข้ากับกล่องควบคุมไฟฟ้าด้วยตัวยึดสายไฟ (อย่าให้เกิดการดึงของสายไฟในส่วนที่ต่อกับบล็อกขั้วต่อ)
- ติดตั้งฝาครอบกล่องควบคุมไฟฟ้าโดยไม่ให้ขยับสายไฟ (ยึดไว้ด้วยสกรู 6 ตัว)
- ใช้วัสดุกันรั้วที่นำมาทำการกันรั้วที่ช่องเชื่อมต่อสายไฟ



เลือกด้าน C หรือ D สำหรับตำแหน่งตัวยึดสายไฟโดยอ้างอิงตารางต่อไปนี้ตามชนิดของสายไฟและเส้นผ่านศูนย์กลาง
* ติดตัวยึดสายที่ด้านซ้ายหรือด้านขวา
เมื่อเชื่อมต่อระบบแฟลต ให้ยึดสายไฟสองเส้นด้วยตัวยึดสายไฟตัวเดียว

ประเภทของสายไฟ	คุณสมบัติ	ตำแหน่งตัวยึดสายไฟ
สาย Cabtyre	สายไฟแบบเกลียว 3 แกน 2.5 mm ²	ด้าน D
สาย Cabtyre	สายไฟแบบเกลียว 4 แกน 1.5 mm ²	ด้าน C



※ ขั้วต่อ 3 และ 4 คือสายไฟหน่วยตัวเลือกการไหล



■ การเดินสายไฟรีโมทคอนโทรล

ปกกฉนวนสายไฟออก 9 mm เพื่อทำการเชื่อมต่อ

แผนผังการเดินสายไฟ



9 การควบคุมการใช้งาน

ข้อกำหนด

เมื่อใช้งานเครื่องปรับอากาศเป็นครั้งแรก ต้องใช้เวลาสักครู่หลังจากเปิดเครื่อง ก่อนที่รีโมทคอนโทรลจะพร้อมใช้งาน: ซึ่งเป็นเรื่องปกติและไม่ใช่อุปสรรคปัญหาใดๆ

- เกี่ยวกับที่อยู่อัดโน้มติ (ที่อยู่อัดโน้มติถูกตั้งค่าโดยการดำเนินการบนแผงจอร์อินเตอร์เฟซภายนอก) เมื่อตั้งค่าที่อยู่อัดโน้มติแล้วการทำงานของรีโมทคอนโทรลจะไม่สามารถทำงานได้ การตั้งค่าใช้เวลากว่า 10 นาที (โดยทั่วไปประมาณ 5 นาที)
- เมื่อเปิดเครื่องหลังจากที่ได้ทำการกำหนดที่อยู่อัดโน้มติแล้ว จะใช้เวลาถึง 10 นาที (โดยทั่วไปประมาณ 3 นาที) สำหรับตัวเครื่องภายนอกในการเริ่มการทำงานหลังจากที่ได้ทำการเปิดเครื่อง

ก่อนที่เครื่องปรับอากาศจะถูกส่งมาจากโรงงาน ตัวเครื่องทุกตัวถูกตั้งค่าเป็น [STANDARD] (มาตรฐาน) ให้เปลี่ยนการตั้งค่าตัวเครื่องภายใน หากจำเป็น

เปลี่ยนการตั้งค่าด้วยการใช้งานรีโมทคอนโทรลแบบมีสาย
 * ไม่สามารถเปลี่ยนการตั้งค่าได้โดยใช้รีโมทคอนโทรลแบบไร้สาย รีโมทคอนโทรลเพียงอย่างเดียวหรือสายรีโมทคอนโทรลแบบควบคุมกลุ่ม ดังนั้นให้ทำการติดตั้งรีโมทคอนโทรลแบบมีสายแยกออกมาด้วย


■ การตั้งค่าการควบคุมการใช้งาน (ตั้งค่าที่หน้างาน)

ขั้นตอนพื้นฐาน

ตรวจสอบให้แน่ใจว่าได้ปิดเครื่องปรับอากาศก่อนทำการตั้งค่า (เปลี่ยนแปลงการตั้งค่าขณะที่เครื่องปรับอากาศไม่ได้ทำงานอยู่)


⚠ ข้อควรระวัง

ตั้งค่าเฉพาะ Code No. ตามที่แสดงในตารางต่อไปนี้ ห้ามตั้งค่า Code No. อื่น หากตั้งค่า Code No. ที่ไม่ได้อยู่ในลิสต์ อาจทำให้ไม่สามารถใช้งานเครื่องปรับอากาศหรืออาจมีปัญหาคืออื่นเกิดขึ้นกับตัวเครื่อง



1 กดปุ่มเมนู [▽] และปุ่มตั้งค่าพร้อมกันค้างไว้ 10 วินาทีขึ้นไป


- หลังจากนั้น หน้าจอจะกะพริบตามที่แสดงในภาพ "ALL" แสดงขึ้นหน้าจอเป็นจำนวนของตัวเครื่องภายในระหว่างการสื่อสารเบื้องต้นทันทีหลังจากที่ได้เปิดเครื่องแล้ว



2 แต่ละครั้งที่กดปุ่มตั้งค่า [▽] [△] จำนวนของตัวเครื่องภายในในการควบคุมเป็นกลุ่มจะเปลี่ยนไปแบบหมุนรอบ เลือกตัวเครื่องภายในที่จะทำการเปลี่ยนการตั้งค่า

- พัดลมของตัวเครื่องภายในทำงานสามารถยืนยันตัวเครื่องภายในที่จะเปลี่ยนการตั้งค่า

3 กดปุ่มตั้งเวลา OFF เพื่อทำการยืนยันตัวเครื่องภายในที่เลือก



4 กดปุ่ม MENU เพื่อให้ Code No. [**] กะพริบ เปลี่ยน Code No. [**] ด้วยปุ่มตั้งค่า [▽] [△]

5 กดปุ่ม MENU เพื่อให้ SET DATA [****] กะพริบ เปลี่ยน SET DATA [****] ด้วยปุ่มตั้งค่า [▽] [△]

6 กดปุ่มตั้งเวลา OFF

- เมื่อทำตามนั้น การตั้งค่าเสร็จสมบูรณ์แล้ว หากต้องการเปลี่ยนแปลงการตั้งค่าอื่นๆ ของตัวเครื่องภายในที่เลือก ให้ทำซ้ำตั้งแต่ขั้นตอนที่ 4

7 เมื่อทำการตั้งค่าทุกอย่างเสร็จเรียบร้อยแล้ว ให้กดปุ่มเปิด/ปิดเครื่องเพื่อตรวจสอบการตั้งค่า "SETTING" จะกะพริบ จากนั้นเนื้อหาบนหน้าจอจะหายไป และเครื่องปรับอากาศจะเข้าสู่โหมดหยุดการทำงานตามปกติ (รีโมทคอนโทรลจะไม่สามารถสั่งงานได้ ขณะที่ "SETTING" กะพริบอยู่)

- หากต้องการเปลี่ยนแปลงการตั้งค่าตัวเครื่องภายในอื่นๆ ให้ทำซ้ำตั้งแต่ขั้นตอนที่ 1

■ การตั้งค่าแรงดันสถิตย์ภายนอก

โปรดอ้างอิง "คุณลักษณะการทำงานของพัดลม" ใน 6 การออกแบบพัดลม เพื่อทำการตั้งค่าแรงดันคงที่ภายนอก ตั้งค่าเปลี่ยนการแตะสัมผัสตามแรงดันคงที่ภายนอกของท่อลมที่จะเชื่อมต่อ ตั้งค่าเปลี่ยนการแตะสัมผัส โดยปฏิบัติตามขั้นตอนการทำงานพื้นฐาน (1 → 2 → 3 → 4 → 5 → 6)

- ให้ระบุ [5d] สำหรับ CODE No. ในขั้นตอนที่ 4
- สำหรับ SET DATA ในขั้นตอนที่ 5 เลือก SET DATA ของแรงดันคงที่ภายนอกที่จะทำการตั้งค่าตามตารางด้านล่างนี้


SET DATA	แรงดันคงที่ภายนอก	
0000	150 Pa	ค่าตั้งจากโรงงาน
0001	50 Pa	—
0002	83 Pa	—
0003	217 Pa	—
0004	117 Pa	—
0005	183 Pa	—
0006	250 Pa	—

รายการดังกล่าวใช้เมื่อ SW501-1 และ SW501-2 อยู่ที่ OFF หากการตั้งค่าไม่ถูกต้อง "P12" อาจปรากฏขึ้น บ่งบอกถึงข้อผิดพลาดของมอเตอร์พัดลม

<การตั้งค่าบนแผงวงจรของตัวเครื่องภายใน>

ใช้สวิตช์ DIP บนแผงวงจรของส่วนรับสัญญาณไร้สายเพื่อทำการตั้งค่าแรงดันคงที่ภายนอก

สำหรับรายละเอียด โปรดอ้างอิงคู่มือการใช้งานของชุดรีโมทคอนโทรลแบบไร้สาย หรือใช้สวิตช์บนแผงวงจรไมโครคอมพิวเตอร์ ภายในตามที่แสดงในภาพและตารางต่อไปนี้



SW501-1	ปิด	เปิด	ปิด	เปิด
SW501-2	ปิด	ปิด	เปิด	เปิด
SET DATA	ค่าตั้งจากโรงงาน	0001	0003	0006

รีเซ็ตเป็นค่าตั้งจากโรงงาน
 ปิดสวิตช์ SW501-1 และ SW501-2 เชื่อมต่อรีโมทคอนโทรลแบบมีสายที่จำหน่ายแยก จากนั้นให้ปฏิบัติตามขั้นตอนสำหรับการตั้งค่าแรงดันคงที่ภายนอกที่หน้านี้เพื่อตั้งค่า [5d] DATA เป็น "0000"

■ การตั้งค่าสัญญาณของแผ่นกรอง

ตามเงื่อนไขการติดตั้ง สามารถปรับเปลี่ยนระยะเวลาการแสดงผลสัญญาณของแผ่นกรอง (การแจ้งเตือนทำความสะอาดแผ่นกรอง) ได้ปฏิบัติตามขั้นตอนการทำงานพื้นฐาน (1 → 2 → 3 → 4 → 5 → 6 → 7)

- ให้ระบุ [01] สำหรับ CODE No. ในขั้นตอนที่ 4
- สำหรับ SET DATA ในขั้นตอนที่ 5 เลือก SET DATA ของระยะเวลาแสดงผลสัญญาณของแผ่นกรองจากตารางดังต่อไปนี้

SET DATA	ระยะเวลาแสดงผลสัญญาณของแผ่นกรอง
0000	ไม่มี
0001	150 H
0002	2500 H (ค่าตั้งจากโรงงาน)
0003	5000 H
0004	10000 H

- อาจไม่มีสัญญาณของแผ่นกรองซึ่งอยู่กับตัวรีโมทคอนโทรล

■ เซนเซอร์รีโมทคอนโทรล

เซนเซอร์วัดอุณหภูมิของตัวเครื่องภายในจะตรวจจับอุณหภูมิห้อง ตั้งค่าเซนเซอร์รีโมทคอนโทรลเพื่อทำการตรวจจับอุณหภูมิโดยรอบรีโมทคอนโทรล

เลือกรายการต่างๆ โดยปฏิบัติตามขั้นตอนการทำงานพื้นฐาน (1 → 2 → 3 → 4 → 5 → 6)

- ให้ระบุ [32] สำหรับ CODE No. ในขั้นตอนที่ 4
- เลือกข้อมูลดังต่อไปนี้สำหรับ SET DATA ในขั้นตอนที่ 5

SET DATA	0000	0001
เซนเซอร์รีโมทคอนโทรล	ไม่ใช้งาน (ค่าตั้งจากโรงงาน)	ใช้งาน

เมื่อ กะพริบ เซนเซอร์รีโมทคอนโทรลกำลังชำรุด เลือก SET DATA [0000] (ไม่ใช้งาน) หรือเปลี่ยนรีโมทคอนโทรล

■ การควบคุมแบบเป็นกลุ่ม

ในการควบคุมเป็นกลุ่ม รีโมทคอนโทรลหนึ่งตัวสามารถควบคุมได้สูงสุดถึง 16 ตัว

- รีโมทคอนโทรลแบบมีสายเท่านั้นที่สามารถควบคุมแบบเป็นกลุ่มได้ รีโมทคอนโทรลไร้สายไม่สามารถใช้การควบคุมแบบนี้ได้
- สำหรับขั้นตอนการเดินสายไฟและสายไฟของระบบสายอิสระ (ท่อส่งสารทำความเย็นแบบเดียวกัน) ให้อ้างอิงจาก "การต่อสายไฟ" ในคู่มือเล่มนี้
- ควรปฏิบัติตามขั้นตอนต่อไปนี้เมื่อต้องเดินสายไฟระหว่างตัวเครื่องภายในแบบเป็นกลุ่ม
- เชื่อมต่อตัวเครื่องภายในด้วยการเชื่อมต่อสายไฟ รีโมทคอนโทรลจากบล็อกขั้วต่อรีโมทคอนโทรล (A, B) ของตัวเครื่องภายในที่เชื่อมต่อกับรีโมทคอนโทรลเข้ากับบล็อกขั้วต่อรีโมทคอนโทรล (A, B) ของตัวเครื่องภายในตัวอื่น (ไม่มีขั้ว)
- สำหรับการกำหนดที่อยู่ ให้อ้างอิงคู่มือการติดตั้งที่ให้มาพร้อมกับตัวเครื่องภายนอก

10 การทดสอบการทำงาน

■ ก่อนทำการทดสอบการทำงาน

- ปฏิบัติตามขั้นตอนต่อไปนี้ ก่อนเปิดแหล่งจ่ายไฟ
 - ด้วยการใช้ชุดอุปกรณ์ทดสอบฉนวน (500VMD) ให้ตรวจสอบความต้านทานระดับ 1MΩ ขึ้นไปมีอยู่ระหว่างบล็อกขั้วต่อ L ถึง N และสายดิน (การต่อสายดิน) อย่าทำการเปิดใช้งานเครื่องปรับอากาศหากพบค่าความต้านทานต่ำกว่า 1 เมกะโอห์ม (MΩ)
 - ตรวจสอบว่าได้เปิดวาล์วของตัวเครื่องภายนอกออกจนสุดแล้ว
- เพื่อปกป้องคอมเพรสเซอร์ในขณะเปิดการทำงาน เปิดเครื่องให้ทำงาน 12 ชั่วโมงขึ้นไปก่อนการใช้งาน
- ก่อนเริ่มการทดสอบการทำงาน ให้กำหนดที่อยู่โดยปฏิบัติตามคู่มือการติดตั้งที่ให้มาพร้อมกับตัวเครื่องภายนอก

◆ ข้อกำหนดในการปิดตัวควบคุมอุณหภูมิ OFF

การทำความเย็น

- เมื่ออุณหภูมิของลมที่ดูดเข้า/ตัวเครื่องภายนอกต่ำกว่าหรือเท่ากับ 19°C
- เมื่ออุณหภูมิของลมที่ดูดเข้า/ตัวเครื่องภายนอกต่ำกว่าหรือเท่ากับ 3°C มากกว่าอุณหภูมิที่ตั้งค่า

■ ดำเนินการทดสอบการทำงาน

- เมื่อใช้การทำงานของพัดลมสำหรับตัวเครื่องภายในอิสระ ให้ปิดเครื่อง วงจรลัด CN72 บนแผงวงจร จากนั้นให้เปิดเครื่องอีกครั้ง (ตั้งค่าโหมดการทำงานเป็น “fan” เพื่อใช้งานตัวเครื่อง) เมื่อดำเนินการทดสอบการทำงานด้วยวิธีนี้ ให้แน่ใจว่าได้ปล่อยวงจรลัด CN72 หลังจากที่ได้เสร็จสิ้นการทดสอบการทำงานแล้ว


ใช้งานตัวเครื่องด้วยรีโมทคอนโทรลตามปกติ สำหรับขั้นตอนการทำงาน ให้อ้างอิงคู่มือผู้ใช้งานที่ให้มาพร้อมกับตัวเครื่องภายนอก
 คุณสามารถสั่งให้เครื่องทำการทดสอบการทำงานภาคบังคับได้ โดยปฏิบัติตามขั้นตอนต่อไปนี้ แม้ว่าการดำเนินการจะหยุดลงเพราะเทอร์โมสตัดปิด เพื่อป้องกันไม่ให้เกิดการทำงานแบบต่อเนื่อง การทดสอบการทำงานภาคบังคับจะถูกปล่อยหลังจากที่ได้ผ่านไป 60 นาที และจะกลับเข้าสู่การทำงานตามปกติ

⚠ ข้อควรระวัง


อย่าใช้การทดสอบการทำงานภาคบังคับเพื่อวัตถุประสงค์อื่น เพราะจะเป็นการเพิ่มภาระให้กับเครื่องปรับอากาศมากเกินไป

รีโมทคอนโทรลแบบมีสาย


ตรวจสอบให้แน่ใจว่าได้ปิดเครื่องปรับอากาศก่อนทำการตั้งค่า (เปลี่ยนแปลงการตั้งค่าขณะที่เครื่องปรับอากาศไม่ได้ทำงานอยู่)



- กดปุ่มตัวตั้งเวลา OFF และ [△] ปุ่มตั้งค่าพร้อมกัน ค้างไว้ 10 วินาทีขึ้นไป [TEST] จะแสดงขึ้นหน้าจอและจะสามารถดำเนินการทดสอบการทำงานได้



- กดปุ่มเปิด/ปิดเครื่อง
- กดปุ่มเมนูเพื่อเลือกโหมดการทำงาน เลือก [Cool] ด้วยปุ่มตั้งค่า [▽] [△] และจากนั้นให้กดปุ่มเมนู (สามครั้ง) อีกครั้งเพื่อกำหนดโหมดการทำงาน
 - อย่าใช้เครื่องปรับอากาศในโหมดอื่นนอกจาก [Cool]
 - ฟังก์ชันการควบคุมอุณหภูมิจะไม่ทำงานระหว่างการทดสอบการทำงาน
 - รหัสการตรวจสอบจะแสดงขึ้นหน้าจอตามปกติ
- หลังการทดสอบการทำงาน ให้กดปุ่มตัวตั้งเวลา OFF เพื่อหยุดการทดสอบการทำงาน ([TEST] จะหายไปจากหน้าจอและเครื่องปรับอากาศจะเข้าสู่โหมดหยุดการทำงานตามปกติ)



11 การบำรุงรักษา


⚠️ ข้อควรระวัง

เมื่อเชื่อมต่อท่อดึงลมกลับเข้ากับตัวเครื่อง วิธีการทำความสะอาดแผ่นกรองอากาศจะแตกต่างกันตามโครงสร้างของส่วนปลายท่อลมให้สอบถามผู้ติดตั้งที่มีความชำนาญ หรือช่างบริการที่มีความชำนาญ

<การดูแลรักษาประจำวัน> (ทุกๆ 3 เดือน)

▼ การทำความสะอาดแผ่นกรองอากาศ

1 กดปุ่ม เพื่อสั่งหยุดการทำงาน จากนั้นให้ปิดเครื่องตัดกระแสไฟฟ้า



1. ถอดแผ่นกรองอากาศ (จำหน่ายแยก)
2. ทำความสะอาดด้วยน้ำหรือเครื่องดูดฝุ่น
 - ถ้าฝุ่นเกาะหนา ให้ทำความสะอาดแผ่นกรองอากาศด้วยน้ำอุ่น สารซักล้างที่มีค่าเป็นกลางหรือน้ำสะอาด
 - หลังจากการทำความสะอาดด้วยน้ำ ให้ตากแผ่นกรองอากาศในที่ร่ม
3. ติดตั้งแผ่นกรองอากาศ (จำหน่ายแยก)

2 เปิดเครื่องตัดกระแสไฟฟ้า จากนั้นให้กดปุ่ม บนรีโมทคอนโทรลเพื่อเริ่มการทำงาน

⚠️ ข้อควรระวัง

- อย่าเปิดเครื่องปรับอากาศขณะที่แผ่นกรองอากาศ (จำหน่ายแยก) ถูกถอดออก

▼ การบำรุงรักษาเครื่องตามช่วงเวลา

เพื่อป้องกันความสูญเสียจากสภาพแวดล้อม ขอแนะนำให้ท่านทำความสะอาด และบำรุงรักษาตัวเครื่องภายในและตัวเครื่องภายนอกของเครื่องปรับอากาศเป็นประจำ

เมื่อใช้งานเครื่องปรับอากาศเป็นเวลานาน ขอแนะนำให้ดำเนินการบำรุงรักษาเครื่องตามช่วงเวลา (ปีละครั้ง)

นอกจากนี้ควรตรวจสอบรอยขีดข่วน หรือสนิมที่ตัวเครื่องภายนอกอยู่เสมอ และกำจัดสนิมออกหรือใช้น้ำยาป้องกันสนิม หากจำเป็นตามข้อควรปฏิบัติทั่วไป เมื่อใช้งานตัวเครื่องภายในเป็นเวลาตั้งแต่ 8 ชั่วโมงขึ้นไปต่อวัน ต้องทำความสะอาดตัวเครื่องภายในและตัวเครื่องภายนอกอย่างน้อยทุกๆ 3 เดือน โดยให้ผู้เชี่ยวชาญเป็นผู้ดำเนินการให้


การบำรุงรักษาอยู่เสมอซึ่งกล่าวมาจะช่วยยืดอายุการใช้งานของผลิตภัณฑ์และยังเป็นทางเลือกค่าใช้จ่ายของผู้ใช้งานเครื่องด้วยการไม่บำรุงรักษาตัวเครื่องภายนอกและตัวเครื่องภายในอยู่เสมออาจทำให้ประสิทธิภาพของตัวเครื่องลดลง มีน้ำรั่วซึม หรือแม้แต่อาจทำให้คอมเพรสเซอร์บกพร่องได้

▼ การตรวจสอบก่อนการบำรุงรักษา (ปีละครั้ง)

ควรให้ผู้ติดตั้งที่มีความชำนาญ หรือช่างบริการที่มีความชำนาญเป็นผู้ดำเนินการตรวจสอบต่อไปนี้

ชิ้นส่วนต่างๆ	วิธีการตรวจสอบ
มอเตอร์พัดลม	เข้าถึงจากแผงปิดช่องทางเข้าออกและตรวจสอบว่ามีเสียงผิดปกติใดๆ หรือไม่
พัดลม	เข้าถึงจากแผงปิดช่องทางเข้าออกและถอดแผงปิดช่องทางเข้าออก ตรวจสอบว่าพัดลมสาย เสียหาย หรือมีฝุ่นเกาะหรือไม่
แผ่นกรอง (จำหน่ายแยก)	เข้าถึงจากช่องตรวจสอบ แล้วตรวจสอบว่ามีคราบหรือรอยแตกบนแผ่นกรองหรือไม่
ถาดน้ำทิ้ง	เข้าถึงจากแผงปิดช่องทางเข้าออกและถอดแผงปิดช่องทางเข้าออก ตรวจสอบว่ามีคราบหรือมีน้ำเสียหรือไม่

- สามารถเข้าถึงตัวเครื่องได้จากแผงปิดช่องทางเข้าออกตามที่แสดงในภาพ




▼ รายการการบำรุงรักษา

ชิ้นส่วน	ตัวเครื่อง	การตรวจเช็ค (ดู / ฟังเสียง)	การบำรุงรักษา
เครื่องแลกเปลี่ยนความร้อน	ตัวเครื่องภายใน / ตัวเครื่องภายนอก	ฝุ่น / สิ่งสกปรกอุดตัน, รอยขีดข่วน	ทำความสะอาดเครื่องแลกเปลี่ยนความร้อนเมื่อเกิดการอุดตัน
มอเตอร์พัดลม	ตัวเครื่องภายใน / ตัวเครื่องภายนอก	เสียง	ตรวจสอบด้วยวิธีการที่เหมาะสมเมื่อเกิดเสียงดังผิดปกติ
แผ่นกรอง (จำหน่ายแยก)	ตัวเครื่องภายใน	ฝุ่น / สิ่งสกปรก, การแตกหัก	<ul style="list-style-type: none"> • ใช้น้ำทำความสะอาดแผ่นกรองเมื่อมีคราบสกปรกมาก • เปลี่ยนใหม่เมื่อชำรุด
พัดลม	ตัวเครื่องภายใน	<ul style="list-style-type: none"> • การสั่น, ความสมดุล • ฝุ่น / สิ่งสกปรก, รูปร่าง 	<ul style="list-style-type: none"> • เปลี่ยนพัดลมเมื่อเกิดการสั่นขณะทำงาน หรือไม่สมดุล • ขัดหรือทำความสะอาดพัดลมเมื่อสกปรก
ตะแกรงช่องลมเข้า/ออก	ตัวเครื่องภายใน / ตัวเครื่องภายนอก	ฝุ่น / สิ่งสกปรก, รอยขีดข่วน	ซ่อมหรือเปลี่ยนใหม่เมื่อชิ้นส่วนผิดรูป หรือเสียหาย
ถาดน้ำทิ้ง	ตัวเครื่องภายใน	ฝุ่น / สิ่งสกปรกอุดตัน, การปนเปื้อนของน้ำทิ้ง	ทำความสะอาดถาดน้ำทิ้งและตรวจสอบการวางท่อให้อยู่ในแนวราบเพื่อให้ระบายน้ำทิ้งได้ดี
แผงตกแต่ง, บานเก็ลด์	ตัวเครื่องภายใน	ฝุ่น / สิ่งสกปรก, รอยขีดข่วน	ทำความสะอาดเมื่อสกปรกหรือทาน้ำยาเคลือบ
ภายนอก	ตัวเครื่องภายนอก	<ul style="list-style-type: none"> • สนิม, ฉนวนหลุดออก • พื้นผิวตัวเครื่องหลุด / กะเทาะออก 	ทาน้ำยาเคลือบ

12 การแก้ไขปัญหา

■ การยืนยันและตรวจสอบ

หากเครื่องปรับอากาศมีปัญหา สัญญาณตัวตั้งเวลา OFF จะแสดงขึ้นสลับกับรหัสตรวจสอบและหมายเลขของตัวเครื่องภายในที่มีปัญหา






■ ประวัติการแก้ไข้ปัญหาและการตรวจยืนยัน

คุณสามารถตรวจสอบประวัติการแก้ไข้ปัญหาได้ด้วยขั้นตอนดังต่อไปนี้ หากเกิดปัญหาลงกับตัวเครื่องภายใน (ประวัติการแก้ไข้ปัญหาจะบันทึกได้ถึง 4 เหตุการณ์)

คุณสามารถตรวจสอบได้ระหว่างการทำงานหรือเมื่อหยุดการทำงาน

- ตัวตั้งเวลา OFF จะถูกยกเลิก หากคุณตรวจสอบประวัติการแก้ไข้ปัญหาในระหว่างการทำงานของตัวตั้งเวลา OFF

ขั้นตอน	คำอธิบายการทำงาน
1	<p>กดปุ่มตั้งเวลา OFF 10 วินาทีขึ้นไปและสัญญาณจะปรากฏเป็นภาพบ่งชี้ว่าได้เข้าสู่โหมดประวัติการแก้ไข้ปัญหา หาก [Service check] แสดงขึ้นหน้าจอ โหมดจะเข้าสู่โหมดประวัติการแก้ไข้ปัญหา</p> <ul style="list-style-type: none"> • [01: ลำดับประวัติการแก้ไข้ปัญหา] จะปรากฏขึ้นในสัญญาณแสดงสถานะอุณหภูมิ • สัญญาณตัวตั้งเวลา OFF จะแสดงขึ้นสลับกับ [check code] และ [indoor Unit No.] ที่มีปัญหา 
2	<p>ทุกครั้งที่เกิดปุ่มตั้งค่า ประวัติการแก้ไข้ปัญหาที่บันทึกไว้จะแสดงขึ้นตามลำดับ ประวัติการแก้ไข้ปัญหาจะปรากฏขึ้นเป็นลำดับจาก [01] (ล่าสุด) ถึง [04] (เก่าสุด)</p> <p>⚠ ข้อควรระวัง</p> <p>ในโหมดประวัติการแก้ไข้ปัญหา ห้ามกดปุ่มเมนูเป็นเวลา 10 วินาที เนื่องจากการกระทำดังกล่าวเป็นการลบประวัติการแก้ไข้ปัญหาทั้งหมดของตัวเครื่องภายใน</p> 
3	<p>หลังจากเสร็จสิ้นการตรวจสอบแล้ว ให้กดปุ่มเปิด/ปิดเพื่อกลับเข้าสู่โหมดธรรมดา</p> <ul style="list-style-type: none"> • หากเครื่องปรับอากาศกำลังทำงานอยู่ เครื่องก็ยังคงทำงานถึงแม้ว่าจะกดปุ่มเปิด/ปิดเครื่องก็ตาม เพื่อสั่งหยุดการทำงาน กดปุ่มเปิด/ปิดอีกครั้ง 

วิธีการตรวจสอบ

บนรีโมทคอนโทรลแบบมีสาย รีโมทคอนโทรลควบคุมกลางและแผงวงจร P.C. อินเตอร์เฟซของตัวเครื่องภายนอก (I/F) การตรวจสอบจะแสดง LCD (รีโมทคอนโทรล) หรือหน้าจอแสดงผลแบบ 7 ส่วน (บนแผงวงจร P.C. อินเตอร์เฟซภายนอก) เพื่อแสดงการทำงาน ดังนั้น จึงรับทราบสถานะการทำงานได้ การใช้ฟังก์ชันวินิจฉัยด้วยตนเอง ปัญหาหรือตำแหน่งที่มีข้อผิดพลาดของเครื่องปรับอากาศจะสามารถตรวจหาได้ตามที่แสดงในตารางด้านล่างนี้

รายการรหัสการตรวจสอบ

- รายการดังต่อไปนี้แสดงถึงรหัสการตรวจสอบแต่ละรหัส ตรวจสอบค่านี้ออกมาจากการตรวจสอบจากตารางตามชิ้นส่วนที่จะทำการตรวจสอบ
- ในกรณีของการตรวจสอบจากรีโมทคอนโทรลตัวเครื่องภายใน อ่าน “หน้าจอแสดงผลของรีโมทคอนโทรลแบบมีสาย” ในรายการนี้
 - ในกรณีของการตรวจสอบจากตัวเครื่องภายนอก อ่าน “หน้าจอแสดงผลแบบ 7 ส่วนของตัวเครื่องภายนอก” ในรายการนี้
 - ในกรณีของการตรวจสอบจากตัวเครื่องภายในด้วยรีโมทคอนโทรลแบบไร้สาย อ่าน “หน้าจอบล็อกเซนเซอร์ของตัวรับสัญญาณ” ในรายการนี้

○ : สว่าง □ : กะพริบ ● : ดับลง
 ALT: กะพริบสลับกันเมื่อมีไฟ LED สองดวงกะพริบ
 SIM: กะพริบพร้อมกันเมื่อมีไฟ LED สองดวงกะพริบ
 อินเวอร์เตอร์: คอมเพรสเซอร์ / แผงวงจร P.C. อินเวอร์เตอร์พัดลม

รหัสการตรวจสอบ			รีโมทคอนโทรลแบบไร้สาย				ชื่อรหัสการตรวจสอบ	เครื่องมือตัดลิน
หน้าจอแสดงผลของรีโมทคอนโทรลแบบมีสาย	หน้าจอแสดงผลแบบ 7 ส่วนของตัวเครื่องภายนอก		หน้าจอบล็อกเซนเซอร์ของตัวรับสัญญาณ					
		รหัสเสริม	การทำงาน	ตัวตั้งเวลา	พร้อม	กะพริบ		
E01	—	—	□	●	●		ปัญหาด้านการสื่อสารระหว่างตัวเครื่องภายในและรีโมทคอนโทรล (ตรวจพบที่ด้านรีโมทคอนโทรล)	รีโมทคอนโทรล
E02	—	—	□	●	●		ปัญหาด้านการส่งสัญญาณของรีโมทคอนโทรล	รีโมทคอนโทรล
E03	—	—	□	●	●		ปัญหาด้านการสื่อสารระหว่างตัวเครื่องภายในและรีโมทคอนโทรล (ตรวจพบที่ด้านตัวเครื่องภายใน)	ตัวเครื่องภายใน
E04	—	—	●	●	□		ปัญหาทางจรรยาบรรณการสื่อสารระหว่างตัวเครื่องภายใน/ภายนอก (ตรวจพบที่ด้านตัวเครื่องภายใน)	ตัวเครื่องภายใน
E06	E06	จำนวนของตัวเครื่องภายในที่รับเซนเซอร์ได้เป็นปกติ	●	●	□		การลดลงของจำนวนตัวเครื่องภายใน	I/F
—	E07	—	●	●	□		ปัญหาทางจรรยาบรรณการสื่อสารระหว่างตัวเครื่องภายใน/ภายนอก (ตรวจพบที่ด้านตัวเครื่องภายนอก)	I/F
E08	E08	ที่อยู่ของตัวเครื่องภายในซ้ำกัน	□	●	●		ที่อยู่ของตัวเครื่องภายในซ้ำกัน	ตัวเครื่องภายใน ● I/F
E09	—	—	□	●	●		รีโมทคอนโทรลตัวหลักซ้ำกัน	รีโมทคอนโทรล
E10	—	—	□	●	●		ปัญหาด้านการสื่อสารระหว่างตัวเครื่องภายใน MCU	ตัวเครื่องภายใน
E11	—	—	□	●	●		ปัญหาการสื่อสารระหว่างชุดเครื่องมือควบคุมแอปพลิเคชันและตัวเครื่องภายใน	ตัวเครื่องภายใน ชุดเครื่องมือควบคุมการทำงาน
E12	E12	01: การสื่อสารของตัวเครื่องภายใน / ตัวเครื่องภายนอก 02: การสื่อสารของตัวเครื่องภายนอก / ตัวเครื่องภายนอก	□	●	●		ปัญหาการเริ่มที่อยู่โดยอัตโนมัติ	I/F
E15	E15	—	●	●	□		ไม่มีตัวเครื่องภายในระหว่างการทำหน้าที่โดยอัตโนมัติ	I/F
E16	E16	00: กำลังไฟเกิน 01: จำนวนของตัวเครื่องที่เชื่อมต่อ	●	●	□		กำลังไฟเกิน / จำนวนของตัวเครื่องภายในที่เชื่อมต่อ	I/F
E18	—	—	□	●	●		ปัญหาการสื่อสารระหว่างตัวเครื่องหลักและรองภายใน	ตัวเครื่องภายใน
E19	E19	00: ตรวจไม่พบตัวเครื่องหลัก 02: มีตัวเครื่องหลักสองตัวหรือมากกว่า	●	●	□		ปัญหาจำนวนตัวเครื่องหลักภายนอก	I/F
E20	E20	01: ตัวเครื่องภายในของสายอื่นที่เชื่อมต่อ 02: ตัวเครื่องภายในของสายอื่นที่เชื่อมต่อ	●	●	□		สายอื่นเชื่อมต่อในระหว่างการกำหนดที่อยู่อัตโนมัติ	I/F
E23	E23	—	●	●	□		ปัญหาการส่งในการสื่อสารระหว่างตัวเครื่องภายนอก ปัญหาในจำนวนของหน่วยก็เก็บความร้อน (ปัญหาการรับเข้า)	I/F
E25	E25	—	●	●	□		ที่อยู่ภายนอกตัวรองซ้ำกัน	I/F
E26	E26	จำนวนของตัวเครื่องภายนอกที่รับสัญญาณได้เป็นปกติ	●	●	□		การลดลงของจำนวนตัวเครื่องภายนอกที่เชื่อมต่อ	I/F
E28	E28	จำนวนของตัวเครื่องภายนอกที่ตรวจพบ	●	●	□		ปัญหาตัวเครื่องรองภายนอก	I/F
E31	E31	*1 ข้อมูลจำนวนอินเวอร์เตอร์	●	●	□		ปัญหาการสื่อสารอินเวอร์เตอร์	I/F
F01	—	—	□	□	●	ALT	ปัญหาเซนเซอร์ TCJ ตัวเครื่องภายใน	ตัวเครื่องภายใน
F02	—	—	□	□	●	ALT	ปัญหาเซนเซอร์ TC2 ตัวเครื่องภายใน	ตัวเครื่องภายใน
F03	—	—	□	□	●	ALT	ปัญหาเซนเซอร์ TC1 ตัวเครื่องภายใน	ตัวเครื่องภายใน
F04	F04	—	□	□	○	ALT	ปัญหาเซนเซอร์ TD1	I/F
F05	F05	—	□	□	○	ALT	ปัญหาเซนเซอร์ TD2	I/F



รหัสการตรวจสอบ			รีโมทคอนโทรลแบบไร้สาย				ชื่อรหัสการตรวจสอบ	เครื่องมือวัดคลื่น
หน้าจอแสดงผลของรีโมทคอนโทรลแบบมีสาย	หน้าจอแสดงผลแบบ 7 ส่วนของตัวเครื่องภายนอก		หน้าจอบล็อกเซนเซอร์ของตัวรับสัญญาณ					
		รหัสเสริม	การทำงาน	ตัวตั้งเวลา	พร้อม	กะพริบ		
F06	F06	01: เซนเซอร์ TE1 02: เซนเซอร์ TE2 03: เซนเซอร์ TE3	☒	☒	○	ALT	ปัญหาเซนเซอร์ TE1, TE2 หรือ TE3	I/F
F07	F07	01: เซนเซอร์ TL1 02: เซนเซอร์ TL2 03: เซนเซอร์ TL3	☒	☒	○	ALT	ปัญหาเซนเซอร์ TL1, TL2 หรือ TL3	I/F
F08	F08	—	☒	☒	○	ALT	ปัญหาเซนเซอร์ TO	I/F
F09	F09	01: เซนเซอร์ TG1 02: เซนเซอร์ TG2 03: เซนเซอร์ TG3	☒	☒	○	ALT	ปัญหาเซนเซอร์ TG1, TG2 หรือ TG3	I/F
F10	—	—	☒	☒	●	ALT	ปัญหาเซนเซอร์ TA ตัวเครื่องภายใน	ตัวเครื่องภายใน
F11	—	—	☒	☒	●	ALT	ปัญหาเซนเซอร์ TF	ตัวเครื่องภายใน
F12	F12	01: เซนเซอร์ TS1 03: เซนเซอร์ TS3	☒	☒	○	ALT	ปัญหาเซนเซอร์ TS1 หรือ TS3	I/F
F13	F13	01: คอมเพรสเซอร์ 1 ด้าน 02: คอมเพรสเซอร์ 2 ด้าน 03: คอมเพรสเซอร์ 3 ด้าน	☒	☒	○	ALT	ปัญหาเซนเซอร์ TH	อินเวอร์เตอร์
F15	F15	—	☒	☒	○	ALT	การเดินสายไฟผิดของเซนเซอร์อุณหภูมิของตัวเครื่องภายนอก (TE, TL)	I/F
F16	F16	—	☒	☒	○	ALT	การเดินสายไฟผิดของเซนเซอร์แรงดันของตัวเครื่องภายนอก (Pd, Ps)	I/F
F22	F22	—	☒	☒	○	ALT	ปัญหาเซนเซอร์ TD3	I/F
F23	F23	—	☒	☒	○	ALT	ปัญหาเซนเซอร์ Ps	I/F
F24	F24	—	☒	☒	○	ALT	ปัญหาเซนเซอร์ Pd	I/F
F29	—	—	☒	☒	●	SIM	ปัญหาอื่นของตัวเครื่องภายใน	ตัวเครื่องภายใน
F30	F30	—	☒	☒	○	SIM	ปัญหาเซนเซอร์ตรวจจับการเคลื่อนไหว	ตัวเครื่องภายใน
F31	F31	—	☒	☒	○	SIM	ปัญหาของ EEPROM ตัวเครื่องภายใน	I/F
H01	H01	01: คอมเพรสเซอร์ 1 ด้าน 02: คอมเพรสเซอร์ 2 ด้าน 03: คอมเพรสเซอร์ 3 ด้าน	●	☒	●		ความเสียหายที่คอมเพรสเซอร์	อินเวอร์เตอร์
H02	H02	01: คอมเพรสเซอร์ 1 ด้าน 02: คอมเพรสเซอร์ 2 ด้าน 03: คอมเพรสเซอร์ 3 ด้าน	●	☒	●		ปัญหาคอมเพรสเซอร์ (ล็อก)	อินเวอร์เตอร์
H03	H03	01: คอมเพรสเซอร์ 1 ด้าน 02: คอมเพรสเซอร์ 2 ด้าน 03: คอมเพรสเซอร์ 3 ด้าน	●	☒	●		ปัญหาระบบวงจรตรวจจับสนิท	อินเวอร์เตอร์
H04	H04	—	●	☒	●		คอมเพรสเซอร์ การทำงานของตัวเรือนเทอร์โมสตัท 1 ตัว	I/F
H05	H05	—	●	☒	●		การเดินสายไฟผิดของเซนเซอร์ TD1	I/F
H06	H06	—	●	☒	●		การดำเนินการป้องกันแรงดันต่ำ	I/F
H07	H07	—	●	☒	●		การป้องกันการตรวจสอบระดับน้ำมันลดลง	I/F
H08	H08	01: ปัญหาเซนเซอร์ TK1 02: ปัญหาเซนเซอร์ TK2 03: ปัญหาเซนเซอร์ TK3 04: ปัญหาเซนเซอร์ TK4 05: ปัญหาเซนเซอร์ TK5	●	☒	●		ปัญหาเซนเซอร์อุณหภูมิตรวจจับสนิทน้ำมัน	I/F
H14	H14	—	●	☒	●		คอมเพรสเซอร์ การทำงานของตัวเรือนเทอร์โมสตัท 2 ตัว	I/F
H15	H15	—	●	☒	●		การเดินสายไฟผิดของเซนเซอร์ TD2	I/F
H16	H16	01: ปัญหาระบบจนวน้ำมัน TK1 02: ปัญหาระบบจนวน้ำมัน TK2 03: ปัญหาระบบจนวน้ำมัน TK3 04: ปัญหาระบบจนวน้ำมัน TK4 05: ปัญหาระบบจนวน้ำมัน TK5	●	☒	●		ปัญหาทางจนวน้ำมัน	I/F
H25	H25	—	●	☒	●		การเดินสายไฟผิดของเซนเซอร์ TD3	I/F

รหัสการตรวจสอบ			รีโมทคอนโทรลแบบไร้สาย				ชื่อรหัสการตรวจสอบ	เครื่องมือวัดคลื่น
หน้าจอแสดงผลของรีโมทคอนโทรลแบบมีสาย	หน้าจอแสดงผลแบบ 7 ส่วนของตัวเครื่องภายนอก		หน้าจอบล็อกเซนเซอร์ของตัวรับสัญญาณ					
		รหัสเสริม	การทำงาน	ตัวตั้งเวลา	พร้อม	กะพริบ		
L02	L02	-	☐	●	☐	SIM	การจับคู่รีโมทของตัวเครื่องภายในและภายนอก	I/F
L03	-	-	☐	●	☐	SIM	ตัวเครื่องกลางของตัวเครื่องภายในซ้ำกัน	ตัวเครื่องภายใน
L04	L04	-	☐	○	☐	SIM	ที่อยู่สายอื่นของตัวเครื่องภายนอกซ้ำกัน	I/F
L05	-	-	☐	●	☐	SIM	ตัวเครื่องภายในซ้ำกันด้วยลำดับความสำคัญ (แสดงในตัวเครื่องภายในที่มีลำดับความสำคัญ)	I/F
L06	L06	จำนวนของตัวเครื่องภายในที่มีลำดับความสำคัญ	☐	●	☐	SIM	ตัวเครื่องภายในซ้ำกันด้วยลำดับความสำคัญ (แสดงในตัวเครื่องนอกเหนือจากตัวเครื่องภายในที่มีลำดับความสำคัญ)	I/F
L07	-	-	☐	●	☐	SIM	สายกลุ่มในตัวเครื่องภายในอิสระ	ตัวเครื่องภายใน
L08	L08	-	☐	●	☐	SIM	กลุ่มตัวเครื่องภายใน / ภายนอกที่อยู่	ตัวเครื่องภายใน, I/F
L09	-	-	☐	●	☐	SIM	การยกเลิกกำลังไฟของตัวเครื่องภายใน	ตัวเครื่องภายใน
L10	L10	-	☐	○	☐	SIM	การยกเลิกกำลังไฟของตัวเครื่องภายนอก	I/F
L17	L17	-	☐	○	☐	SIM	ปัญหาการจับคู่รีโมทประเภทตัวเครื่องภายนอก	I/F
L18	L18	-	☐	○	☐	SIM	ปัญหาหน่วยตัวเลือกการไหล	I/F
L20	-	-	☐	○	☐	SIM	ที่อยู่ควบคุมกลางซ้ำกัน	ตัวเครื่องภายใน
L28	L28	-	☐	○	☐	SIM	ตัวเครื่องภายนอกเชื่อมต่อกันมากเกินไป	I/F
L29	L29	*1 ข้อมูลจำนวนอินเวอร์เตอร์	☐	○	☐	SIM	จำนวนของปัญหาอินเวอร์เตอร์	I/F
L30	L30	ที่อยู่ตัวเครื่องภายในที่ตรวจพบได้	☐	○	☐	SIM	อุปกรณ์ที่เชื่อมต่อกันด้านนอกของตัวเครื่องภายใน	ตัวเครื่องภายใน
-	L31	-	-	-	-	-	ปัญหา I/C ขยาย	I/F
P01	-	-	●	☐	☐	ALT	ปัญหามอเตอร์พัดลมของตัวเครื่องภายใน	ตัวเครื่องภายใน
P03	P03	-	☐	●	☐	ALT	อุณหภูมิอากาศออก ปัญหา TD1	I/F
P04	P04	01: คอมเพรสเซอร์ 1 ด้าน 02: คอมเพรสเซอร์ 2 ด้าน 03: คอมเพรสเซอร์ 3 ด้าน	☐	●	☐	ALT	การทำงานของระบบ SW แรงดันสูง	อินเวอร์เตอร์
P05	P05	00: 01: คอมเพรสเซอร์ 1 ด้าน 02: คอมเพรสเซอร์ 2 ด้าน 03: คอมเพรสเซอร์ 3 ด้าน	☐	●	☐	ALT	การตรวจจับการพลาดเฟส / การตรวจจับไฟดับ ปัญหาแรงดันไฟฟ้า DC อินเวอร์เตอร์ (คอมเพรสเซอร์) ปัญหาแรงดันไฟฟ้า DC อินเวอร์เตอร์ (คอมเพรสเซอร์) ปัญหาแรงดันไฟฟ้า DC อินเวอร์เตอร์ (คอมเพรสเซอร์)	I/F
P07	P07	01: คอมเพรสเซอร์ 1 ด้าน 02: คอมเพรสเซอร์ 2 ด้าน 03: คอมเพรสเซอร์ 3 ด้าน ----- 04: แผงระบายความร้อน	☐	●	☐	ALT	ปัญหาแผงระบายความร้อนอุณหภูมิร้อนเกิน ----- ปัญหาการเกิดหยดน้ำของแผงระบายความร้อน	อินเวอร์เตอร์, I/F
P10	P10	ที่อยู่ตัวเครื่องภายในที่ตรวจพบได้	●	☐	☐	ALT	ปัญหาการไหลกลับของตัวเครื่องภายใน	ตัวเครื่องภายใน
P11	P11	-	●	☐	☐	ALT	ปัญหาการเอียงของเครื่องแลกเปลี่ยนความร้อนภายนอก	I/F
P12	-	-	●	☐	☐	ALT	ปัญหามอเตอร์พัดลมของตัวเครื่องภายใน	ตัวเครื่องภายใน
P13	P13	-	●	☐	☐	ALT	ปัญหาการตรวจจับของเหลวย้อนกลับภายนอก	I/F
P15	P15	01: สภาวะ TS 02: สภาวะ TD	☐	●	☐	ALT	การตรวจพบการรั่วไหลของก๊าซ	I/F
P17	P17	-	☐	●	☐	ALT	อุณหภูมิอากาศออก ปัญหา TD2	I/F
P19	P19	จำนวนของตัวเครื่องภายนอกที่ตรวจพบ	☐	●	☐	ALT	ปัญหาหมักหมนของวาล์ว 4 ทิศทาง	I/F
P20	P20	-	-	●	-	ALT	การดำเนินการป้องกันแรงดันสูง	I/F
P22	P22	#0: วงจรลัดส่วนประกอบ #E: ปัญหาแรงดันไฟฟ้า Vdc #1: ปัญหาวงจรตรวจจับตำแหน่ง #2: ปัญหาเซนเซอร์กระแสอินพุต #3: ปัญหามอเตอร์ล็อก #C: ปัญหาอุณหภูมิของเซนเซอร์ (ไม่มีเซนเซอร์ TH) #4: ปัญหากระแสมอเตอร์ #D: วงจรลัดเซนเซอร์/ปัญหาการปล่อย (ไม่มีเซนเซอร์ TH) #5: การชิงโครโนซ์/ปัญหา step-out ใส่หมายเลขพัดลมอินเวอร์เตอร์ในเครื่องหมาย [#]	☐	●	☐	ALT	ปัญหาอินเวอร์เตอร์พัดลมของตัวเครื่องภายนอก	อินเวอร์เตอร์



รหัสการตรวจสอบ			รีโมทคอนโทรลแบบไร้สาย				ชื่อรหัสการตรวจสอบ	เครื่องมือตัดคืน	
หน้าจอบ่งชี้ผลของรีโมทคอนโทรลแบบมีสาย	หน้าจอบ่งชี้ผลแบบ 7 ส่วนของตัวเครื่องภายนอก		หน้าจอบ่งชี้ผลของรีโมทคอนโทรลแบบไร้สาย						
		รหัสเสริม		การทำงาน	ตัวตั้งเวลา	พร้อม	กะพริบ		
P26	P26	01: คอมเพรสเซอร์ 1 ด้าน 02: คอมเพรสเซอร์ 2 ด้าน 03: คอมเพรสเซอร์ 3 ด้าน		☐	●	☐	ALT	ปัญหาการป้องกัน IPM ล้น	อินเวอร์เตอร์
P29	P29	01: คอมเพรสเซอร์ 1 ด้าน 02: คอมเพรสเซอร์ 2 ด้าน 03: คอมเพรสเซอร์ 3 ด้าน		☐	●	☐	ALT	ปัญหาระบบวงจรตรวจจับตำแหน่งคอมเพรสเซอร์	อินเวอร์เตอร์
P31	—	—		☐	●	☐	ALT	ปัญหาอื่นๆ ของตัวเครื่องภายใน (ปัญหาตัวเครื่องรองภายในแบบกลุ่ม)	ตัวเครื่องภายใน

*1 ข้อมูลจำนวนอินเวอร์เตอร์

หมายเลข	คอมเพรสเซอร์อินเวอร์เตอร์		อินเวอร์เตอร์พัดลม		ปัญหา
	1	2	1	2	
01	○				คอมเพรสเซอร์ 1
02		○			คอมเพรสเซอร์ 2
03	○	○			คอมเพรสเซอร์ 1 + คอมเพรสเซอร์ 2
08			○		พัดลม1
09	○		○		คอมเพรสเซอร์ 1 + พัดลม1
0A		○	○		คอมเพรสเซอร์ 2 + พัดลม1
0B	○	○	○		คอมเพรสเซอร์ 1 + คอมเพรสเซอร์ 2 + พัดลม1
10				○	พัดลม2
11	○			○	คอมเพรสเซอร์ 1 + พัดลม2
12		○		○	คอมเพรสเซอร์ 2 + พัดลม2
13	○	○		○	คอมเพรสเซอร์ 1 + คอมเพรสเซอร์ 2 + พัดลม2
18			○	○	พัดลม1 + พัดลม 2
19	○		○	○	คอมเพรสเซอร์ 1 + พัดลม1 + พัดลม2
1A		○	○	○	คอมเพรสเซอร์ 2 + พัดลม1 + พัดลม2
1B	○	○	○	○	ทั้งหมด
○ : ปัญหาอินเวอร์เตอร์					

- สำหรับรายละเอียดเกี่ยวกับรหัสการตรวจสอบที่กำหนดด้วยแผงวงจร P.C. อินเวอร์เตอร์หรือแผงวงจร P.C. อินเวอร์เตอร์ให้อ้างอิงคู่มือการติดตั้งที่แนบมากับตัวเครื่องภายนอก

ปัญหาที่ตรวจพบโดยอุปกรณ์ควบคุมกลาง

รหัสการตรวจสอบ			รีโมทคอนโทรลแบบไร้สาย				ชื่อรหัสการตรวจสอบ	เครื่องมือตัดคืน	
ตัวแสดงอุปกรณ์ควบคุมกลาง	หน้าจอบ่งชี้ผลแบบ 7 ส่วนของตัวเครื่องภายนอก		หน้าจอบ่งชี้ผลของรีโมทคอนโทรลแบบไร้สาย						
		รหัสเสริม		การทำงาน	ตัวตั้งเวลา	พร้อม	กะพริบ		
C05	—	—						ปัญหาการส่งในอุปกรณ์ควบคุมกลาง	ลิงก์สื่อสาร
C06	—	—						ปัญหาการรับในอุปกรณ์ควบคุมกลาง	ลิงก์สื่อสาร
C12	—	—						สัญญาณเตือนเป็นชุดของอินเวอร์เตอร์เพชควบคุมอุปกรณ์ใช้งานทั่วไป	อุปกรณ์ใช้งานทั่วไป I/F
P30 (L20)	—	—		แตกต่างกันตามเนื้อหาปัญหาของตัวเครื่องที่มีสัญญาณเตือนเกิดขึ้น (L20 แสดงขึ้นหน้าจอ)				ปัญหาตัวเครื่องรองควบคุมแบบกลุ่ม • ที่อยู่ข้างกันของตัวเครื่องภายในในอุปกรณ์ควบคุมกลาง • ด้วยการผลิตของระบบปรับอากาศ ตัวเครื่องภายในอาจตรวจพบรหัสการตรวจสอบ L20	ลิงก์สื่อสาร

คำเตือนเกี่ยวกับการรั่วไหลของสารทำความเย็น

ตรวจสอบค่าจำกัดความเข้มข้น

ห้องที่ติดตั้งเครื่องปรับอากาศจะต้องการออกแบบในกรณีที่ก๊าซสารทำความเย็นรั่วซึมออก ความเข้มข้นของก๊าซดังกล่าวจะต้องไม่เกินขีดจำกัดที่กำหนดไว้

สารทำความเย็น R410A ที่ใช้ในเครื่องปรับอากาศมีความปลอดภัยปราศจากแอมโมเนียที่ไวไฟหรือเป็นพิษ และไม่ถูกจำกัดด้วยกฎหมายที่ผลบังคับใช้เพื่อป้องกันโอโซน อย่างไรก็ตาม เนื่องจากสารทำความเย็นดังกล่าวมีองค์ประกอบอื่นๆ นอกจากอากาศ หากความเข้มข้นเพิ่มขึ้นเกินขีดจำกัดอาจเสี่ยงต่อการขาดอากาศหายใจได้ กรณีการขาดอากาศหายใจจากการรั่วซึมของสารทำความเย็น R410A แทบจะไม่ปรากฏขึ้นเลย ด้วยจำนวนอาคารที่มีความหนาแน่นสูงเพิ่มขึ้นในปัจจุบัน การติดตั้งระบบเครื่องปรับอากาศหลายตัวจึงได้มีมากขึ้น เนื่องจากจำเป็นต้องใช้พื้นที่บนชั้นอาคารอย่างมีประสิทธิภาพ การควบคุมเฉพาะตัวเครื่อง การอนุรักษ์พลังงานด้วยการลดความร้อนและกำลังไฟฟ้า เป็นต้น

โดยเฉพาะอย่างยิ่ง ระบบเครื่องปรับอากาศหลายตัวสามารถเติมสารทำความเย็นได้ครั้งละจำนวนมาก เมื่อเทียบกับเครื่องปรับอากาศตัวเดียวแบบเดิม หากติดตั้งเครื่องปรับอากาศตัวเดียวของระบบเครื่องปรับอากาศหลายตัวในห้องขนาดเล็ก ให้เลือกรุ่นและขั้นตอนการติดตั้งที่เหมาะสม เนื่องจากหากเกิดเหตุสารทำความเย็นรั่วซึมออกมา ความเข้มข้นก็จะไม่สูงจนถึงขีดจำกัด (และในกรณีที่เกิดเหตุฉุกเฉิน อาจแก้ไขปัญหาล่วงก่อนที่การบาดเจ็บจะเกิดขึ้นได้)


ในห้องที่มีความเข้มข้นอาจเกินขีดจำกัด ให้ทำการเปิดช่องไปยังห้องที่อยู่ติดกัน หรือติดตั้งระบบถ่ายเทอากาศและเครื่องตรวจจับก๊าซรั่ว ความเข้มข้นแสดงค่าตามด้านล่าง

$$\frac{\text{ปริมาณทั้งหมดของสารทำความเย็น (kg)}}{\text{ปริมาตรต่ำสุดของห้องที่ติดตั้งเครื่องภายใน (m}^3\text{)}} \leq \text{ค่าจำกัดความเข้มข้นของสารทำความเย็น (kg/m}^3\text{)}$$

ค่าจำกัดความเข้มข้นของสารทำความเย็น R410A ที่ใช้ในเครื่องปรับอากาศหลายตัวอยู่ที่ 0.3 kg/m³

▼ หมายเหตุ 1

หากมีระบบทำความเย็นตั้งแต่ 2 ระบบขึ้นไปในอุปกรณ์ทำความเย็นตัวเดียวกัน ปริมาณของสารทำความเย็นควรเป็นไปตามที่คำนวณในอุปกรณ์แต่ละเครื่อง



สำหรับปริมาณที่คำนวณในตัวอย่างเป็น:


ปริมาณก๊าซทำความเย็นที่อาจรั่วไหลในห้อง A, B และ C อยู่ที่ 10 kg

ปริมาณก๊าซทำความเย็นที่อาจรั่วไหลในห้อง D, E และ F อยู่ที่ 15 kg

▼ หมายเหตุ 2


มาตรฐานสำหรับปริมาตรในห้องต่ำสุดมีดังนี้

- 1) ไม่มีผนังกัน (ส่วนที่แรงงา)




ข้อสำคัญ

- 2) เมื่อมีการเปิดช่องไปยังห้องที่อยู่ติดกันอย่างมีประสิทธิภาพเพื่อการระบายก๊าซสารทำความเย็นที่รั่วไหล (ช่องเปิดที่ไม่ใช้ประตูหรือช่องเปิดที่มีขนาด 0.15% หรือมากกว่าพื้นที่ว่างบนชั้นอาคารตามลำดับ ที่ส่วนบนหรือส่วนล่างของประตู)




- 3) หากตัวเครื่องภายในติดตั้งในห้องที่มีผนังกันในแต่ละห้องและการเดินท่อส่งสารทำความเย็นเชื่อมต่อระหว่างกัน ห้องที่มีขนาดเล็กสุดจะเป็นเป้าหมาย แต่เมื่อมีการติดตั้งระบบถ่ายเทอากาศเชื่อมต่อกันด้วยเครื่องตรวจจับก๊าซรั่วในห้องที่มีขนาดเล็กสุดซึ่งเกินค่าจำกัดความหนาแน่น ปริมาตรของห้องที่มีขนาดเล็กสุดถึงดัดไปจะเป็นเป้าหมาย



▼ หมายเหตุ 3

พื้นที่ชั้นอาคารภายในต่ำสุดเทียบกับปริมาณของสารทำความเย็น มีคร่าวๆ ดังนี้: (เมื่อความสูงของเพดานอยู่ที่ 2.7 m)



■ การยืนยันการตั้งค่าตัวเครื่องภายใน

ก่อนที่จะมีการส่งมอบ ให้ผู้ดูแลลูกค้า ให้ตรวจสอบที่อยู่และการทำงานของตัวเครื่องภายในที่ได้ติดตั้งในคอมมูนิตี้และกรอกใบตรวจสอบ (ตารางดังต่อไปนี้) บัณฑิตข้อมูลของตัวเครื่องทั้งสี่เครื่องลงในใบตรวจสอบ ทำสำเนาใบตรวจสอบนี้ตามจำนวนตัวเครื่องภายใน หากกรณีที่ติดตั้งเป็นระบบการควบคุมแบบเป็นกลุ่ม ให้ใช้ใบตรวจสอบนี้ด้วยการกรอกระบบของแต่ละสายเข้าไปในคู่มือการติดตั้งแต่ละเล่มที่ให้มาพร้อมกันกับตัวเครื่องภายใน

ข้อสำคัญ

ใบตรวจสอบนี้จำเป็นต้องใช้ในการบำรุงรักษาหลังจากการติดตั้ง กรอกใบตรวจสอบนี้และจากนั้นจึงยื่นคู่มือการติดตั้งให้กับลูกค้า

ใบตรวจสอบการตั้งค่าตัวเครื่องภายใน

ตัวเครื่องภายใน	ตัวเครื่องภายใน	ตัวเครื่องภายใน	ตัวเครื่องภายใน	ตัวเครื่องภายใน
ชื่อห้อง	ชื่อห้อง	ชื่อห้อง	ชื่อห้อง	ชื่อห้อง
รุ่น	รุ่น	รุ่น	รุ่น	รุ่น
ตรวจสอบที่อยู่ของตัวเครื่องภายใน (สำหรับวิธีการตรวจสอบ ให้อ้างอิงจาก การควบคุมการใช้งาน ในคู่มือเล่มนี้)				
* ในกรณีที่มีบริเวณเครื่องเดียว ไม่จำเป็นต้องกรอกที่อยู่ตัวเครื่องภายใน (CODE NO.: สาย [12], ตัวเครื่องภายใน [13], กลุ่ม [14], การควบคุมกลาง [03])				
สาย	ตัวเครื่องภายใน	กลุ่ม	สาย	ตัวเครื่องภายใน
สาย	ตัวเครื่องภายใน	กลุ่ม	สาย	ตัวเครื่องภายใน
ที่อยู่การควบคุมกลาง				
ที่อยู่การควบคุมกลาง				
ที่อยู่การควบคุมกลาง				
การตั้งค่าต่างๆ				

คุณได้เปลี่ยนการตั้งค่าพาด้านสูงหรือไม่? หากไม่ ให้กรอกเครื่องหมายตรวจสอบ [X] ใน [NO CHANGE] และกรอกเครื่องหมายตรวจสอบ [X] ใน [ITEM] หากมีการเปลี่ยนแปลงตามลำดับ (สำหรับวิธีการตรวจสอบ ให้อ้างอิงจาก การควบคุมการใช้งาน ในคู่มือเล่มนี้) * ในกรณีที่ติดตั้งระบบปรับอากาศแบบเป็นกลุ่ม การตั้งค่าจะมีการเปลี่ยนแปลงโดยอัตโนมัติ

แรงดันตั้งที่ภายนอก (CODE NO. [5d])	แรงดันตั้งที่ภายนอก (CODE NO. [5d])	แรงดันตั้งที่ภายนอก (CODE NO. [5d])	แรงดันตั้งที่ภายนอก (CODE NO. [5d])
<input type="checkbox"/> NO CHANGE	<input type="checkbox"/> NO CHANGE	<input type="checkbox"/> NO CHANGE	<input type="checkbox"/> NO CHANGE
<input type="checkbox"/> STANDARD	<input type="checkbox"/> STANDARD	<input type="checkbox"/> STANDARD	<input type="checkbox"/> STANDARD
<input type="checkbox"/> STATIC 1	<input type="checkbox"/> STATIC 1	<input type="checkbox"/> STATIC 1	<input type="checkbox"/> STATIC 1
<input type="checkbox"/> STATIC 2	<input type="checkbox"/> STATIC 2	<input type="checkbox"/> STATIC 2	<input type="checkbox"/> STATIC 2
<input type="checkbox"/> STATIC 3	<input type="checkbox"/> STATIC 3	<input type="checkbox"/> STATIC 3	<input type="checkbox"/> STATIC 3
<input type="checkbox"/> STATIC 4	<input type="checkbox"/> STATIC 4	<input type="checkbox"/> STATIC 4	<input type="checkbox"/> STATIC 4
<input type="checkbox"/> STATIC 5	<input type="checkbox"/> STATIC 5	<input type="checkbox"/> STATIC 5	<input type="checkbox"/> STATIC 5
<input type="checkbox"/> STATIC 6	<input type="checkbox"/> STATIC 6	<input type="checkbox"/> STATIC 6	<input type="checkbox"/> STATIC 6

คุณได้เปลี่ยนระยะเวลาการแสดงของสัญญาณเตือนให้ทำงานหรือไม่? หากไม่ ให้กรอกเครื่องหมายตรวจสอบ [X] ใน [NO CHANGE] และกรอกเครื่องหมายตรวจสอบ [X] ใน [ITEM] หากมีการเปลี่ยนแปลงตามลำดับ (สำหรับวิธีการตรวจสอบ ให้อ้างอิงจาก การควบคุมการใช้งาน ในคู่มือเล่มนี้)

ระยะเวลาการแสดงของสัญญาณเตือนให้ทำงานและอายุของแผ่นกรอง (CODE NO. [01])	ระยะเวลาการแสดงของสัญญาณเตือนให้ทำงานและอายุของแผ่นกรอง (CODE NO. [01])	ระยะเวลาการแสดงของสัญญาณเตือนให้ทำงานและอายุของแผ่นกรอง (CODE NO. [01])	ระยะเวลาการแสดงของสัญญาณเตือนให้ทำงานและอายุของแผ่นกรอง (CODE NO. [01])
<input type="checkbox"/> NO CHANGE	<input type="checkbox"/> NO CHANGE	<input type="checkbox"/> NO CHANGE	<input type="checkbox"/> NO CHANGE
<input type="checkbox"/> NONE	<input type="checkbox"/> NONE	<input type="checkbox"/> NONE	<input type="checkbox"/> NONE
<input type="checkbox"/> 150H	<input type="checkbox"/> 150H	<input type="checkbox"/> 150H	<input type="checkbox"/> 150H
<input type="checkbox"/> 2500H	<input type="checkbox"/> 2500H	<input type="checkbox"/> 2500H	<input type="checkbox"/> 2500H
<input type="checkbox"/> 5000H	<input type="checkbox"/> 5000H	<input type="checkbox"/> 5000H	<input type="checkbox"/> 5000H
<input type="checkbox"/> 10000H	<input type="checkbox"/> 10000H	<input type="checkbox"/> 10000H	<input type="checkbox"/> 10000H

คุณได้เปลี่ยนค่าเซ็นเซอร์อุณหภูมิที่ตรวจหรือไม่? หากไม่ ให้กรอกเครื่องหมายตรวจสอบ [X] ใน [NO CHANGE] และกรอกเครื่องหมายตรวจสอบ [X] ใน [ITEM] หากมีการเปลี่ยนแปลงตามลำดับ (สำหรับวิธีการตรวจสอบ ให้อ้างอิงจาก การควบคุมการใช้งาน ในคู่มือเล่มนี้)

อุณหภูมิที่ตรวจรับ การตั้งค่าเปลี่ยน (CODE NO. [06])	อุณหภูมิที่ตรวจรับ การตั้งค่าเปลี่ยน (CODE NO. [06])	อุณหภูมิที่ตรวจรับ การตั้งค่าเปลี่ยน (CODE NO. [06])	อุณหภูมิที่ตรวจรับ การตั้งค่าเปลี่ยน (CODE NO. [06])
<input type="checkbox"/> NO CHANGE	<input type="checkbox"/> NO CHANGE	<input type="checkbox"/> NO CHANGE	<input type="checkbox"/> NO CHANGE
<input type="checkbox"/> NO SHIFT	<input type="checkbox"/> NO SHIFT	<input type="checkbox"/> NO SHIFT	<input type="checkbox"/> NO SHIFT
<input type="checkbox"/> +1°C	<input type="checkbox"/> +1°C	<input type="checkbox"/> +1°C	<input type="checkbox"/> +1°C
<input type="checkbox"/> +2°C	<input type="checkbox"/> +2°C	<input type="checkbox"/> +2°C	<input type="checkbox"/> +2°C
<input type="checkbox"/> +3°C	<input type="checkbox"/> +3°C	<input type="checkbox"/> +3°C	<input type="checkbox"/> +3°C
<input type="checkbox"/> +4°C	<input type="checkbox"/> +4°C	<input type="checkbox"/> +4°C	<input type="checkbox"/> +4°C
<input type="checkbox"/> +5°C	<input type="checkbox"/> +5°C	<input type="checkbox"/> +5°C	<input type="checkbox"/> +5°C
<input type="checkbox"/> +6°C	<input type="checkbox"/> +6°C	<input type="checkbox"/> +6°C	<input type="checkbox"/> +6°C

คุณได้เปลี่ยนค่าแยกจำหน่ายที่ใช้งานหรือไม่? หากไม่ ให้กรอกเครื่องหมายตรวจสอบ [X] ในแต่ละ [ITEM] (ในกรณีที่มีการใช้งาน การเปลี่ยนค่าจะมีความจำเป็นทางเทคนิค สำหรับวิธีการเปลี่ยนค่าให้ดูคู่มือการติดตั้งที่ให้มาพร้อมกับชิ้นส่วนที่แยกจำหน่ายแต่ละชิ้น)

<input type="checkbox"/> อื่นๆ ()	<input type="checkbox"/> อื่นๆ ()	<input type="checkbox"/> อื่นๆ ()	<input type="checkbox"/> อื่นๆ ()
------------------------------------	------------------------------------	------------------------------------	------------------------------------





Installation Manual

Model name:

40VD ___ H-8S-TST



1128950164